

EXHIBIT 3  
USER'S MANUAL

FOUR (4) PAGE USER'S MANUAL FOLLOWS THIS SHEET

USER'S MANUAL  
FCC ID: EHK612TEVENFLO  
EXHIBIT 3

# evenflo Privacy Rechargeable Monitor with Sound Lights


## Owner's Handbook

Model G12 10/99

Thank you for purchasing the Evenflo Privacy Rechargeable Monitor.

Understanding how your monitor works helps you obtain the highest performance levels. Before setting up and using your Evenflo Privacy Rechargeable Monitor, please read this Owner's Handbook completely. It provides helpful tips to ensure the best operating circumstances for monitoring your child.

**IMPORTANT:** The Evenflo Privacy Rechargeable Monitor should not be used as a replacement for adult supervision of children. Please note that any modification of the transmitter or receiver will violate FCC compliance and can void the user's authority to operate this monitor set.



# Important Safety Instructions



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.

## ⚠ WARNING! ⚡

- DO NOT OPEN. NO USER SERVICEABLE PARTS INSIDE. RISK OF ELECTRIC SHOCK. MAY CAUSE SERIOUS INJURY, FIRE, OR DEATH.
- DO NOT USE NEAR WATER OR OUTDOORS.
- DO NOT PLACE FURNITURE ON CORD.

1. Read and follow all instructions carefully before using your Evenflo *Privacy* Rechargeable Monitor.



2. Read and observe all warnings on the product and in this Owner's Manual. Pay special attention to information marked "WARNING" and "IMPORTANT". This information can affect your child's safety. Keep this owner's manual nearby for quick and easy reference.

## ⚠ WARNING!



3. • Never place the baby's unit or its adapter cord in the crib or playpen, or within reach of the child. DO NOT hang this monitor near or on crib. The cord can present a strangulation hazard.
- Always keep the adapters, transmitter and receiver out of the reach of children.

## ⚠ WARNING!



4. AVOID PLACEMENT NEAR WATER AND MOISTURE. Do not use baby's unit outdoors. Do not use your monitor near a bathtub, shower, sink, laundry tub, swimming pool, wet basement or other locations where water or moisture are present.



5. Allow for proper ventilation of the adapters and the monitors. Do not place your monitor on or under a rug, bed, sofa, blanket or similar object that blocks its ventilation. Do not place it in a built-in installation such as a bookcase or stereo cabinet. These may impede the flow of air through the ventilation openings.



6. Remove the batteries from the Parent's Unit and unplug the AC adapters if the monitor will not be used for a long period of time.



7. Avoid placement near heat sources. Do not use your monitor near a radiator, stove, heat register, or other appliance (including amplifiers and TVs) that produce heat. Heat can damage the case or components.



8. Operate this monitor by using only the Evenflo rechargeable battery pack, or the Evenflo AC adapters provided, and plugging these adapters into standard household current (120V AC outlet). Do not use extension cords.

## ⚠ WARNING!

- This product does not replace responsible adult supervision of a child.
- You should check on your child regularly as this product will not detect your child's quiet activities.
- This product is not intended to be used as a medical monitor, and its use should not replace adult supervision. A responsible adult must stay within range of the Evenflo Static-Free Rechargeable Monitor at all times during use.
- Always be sure that both the Baby's and Parent's units are properly functioning, on the same channel and within reception range of each other.
- It is essential to check the sound reception regularly.



9. Protect AC adapter cords. Route cords so that they are not walked on or pinched by items placed upon them, and pay particular attention to cords at the AC adapter plugs, wall plugs, and where they plug into the transmitter or receiver.

## ⚠ WARNING!



10. DO NOT IMMERSE ANY COMPONENT IN WATER. Clean these monitors with a dry cloth.



11. Do not use near fluorescent lights, appliances with motors, televisions, fans or other machinery. These items may interfere with the quality of your units' transmission or reception.



12. Adapter must be removed from receiver for battery operation. In case of a power outage, batteries will not act as a backup if the adapter is engaged.

13. Do not use your monitor if:

- Either adapter or its cord has been damaged.
- Objects have fallen or liquid has been spilled into any of its components.
- It has been exposed to rain or water.
- It has been dropped or something inside is damaged.

14. Refer to the Troubleshooting Chart in this handbook before returning your monitor for servicing. You may be able to solve the problem on your own in very little time.

15. If service is required due to a possible defect, and the monitor is still under warranty, see Limited Warranty for instructions. This product should be serviced only by qualified service personnel at Evenflo Company, Inc. when:

- An AC adapter or its plug has been damaged.
- Objects have fallen or liquid has been spilled into the Transmitter or Receiver.
- The Transmitter or Receiver do not appear to operate normally or exhibit a marked change in performance.
- There are no user serviceable parts inside these monitors. Do not open the cases.

# Helpful Operating Tips

- FOR BEST RESULTS, use your AC adapter with the Parent's unit. The power is more consistent than that of the battery, and using the adapter provides clearer reception.
- In some homes, battery operation will dramatically reduce the effective range of the system.
- Your monitor's typical transmission/reception range is about 300 feet depending on battery power and possible obstructions (i.e. walls) that radio waves encounter. The methods and materials used in your home's construction, terrain and other factors may also affect transmission.
- For best results, use your adapter when you are in the same place (such as your bedroom at night or the kitchen during the day) over a long period of time. The adapter provides maximum power.
- WARNING: Your adapters are equipped with polarized alternating current line plugs (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Most building codes currently require polarized electrical outlets. Do not defeat the safety purpose of the polarized plug.

- WARNING: The AC adapters or rechargeable battery packs provided with these monitors should NOT be used with other equipment under any circumstances. Do not use any other product's adapter or rechargeable battery packs with this monitor. Different adapters and rechargeable battery packs use different amounts of current.
- IMPORTANT: This nursery monitor operates over public airwaves. Transmissions from your Baby's unit may be picked up by another product operating on the same frequency. Your Parent's unit may also pick up transmissions from another product on the same frequency. If interference occurs, change BOTH your Baby's and Parent's units to the alternate frequency channel.
- FOR BEST BATTERY PERFORMANCE, ALLOW BATTERIES TO COMPLETELY DISCHARGE EVERY FEW WEEKS.
- ALWAYS make sure that both units are on the same frequency channel. It is possible for the Parent's unit to pick up the Baby's unit even if they are on different channels when both units are close together. However, you'll experience static and interference.



UL Listed Adapter.  
FCC Approved.

## Using Your Evenflo

## Rechargeable Monitor

Before you set up your monitor, read "Important Safety Instructions" carefully and completely.

### Setting Up Your Monitor

Components: Baby's Unit (transmitter), Parent's Unit (receiver) and two identical AC adapters.

#### PARENT'S UNIT

The Parent's Unit is a receiver of sounds from the Baby's Unit (transmitter). Battery in Parent's Unit must be charged before portable use. You can use the Parent's Unit while it is being charged.

#### To charge:

- Attach the AC adapter to the Parent's Unit, fully extend the cord, and plug the adapter into a standard wall outlet. Use only the adapters included.
- Allow the battery to charge for 30 minutes before turning the Parent's Unit on.
- Allow the battery to fully charge for 24 hours before portable use.

#### BABY'S UNIT

The Baby's Unit is a transmitter, which sends sounds to the Parent's Unit (receiver).

- Place the Baby's Unit 5 to 10 feet from your baby.

**WARNING: DO NOT PLACE THE BABY'S UNIT OR ITS CORD IN THE CRIB OR WITHIN YOUR BABY'S REACH.**

- Aim the front of the Baby's Unit toward your baby. Be sure that there aren't any large objects blocking the path between the Baby's Unit and the baby.
- Attach the AC adapter to the Baby's Unit, fully extend the cord, and plug the adapter into an electrical outlet. Use only the adapters included.

### Using Your Monitor

#### BABY'S UNIT

- Check the channel switch. Insure the Baby's Unit is set to the same channel (frequency) as the Parent's Unit.
- Push down on the on/off button. Power light will glow *and green*.
- Turn off the Baby's Unit when not in use.

#### PARENT'S UNIT

- Check the channel switch. Insure the Baby's Unit is set to the same channel (frequency) as the Parent's Unit.
- Move to a room away from the Baby's Unit.
- Place the Parent's Unit where you can easily monitor it by sight or sound. You can use the Parent's Unit three ways:
  1. When the Parent's Unit is charged, place it where you can easily monitor it.
  2. When the Parent's Unit is charged, wear it using the belt clip.
  3. When the AC adapter is plugged into a standard wall outlet and the Parent's Unit is recharging.
- Turn on the Parent's Unit by rotating the On/Off Volume Control; adjust volume. The power light will glow *and green*.
- Speak into the Baby's Unit to verify sound transmission.

**RANGE INDICATOR LIGHT/OUT-OF-RANGE ALARM (SECURITY SENSOR)**  
Your Evenflo *Primary* Rechargeable Monitor has a unique coded transmission system. The Parent's Unit only works when it picks up a transmission containing this coded signal.

*The range indicator light will illuminate if the signal is lost for any reason and the alarm will sound.*

*At night you can sleep in peace knowing that any problem that prevents you from monitoring your child will cause the Out-of-range Alarm to sound.*

The alarm will sound if:

- The units are taken out-of-range of one another.
- They are set to different channels.
- Power to the Baby's Unit is lost.
- A strong interfering signal starts on the selected channel.

The Out-of-Range Alarm can only be stopped by re-establishing contact between the two units or by turning off the Parent's Unit. This new alarm feature is designed to give you the user-confidence and the reassurance that your Evenflo *Primary* Rechargeable Monitor is functioning correctly.

**Operational Range:** Your monitor's typical transmission/reception range is approximately 300 feet.

**Power Indicator Light:** In portable, battery-powered mode, light *when battery needs to be recharged.*

**Channel A/B:** If interference occurs, change BOTH your Baby's Unit and Parent's Unit to the alternate frequency channel.

The *Primary* Rechargeable Monitor operates over public airwaves. Transmission from your Baby's Unit may be picked up by another product if it is on the same frequency. Your Parent's Unit may also pick up transmissions from another product if it is on the same frequency.

#### RECHARGING THE BATTERY IN THE PARENT'S UNIT

The power light in the Parent's Unit goes out when it is time to recharge; the unit will not work unless it is plugged into a wall socket via the AC adapter.

#### To recharge:

- Attach the AC adapter into the Parent's Unit, plug it into a standard wall outlet.
- Allow the battery to charge for 24 hours. You can use the Parent's Unit while it is being charged.

**NOTE:** Continuously recharging the battery can reduce battery life. For best results, recharge the battery only after the monitor has been in use for several hours or when the power light goes out.

#### IMPORTANT:

- FOR BEST PERFORMANCE, ALLOW BATTERIES TO COMPLETELY DISCHARGE EVERY FEW WEEKS.

#### REPLACING THE RECHARGEABLE BATTERY IN THE PARENT'S UNIT

The rechargeable battery in the Parent's Unit needs to be replaced when the battery will not hold a charge or the battery will only hold a charge for a brief time. To order a new rechargeable battery pack for the Parent's Unit, call Evenflo Company, Inc. at 1-800-233-5921.

**NOTE:** Do not remove old battery pack until new pack is available for installation.

- Replace battery only with an Evenflo Model *rechargeable battery pack.*
- *TURN the unit upside down and remove the battery door.*
- Remove battery and disconnect.
- Attach new battery connector to connector in compartment.
- Place battery in compartment.
- Replace cover and snap securely in place.