



ROG PELTA

WIRELESS GAMING HEADSET


Product name: Gaming Headset
Model/Model: A501

Quick Start Guide
快速使用指南 (繁體中文)
快速使用指南 (简体中文)
クイックスタートガイド (JP)
간단사용설명서 (KO)
Guide de démarrage rapide (FR)
Schnellstartanleitung (DE)
Guida rapida (IT)
Guia de início rápido (PT:BR)
Краткое руководство (RU)
Guia de início rápido (ES)
Beknopte handleiding (NL)


Hızlı Başlangıç Kılavuzu (TR)
Стисле керівництво для початку експлуатації (UA)
Przewodnik szybkiego startu (PL)
Rychlý průvodce (CS)
Gid de pornire rapidă (RO)
Gyors üzembe helyezési útmutató (HU)
Snabbstartshandbok (SV)
Pikaopas (FI)
Hurtigstartveiledning (NO)
(AR) دليل التشغيل السريع
Stručný návod na používanie (SK)
מדריך להתחלה מהירה (HB)



Package contents



Headset features



1

2

3

4

5

1 Microphone Mute button / Microphone Mute button (TC) / Microphone Mute button (SC)


2 Audio control wheel / Audio control wheel (TC) / Audio control wheel (SC)

3 Function button / Function button (TC) / Function button (SC)


4 Mode switch / Mode switch (TC) / Mode switch (SC)

5 Microphone jack with LED / Microphone jack with LED (TC) / Microphone jack with LED (SC)

Installing the elastic headband



Buttons and switches



Microphone Mute button

Turn on/off RGB lighting 5s

Audio control wheel

Function button

Factory default (under 2.4GHz mode) 15s

Mode switch

Power off (USB mode) Bluetooth® mode RF 2.4GHz mode

LED indicators

Logo LED indicator	
Flashing (red)	Flashing (blue)
Headset charging	No Bluetooth device paired
Fast flashing (red)	Fast flashing (blue)
Low battery (below 20%)	Pairing to a device
Solid (green)	No light
Fully charged	Headset off

CAUTION! Using the headset whilst charging the power will cause the temperature of the headset to rise.

Microphone jack LED

Solid (red)	Microphone muted
No light	Microphone unmuted

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

Getting started

To set up your ROG PELTA gaming headset:

- Connect the headset to your device through Bluetooth® or dongle.
- Download the Armoury Crate software from <http://rog.asus.com> and then install it on your computer.

Pairing Bluetooth® again

You can pair Bluetooth® again by following the steps below.

- Turn off your headset
- Press and hold the **Function button** for 5 seconds.

安全上のご注意

Operating temperature
Operating temperature for this product while in use is 0°C ~ 40°C, with an operating voltage of 3.3V ~ 4.2V.

Operating temperature for this product while in use is 0°C ~ 40°C, with an operating voltage of 3.3V ~ 4.2V.

(五) 如对其他合法时无线电电台(站)产生有害干扰时,应立即停止使用,并采取措施消除干扰后方可继续使用;

(六) 在航空器内和依据法律法规、国家有关规定、标准规划的射电天文台、气象雷达站、卫星地球站(含测控、测距、测速、导航站)等军民用无线电电台(站)、机场等的电磁环境保护区域内使用微功率设备,应当遵守电磁环境保护及相关行业主管部门的规定;

(七) 禁止在以机场跑道中心点为圆心、半径500米的区域内使用各类模型遥控器;

(八) 本产品使用时工作温度为 -40°C ~ 40°C 、工作电压 $3.32\sim 4.2\text{V}$ 。

CAUTION! The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

低功率射頻器材技術規範

listen at high volume levels for long periods.

To prevent possible hearing damage, do not listen at high volume levels for long periods.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

部件名称	有害物质						
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴 素(PBB)	多溴二苯醚(PBDE)	
印刷电路板及电子组件	X	○	○	○	○	○	
塑胶外壳	○	○	○	○	○	○	
皮革耳罩	○	○	○	○	○	○	
麦克风组	X	○	○	○	○	○	
线材	X	○	○	○	○	○	
电池	X	○	○	○	○	○	

本表格依据 SJ/T 11364 的规定编制。

○：表示该有害物质在该部件所有均质材料中的含量超出 GB/T 26572 规定的限量要求以下。

×：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求，然该部件仍符合欧盟指令 2011/65/EU 的规定。

备注：此产品标示之环保使用期限，系指在一般正常使用状况下。

單元	限用物質及其化學符號					
	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr ⁶⁺)	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
印刷電路板及電子組件	—	○	○	○	○	○
塑膠外殼	○	○	○	○	○	○
皮革耳罩	○	○	○	○	○	○
麥克風組	—	○	○	○	○	○
其他及其配件	—	○	○	○	○	○

備考：1. "○" 係指該項限用物質之百分比含量未超過百分比含量基準值。
備考：2. "—" 係指該項限用物質為排除項目。

FCC COMPLIANCE INFORMATION

Per FCC Part 2 Section 2.1077



Responsible Party: **Asus Computer International**
Address: **48720 Kato Rd, Fremont, CA 94538.**
Phone/Fax No: **(510)739-3777/(510)608-4555**

hereby declares that the product

Product Name : **Gaming Headset**
Model Number : **A501**

compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Ver. 180620

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

ASUSTek Computer Inc. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of The Radio Equipment Regulations 2017 (S.I. 2017/1206). Full text of UKCA declaration of conformity is available at <https://www.asus.com/support/>.

Function	Frequency	Maximum Output Power EIRP (mW)
2.4GHz wireless	(2402 - 2480MHz) - Headset	< 100
	(2402 - 2480MHz) - Dongle	< 100
Bluetooth	(2402 - 2480MHz) - Headset	< 100

English ASUS/TEK Computer Inc. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of related Directives. Full text of EU declaration of conformity is available at: www.asus.com/support

Français AsusTek Computer Inc. déclare par la présente que cet appareil est conforme aux critères essentiels et autres clauses pertinentes des directives concernées. La déclaration de conformité de l'UE peut être téléchargée à partir du site Internet suivant : www.asus.com/support.

[www.asus.com/support](#)

Magyar Az ASUSTEK Computer Inc. ezennel kijelenti, hogy ez az eszköz megfelel a kapcsolódó irányelvnek / törvény követelményeinek és egyúttal vonatkozó rendszerteljesítési követelmények teljesítésére.

Latvian ASUSTEK Computer Inc. ar šo paziņo, ka šī ierīce atbilst saistošajai Direktīvu būtiskajām prasībām un citiem citiem saistošajiem nosacījumiem. Pils ES atbilstības paziņojuma teksts pieejams šeit:

[www.asus.com/support](#)

Bosanski ASUSTEK Computer Inc. ovim izjavljaju da je ovaj uređaj usklađen sa bitnim zahtjevima i ostalim odgovarajućim odredbama vezanim direktiva. Cijeli tekst ES izjave o usklađenosti dostupan je na:

[www.asus.com/support](#)

עברית אסוס טיפקמפר אינץ' אוזר יאזוואן דא זאל ווער די דאזיקער פארשטעלונג אז דאס געזעצטע צייכענען איז קלארענדיק מיט אלע דאס נוצנדיקע רעגולירונגען און אנדערע דאס באנוצטע סיסטעם פארשטעלונגען.

תוקנה 16/04/2018, תל ירוקלה נת השר המנדל על התחרות
המידענות והתודעתיות עבר האידור החסימה בחבובות, באתר:
[www.asus.com/support](#)

Bosanski ASUS[®]TeK Computer Inc. ovim izjavljuje da je ovaj uređaj usklađen sa bitnim zahtjevima i ostalim odgovarajućim odredbama vezanih direktiva. Cijeli tekst EU izjave o usklađenosti dostupan je na:
www.asus.com/support

Function	Frequency	Maximum Output Power EIRP (mW)
2.4GHz wireless	(2402 - 2480MHz) - Headset	< 100
	(2402 - 2480MHz) - Dongle	< 100
Bluetooth	(2402 - 2480MHz) - Headset	< 100

Официальные сайты ASUS в России:
www.asus.ru
www.asus.com/ru/support

Данное устройство соответствует требованиям Технического регламента Таможенного Союза ТР ТС 020/2011
 Электромагнитная совместимость технических средств утв. решением КТС от 09.12.2011г. №879

Visit our multi-language website at <https://www.asus.com/support>.



Manufacturer	ASUSTek COMPUTER INC.
Address, City	1F, No. 15, Lide Rd., Beitou Dist., Taipei City 112
Authorized Representative in Europe	ASUS COMPUTER GmbH
Address	Harkortstrasse 21-23, 40880 Ratingen
Country	Germany
Authorized Representative in United Kingdom	ASUSTEK (UK) LIMITED
Address	1st Floor, Sackville House, 143-149 Fenchurch Street, London, EC3M 6BL, England
Country	United Kingdom

CE Mark Warning
CE

Français AsusTek Computer Inc. déclare par la présente que cet appareil est conforme aux critères essentiels et autres clauses pertinentes des directives concernées. La déclaration de conformité de l'UE peut être téléchargée à partir du site Internet suivant : www.asus.com/support.