

(W) 381mm

## Back panel

## Outside panel

Front panel

ww/zl (H) 127mm



|                          |               |
|--------------------------|---------------|
| <b>Zoom in / out</b>     |               |
| 拡大 / 縮小                  |               |
| ズームイン / ズームアウト           |               |
| увеличение / уменьшение  |               |
| Zoom in / out            | تصغير / تكبير |
| Zoom avant / arrière     |               |
| Ingrandir / Réduire      |               |
| Vergrößern / Verkleinern |               |
| Zoom inn / out           |               |
| Zoom inn / out           |               |
| Azcarar / Alajar         |               |
| Ampliar / Reduzir        |               |
| Platziert / oddalit      |               |
| Mayebawon / Jukjupwon    |               |
| 확대 / 확대 / 축소             |               |
| Ampliar / Reduzir        |               |
| Byodime / Kucitum        |               |

|      |    |    |    |      |        |       |        |       |       |        |        |       |      |      |      |    |      |      |
|------|----|----|----|------|--------|-------|--------|-------|-------|--------|--------|-------|------|------|------|----|------|------|
| Back | 返回 | 后退 | 戻る | Haza | Tilbaw | Retor | الرجوع | Indie | Zurûr | Tilbaw | Tilbaw | Atrâs | Recu | Zpét | flaw | 뒤로 | Recu | Gerî |
|------|----|----|----|------|--------|-------|--------|-------|-------|--------|--------|-------|------|------|------|----|------|------|

|                |          |
|----------------|----------|
| <b>Forward</b> |          |
| 向前             | Binepêd  |
| 前进             | Framåt   |
| 進む             | Suivant  |
|                | لاحام    |
|                | Avanti   |
|                | Weiter   |
|                | Fremover |
|                | Fremad   |
|                | Adelante |
|                | Avançar  |
|                | Vpřed    |
|                | Eμπρός   |
|                | 앞으로      |
|                | Avançar  |
|                | ileri    |

[illegible]

Οδηγός Γρήγορης  
Guia Rápido



Dell™ WM514

# Quick Start Guide

|                            |                               |
|----------------------------|-------------------------------|
| 快速開始指南<br>クイックスタートガイド      | 快速入門指南<br>Краткое руководство |
| Guide till snabbstart      | Guide de démarrage            |
| دليل التشغيل السريع        | Guide all'avvio rapido        |
| Schnelstartanleitung       | Hurtigstartsveiledning        |
| Vejledning til hurtigstart | Guia de início rápido         |
| Guia de inicio rapido      | Uvodni priručka               |
| Οδηγος Γρήγορης Εκκίνησης  | 빠른 실행 가이드                     |
| Guia Rápido                | Hızlı Başlangıç Kılavuzu      |

快速開始指南

快速入門指南

クイックスタートガイド

Краткое руководство

Guide till snabbstart

Guide de démarrage rapide

Guide till snabbstart | Guide de démarrage rapide

دليل التشغيل السريع | Guida all'avvio rapido

Schnellstartanleitung | HURTIARTSVEILEDNING

Veiledning til hurtigstart | Gufa de inicio rápido

Guia de início rápido | Introdução rápida

Οδοντός [Οόντονος Εγκύλιος] | 배트 시퀀스 가이드

Guia Bápido | Hızlı Başlangıç Kılavuzu


30500X0050E

© 2015 Dell Inc. All right reserved.


Inside panel

(W) 381mm

(H) 127mm



[www.dell.com/support](http://www.dell.com/support)



Windows 8 Only



Windows 8 Only



|                           |
|---------------------------|
| Windows charms 功能表        |
| Windows charms            |
| Windows charms            |
| Windows 차름 - W            |
| Чармы Windows             |
| Windows snabbtastfalt     |
| Icônes Windows            |
| Windows charms ميزات      |
| Icone promemoria di Wind  |
| Windows-Charms            |
| Windows charms (Window    |
| Windows charms            |
| Windows charms            |
| Acessoos de Windows       |
| Windows charms            |
| Ovaldaci tlačítka Windows |
| Windows charms            |
| 윈도우 차름 - 창 (charms bar)   |
| Windows charms            |
| Windows 차름                |
| Windows 차름 Yan Chubutu    |

|        |          |                            |                |              |              |                          |                     |                   |                        |            |                      |                 |
|--------|----------|----------------------------|----------------|--------------|--------------|--------------------------|---------------------|-------------------|------------------------|------------|----------------------|-----------------|
| 應用程式切換 | App-byte | Changer d'application      | متاح التطبيقات | App-by-typer | Skin all app | Selector de aplicaciones | Alternar aplicativo | Přepínat aplikace | Mengenalap as eapuyonj | 응용 프로그램 전환 | Mudança de aplicação | Uqaulama Sicimi |
| 應用程序切换 | アプリスイッチ  | Переключение на приложение |                | App-Wechsel  |              |                          |                     |                   |                        |            |                      |                 |

|       |                     |                        |                |                |                            |                          |                     |                        |             |                           |                          |                      |           |                        |          |                           |                     |
|-------|---------------------|------------------------|----------------|----------------|----------------------------|--------------------------|---------------------|------------------------|-------------|---------------------------|--------------------------|----------------------|-----------|------------------------|----------|---------------------------|---------------------|
| 撫摩和接觸 | Scorri e panoramica | Scrollen und schwenken | Blå og høft    | Rul og panorer | Displazarse y panorámica   | Rolagem e panorâmica     | Posounout           | Kölmön közi jastatónon | 스크롤 및 이동    | Deslocamento e panorâmica | Kaydırma ve tersviz      |                      |           |                        |          |                           |                     |
| 滾動和平移 | スクロール / パン          | Прокрутка и панор      | Klicka och dra | تدوير          | Defillement et panoramique | Defilieren und schwenken | Scorri e panoramica | Scrollen und schwenken | Blå og høft | Rul og panorer            | Displazarse y panorámica | Rolagem e panorâmica | Posounout | Kölmön közi jastatónon | 스크롤 및 이동 | Deslocamento e panorâmica | Kaydırma ve tersviz |

|                          |
|--------------------------|
| Windows charms 功能表       |
| Windows charms           |
| Windows charms           |
| Windows 차름 - W           |
| Чармы Windows            |
| Windows snabbtastfalt    |
| Icônes Windows           |
| Windows charms ميزات     |
| Icone promemoria di Wind |
| Windows-Charms           |
| Windows charms (Window   |
| Windows charms           |
| Windows charms           |
| Acesso de Windows        |
| Windows charms           |
| Ovaldac tlačítka Windows |
| Windows charms           |
| 윈도우 차름 - 창 (charms bar)  |
| Windows charms           |
| Windows 차름               |
| Windows 차름 Yan Chubutu   |

[illegible]

|       |                     |                       |                |                |                            |                      |                       |                       |                |                           |                      |           |                       |          |                           |                     |
|-------|---------------------|-----------------------|----------------|----------------|----------------------------|----------------------|-----------------------|-----------------------|----------------|---------------------------|----------------------|-----------|-----------------------|----------|---------------------------|---------------------|
| 抛量初接觸 | Scorri e panoramica | Scorren und schwenken | Blå og høft    | Rul og panorer | Displazarse y panorámica   | Rotagem e panorâmica | Posounout             | Kölmön kös iustatömon | 스크롤 및 이동       | Deslocamento e panorâmica | Kaydırma ve tersviz  |           |                       |          |                           |                     |
| 滾動和平移 | スクロール / パン          | Прокрутка и панор     | Klicka och dra | تدوير          | Defillement et panoramique | Scorri e panoramica  | Scorren und schwenken | Blå og høft           | Rul og panorer | Displazarse y panorámica  | Rotagem e panorâmica | Posounout | Kölmön kös iustatömon | 스크롤 및 이동 | Deslocamento e panorâmica | Kaydırma ve tersviz |