


FRONT

BACK



Model: KP-542  
Bluetooth® Karaoke with 2 Wireless Microphones

BC



Back of Speaker

**Wired Mic Port**  
Insert a wired microphone (not included) into the 6.5mm mic port to use instead of wireless microphone, if desired.

**Aux-In Port**  
Insert an Aux-in cable to play audio from other sources. This 3.5mm port is for audio input only—not a microphone port.

**USB Port**  
Insert a USB flash drive to play MP3 music. For best results, use a USB flash drive with capacity no larger than 64GB. Maximum supported USB flash drive capacity is 128GB.

LED Status Indicators

Battery Charging Status on Speaker

|   |     |                |
|---|-----|----------------|
| ● | RED | charging*      |
| ● | OFF | fully charged* |


\* The speaker will sound a tone when the battery power is low, indicating that it needs to be recharged.

Battery Charging Status on Wireless Mic



|   |     |                |
|---|-----|----------------|
| ● | RED | charging*      |
| ● | OFF | fully charged* |

\* The wireless mic will flash fast blue when the battery power is low, indicating that it needs to be recharged.

Charging The Speaker/Wireless Mic



Bottom of Wireless Mic



CHARGE THESE  
UNITS BEFORE USE  
ABOUT 4 HOURS

Bluetooth® Operation

Note: If the KP-542 unit is currently linked via Bluetooth to a device and you want to pair to another device, first turn off Bluetooth on the linked device and "Karaoke 542" will now appear on the new device. Select it to pair the new device.

1. The first time you power on the speaker the unit will enter Bluetooth® pairing mode.
- Select "Karaoke 542" on your device to pair.
2. Short press the **MI** to play/pause music.
3. Short press the **MI** button to go to the previous song.
4. Short press the **MI** button to go to the next song.
5. After your device has been paired successfully for the first time it will automatically link to the KP-542 the next time it is powered on in Bluetooth® mode.

Note: The KP-542 can connect to only one Bluetooth device at a time.

Wireless Stereo

(REQUIRES 2 SPEAKERS)

1. Power on two speakers and enter Bluetooth® mode.
2. Turn off the Bluetooth® function on your phone or other Bluetooth® device. Long press the **MI/TWS** button of either speaker. A beep tone will be heard to signify that the two speakers have connected via Bluetooth®.
3. Turn on Bluetooth® on the mobile phone and search for "Karaoke 542" and connect. A voice prompt will announce "Connected" signifying that the mobile has connected to the speakers. You can now enjoy music from the two speakers.
4. Both units will link automatically next time when both units are powered on.
5. To disable Wireless Stereo, and reset Bluetooth pairing: long press the **MI/TWS** button of either speaker, and a beep tone will be heard to signify that the two speakers have disconnected.

Troubleshooting

No Sound

- Check if the unit and mic are powered on.
- Check whether the Bluetooth® is connected successfully.
- Adjust the volume.

Presence of Noise

- Verify the location is free of environmental noise interfering with the KP-542 unit/wireless microphone and your device.
- Verify the wireless microphone is within 10 meter (30 foot) range of the KP-542 unit.

The Bluetooth® connection is not available

- Check to see if Bluetooth® is enabled.
- Please check the distance between the KP-542 and your device is within 10 meters (30 feet).
- The karaoke unit is already paired with another phone. First, turn off the Bluetooth® on the other phone and restart the unit, then try to pair with the phone again.
- Check whether there are external devices such as a TF card, scan disk, Aux-in cable, ...etc. are installed or connected. If there are external devices connected, please unplug them and search for the Bluetooth® name again.

Internal Rechargeable Lithium-ion Battery

This device uses an internal rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead, try charging it several times. If problems persist, do not attempt to replace the battery yourself, see warranty for factory service.

CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if mistreated. Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Always confirm that the temperature is 5°C – 35° C (41° - 95° Fahrenheit) before you charge the battery. Leakage or deterioration of the battery may occur if this warning is not heeded.

- Charging the battery should be conducted under adult supervision.
- Never expose the battery to any liquid.
- Never expose the battery to excessive heat such as direct sunlight or fire. Never use the battery pack in an unventilated vehicle where excessive internal temperatures may be encountered.
- Always keep the battery out of the reach of infants and small children.
- Always charge lithium devices on a non-flammable surface - wooden tables, carpeted floors, and bedding are not recommended charging surfaces.

Disposal

- Do not dispose of lithium-ion batteries in household trash or recycling bins.
- Recycle batteries at certified collection centers. Visit [www.call2recycle.org](http://www.call2recycle.org) to find a location near you.

FCC ID: EMO542A  
IC: 986B-542A  
HVIN: XX-542a

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Information

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Compliance

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. The device shall be operated and installed without restriction. Cet équipement est conforme aux limites d'exposition aux rayonnements établies par la FCC pour un environnement non contrôlé. Son utilisation et son installation ne sont assujetties à aucune restriction.

ONE YEAR LIMITED WARRANTY

For product support and warranty please visit: <https://ekids.com/pages/contact>

© 2026 ekids, LLC  
Questions? Visit <https://ekids.com/pages/contact>

KP-542\_051826-A

Printed in China