



The diagram illustrates the components of the B57 headphones. On the left is a line drawing of the B57 headphones, showing the headband, ear cups, and a control module on the right ear cup. Below the headphones is the label "B57 Headphones". To the right of the headphones are two cables. The top cable is a "Detachable Audio Cable*" with a 3.5mm audio jack on one end and a connector for the headphones on the other. Below it is a "USB-C Charging Cable" with a USB-C connector on one end and a standard USB-A connector on the other. The asterisk in the cable label indicates that the detachable audio cable is only available for certain models.

B57 Headphones

Detachable Audio Cable*
(*select models only)

USB-C Charging Cable

Computer connected to working outlet

Computer USB port

USB Adaptor (not included)

OR

Function	Action Required
Turn headphones On	When headphones are 'Off', <i>press and hold</i> the Power Button for 3 seconds until the LED indicator flashes red.
Enter Pairing Mode	<i>Double press</i> the Power Button to manual pairing mode, the LED indicator alternately flashing red and blue.
Pairing	Make sure your Bluetooth device is 'On' and discoverable. When "Kids B5" appears on your device's menu, select it to complete pairing.
Play / Pause	Short press the Play/Pause Button to start playback. Short press to pause playback. Short press to resume playback.
Skip to next track	Press the + button twice during playback.
Skip to beginning of current track	Press the ⏮ button twice during track playing after 5 seconds.
Skip to beginning of previous track	Press the ⏮ button twice in the track playing the beginning 5 seconds.
Increase volume	Press the + button during playback (hold for rapid setting)
Decrease volume	Press the - button during playback (hold for rapid setting)
Answer an incoming phone call	Short press the Play/Pause Button when you hear the incoming ring sound. NOTE: Music will automatically pause when you are answering a call and resume when you end the call.
End a call	Short press the Play/Pause Button to end the call and 'hang up'.
Transfer a call between the phone and the headphones	While the call is in progress, <i>press and hold</i> the Play/Pause Button for 2 seconds.
Last number redial	When no call is in progress, double press Play/Pause button to redial the last number.
Siri/Google Assistant	<i>Press and hold</i> the Play/Pause button for 2-3 seconds.
Reset Bluetooth/Clear all paired devices	<i>Press and hold</i> the + for 5 seconds during pairing mode.
Turn headphones Off	<i>Press and hold</i> Play/Pause button for 5 seconds until the LED indicator turns red and then shuts off. Headphones will shut off automatically if no music plays for 60 minutes.

CAN ICES-3 (B)/NMB-3(B)

B57EX-IB 011325-A