

Model: iUVBT1 QSG
Instruction manual - US English
Size: 400mm(W) x 150mm(H)
Folded Size: 80 x 150 mm
157g, Art paper / 1C + 1C / Straight corners
July 7, 2020

iHome
HEALTH

POWERUVC PRO


360° UV-C Sanitizer
with Bluetooth Speaker



Model: iUVBT1

Quick Start Guide

QUESTIONS? visit www.ihome.com



USING THE SANITIZER

This superior quality UV-C LED light safely kills up to 99.9% of surface germs in under 3 minutes, without using harmful chemicals.

The iUVBT1 is safe to use on everyday essentials including smartphones, cosmetic tools, toothbrushes, and more.

INSTALLING THE UV SHELF

A shelf is provided to ensure optimal spacing between your objects and the UVC LEDs. Place the shelf inside the cabinet, and firmly press it into the locking tabs.

SANITIZING ITEMS

1. Make sure the iUVBT1 is plugged into a working wall outlet. Lift the lid of the unit and place items on the shelf, making sure to not overlap items. Close the lid.
2. Press and release the **Sanitize Button** to begin a 3 min sanitizing cycle. A countdown timer will display the remaining cycle time. LED status indicator (around the rim of the cabinet) will slowly blink, and a tone will sound when the cycle is complete.
3. Features a built-in safety switch that will shut off the UV light whenever the lid is opened. Do not attempt to defeat the safety function and operate the unit with an open lid.
4. If the lid is opened during the UV sanitizing cycle, the timer will pause. Closing the lid within 1 minute will resume the cycle.
5. We recommend leaving the shelf in place while sanitizing your items. If items are too large, the shelf may be removed. In those cases, we recommend flipping the items over and sanitizing a second time for optimal effect.
6. To cancel a sanitizing cycle, press the **Sanitize Button**.

NOTES

1. Features a built-in safety switch that will shut off the UV light whenever the lid is opened. Do not attempt to defeat the safety function and operate the unit with an open lid.
2. Press and release the **Sanitize Button** to begin a 3 min sanitizing cycle. A countdown timer will display the remaining cycle time. LED status indicator (around the rim of the cabinet) will slowly blink, and a tone will sound when the cycle is complete.
3. Features a built-in safety switch that will shut off the UV light whenever the lid is opened. Do not attempt to defeat the safety function and operate the unit with an open lid.
4. If the lid is opened during the UV sanitizing cycle, the timer will pause. Closing the lid within 1 minute will resume the cycle.
5. We recommend leaving the shelf in place while sanitizing your items. If items are too large, the shelf may be removed. In those cases, we recommend flipping the items over and sanitizing a second time for optimal effect.
6. To cancel a sanitizing cycle, press the **Sanitize Button**.

CLOCK AND BLUETOOTH SETUP

Step One: Connecting the Unit

Connect the included AC adapter to the DC jack located on the back of the unit and connect the other end to a working wall outlet.



Step Two: Setting Your Clock

- Remove battery pull tab from the bottom of the unit.
- Press and hold the **Time Set Button** until the display flashes.
- Press the **or + Buttons** to adjust selections and tap **Time Set** to confirm (make sure you set the correct AM/PM time).
- Do this for time, year, month, and date.
- All done!

Daylight Savings Time: By default, the **DST Switch** is set to Auto and will automatically adjust the time in March/November.

Tip: Press either **Alarm Button** during clock setting to toggle between 12/24 hour display modes.

Step Three: Bluetooth Pairing

- Press the **Power Button** to turn the unit ON. Turn on your Bluetooth device and make it 'discoverable' by turning on Bluetooth mode.
- The unit will automatically enter pairing mode.
- Select 'iHome iUVBT1' on your device's Bluetooth menu to connect.

(To manually pair your device, press and hold the **Bluetooth Pairing Button** until the Bluetooth Pairing icon flashes to indicate the unit is in pairing mode.)

USING THE AUTO DIMMER

This unit is equipped with a sensor that will automatically adjust the brightness of the clock display based on ambient light in your room. When the room is well lit, the display will adjust to Hi brightness for better visibility. In a dark room, it will dim to a lower brightness. You can adjust the 'lower limit' of the Auto-dimmer to fit your personal preference of display brightness in a dark room.

The 3 options are:

- **"Auto 2"** - minimum brightness setting will be level 2
- **"Auto 1"** - minimum brightness setting will be level 1
- **"Auto 0"** - clock display will turn FULLY OFF in a dark room

To adjust Dimmer settings:

Press the **Snooze/Dimmer Button repeatedly** to cycle through brightness levels: Auto 1, Auto 2, Auto 0, Hi, 3, 2, Lo, or OFF. (Note: choosing **Hi, 3, 2, Lo, or OFF** are fixed settings and will not auto-adjust.)

USING ALARMS

Dual alarms can be set to different times and alarm sources. Each is set in the same way. Instructions are given as 'Alarm Button', use **Alarm 1 Button** or **Alarm 2 Button** to set respective alarms.

1. Press and hold the **Alarm Button** for 2 seconds until the display flashes. A beep sounds.
2. Press the **or + Buttons** to adjust the alarm time to the desired time (hold for rapid setting). Make sure you set the correct AM/PM alarm time. The PM indicator appears to the left of the display.
3. Press the **Alarm Button** to confirm the alarm time setting. The alarm schedule will flash. 7 (every day), 5 (weekdays) or 2 (weekend only). Press the **or + Buttons** to select an alarm schedule.

(continued on next page...)

USING THE ALARMS (CONTINUED)

4. Press the **Alarm Button** to confirm the alarm schedule. The wake-to source will flash.
 5. Press the **or + Buttons** to select the desired wake-to alarm source: Bluetooth or Tone.
 - Wake to Bluetooth:** You will wake to the currently listed Bluetooth device. If no device is detected, the alarm will default to the last tone selected.
 - Wake to Tone:** Press the **Alarm Button** to confirm. Press the **or + Buttons** to select the desired tone to wake to (Tone 1-Tone 4).
 6. Press the **Alarm Button** to confirm wake-to source. The alarm volume will flash.
 7. Press the **or + Buttons** to adjust the alarm volume.
 8. Press the **Alarm Button** to confirm the alarm settings and exit alarm setting mode. 2 beeps will confirm alarm setting is complete. The alarm icon will remain on the display to show the alarm is armed.
- To Preview:** Press and release the **Alarm Button** to view the current alarm time.
- Turning Alarms ON/OFF:** Press and release the **Alarm Button** twice within 5 seconds to toggle the alarm ON and OFF, indicated by the related white alarm indicator.
- When the alarm sounds, press the **Power/Alarm Reset Button** or the corresponding **Alarm Button (1 or 2)** to disable the alarm and reset it to come on at the same time the next day.

SNOOZE / DISPLAY DIMMER

Snooze: When the alarm is sounding, press the **ZZZ/Dimmer Button** to snooze for 9 minutes.

Dimmer: Press the **ZZZ/Dimmer Button** (when alarm is NOT sounding) to adjust display brightness. (Display can be dimmed during Snooze mode.)

PROGRAMMABLE SNOOZE

To adjust the snooze duration:

1. Press and hold the **ZZZ/Dimmer Button**.
2. Use the **or + Buttons** to adjust the snooze duration from 1-29 minutes. Press the **ZZZ/Dimmer Button** again to confirm.

CHARGING DEVICES VIA USB

There are 2 USB charging ports on the iUVBT1 - each is 1A. To charge your devices, connect a standard USB cable from included to a USB port on the unit, and plug the other end into the charging port on your device.

Note: Unit must be plugged into a working outlet in order to charge devices.

Battery Back-Up

The unit comes with a CR-2450 back-up battery installed to provide continuous alarm operation and clock settings in the event of a temporary power failure. Remove the battery pull tab before use. When the battery icon on the clock display is flashing, it is time to replace the back-up battery. The battery compartment is located on the bottom of the unit.

1. Make sure the AC adapter is connected, or you will lose your time and alarm settings during battery replacement.
2. Use a Phillips screwdriver to open the battery compartment door.
3. Remove exhausted battery from compartment and insert 1 CR-2450 battery, checking that the + side is facing you. Replace compartment door. Do not overtighten.

WARNING: Lithium batteries can explode or cause burns if disassembled, shorted, recharged, exposed to water, fire, or high temperatures. Do not place loose batteries in a pocket, purse, or other container containing metal objects, mix with used or other battery types, or store with hazardous or combustible materials. Store in cool, dry, ventilated area. Follow applicable laws and regulations for transport and disposal.

- Do not ingest the battery. Chemical Burn Hazard. This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
 - Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
 - Attention should be drawn to the environmental aspects of battery disposal.
- Maintenance • Caring For Your Device**
- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
 - Remove the plastic protective film from the clock display.
 - Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.
 - Should the casing of your device become soiled, you may wipe down with a moist cloth.
 - Do not immerse the device into water or any cleaning solvents.
 - Do NOT use gasoline, benzene, thinner, harsh cleaners, etc on and/or in the unit while cleaning, as they may damage the product. NEVER use alcohol or other solvents.

IMPORTANT SAFETY INSTRUCTIONS

Please read all warnings, read and follow all instructions and keep these instructions handy for future reference.

WARNING: DO NOT ATTEMPT TO OPERATE THIS DEVICE WITH THE LID OPEN. This device must only be operated in safety with low voltage corresponding to the power source used.

WARNING: This device is not for use in the presence of flammable or explosive gases. When the lid is open, it is important not to allow or tamper with this safety feature as UV-C light can cause damage to eyesight and skin.

WARNING: KEEP OUT OF REACH OF CHILDREN: This device is not a toy and is not intended to be used by children.

ATTENTION: Use only the supplied power adapter. This product must only be operated in safety with low voltage corresponding to the power source used.

ATTENTION: Prolonged or excessive exposure to UV-C light may degrade and/or damage plastic, plastics and other non-metallic materials.

Power operation away from strong magnetic fields:

• Do not look directly at the UV-C source.

• Device is intended for indoor use only. Do not use outdoors or on wet surfaces.

• Device should be protected from the elements and from temperatures below freezing.

• Do not operate/drop near water or while bathing or swimming, do not handle the device with wet hands.

• Only use as intended. Use according to the manufacturer's instructions without tampering or modifying the device in any way.

• Do not alter the construction or design of the device, except safety labels, markings or devices.

• Do not use device for other than its intended purpose, as described in the manual.

• Do not operate if any damage to the unit is visible or suspected, such as after being dropped.

• Do not use if charging cable/cord is damaged.

• Keep the cable/cord and device away from heated surfaces.

• Close supervision is necessary when any appliance device is used by or near children and people with special needs.

• Do not operate in the presence of explosives and/or flammable fumes, smoke or flames.

Disclaimer: This product is not intended to diagnose, treat, cure or prevent any disease or medical condition. The information provided herein is not to be construed as a medical diagnosis or medical advice. No medical claims are implied or intended with the use of this device. Purchaser assumes responsibility for correct and proper use of device.

1 Year Limited Warranty

For warranty and full instructions, visit ihome.com/support

© 2020 iSD Technology, Inc. All rights reserved. Questions? Visit www.ihome.com

FCC Information

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device complies with Part 15 of the FCC Rules, which requires the user to stop operating the device if it is found to cause interference.

(1) This device may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to your radio reception, you may need to take one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

The device complies with ICES-003 exposure requirement, users can obtain Canadian information on RF exposure and compliance.

This device complies with ICES-003 exposure requirement (maximum) that complies with the Canadian Radio-television and Telecommunications Commission (CRTC) regulations.

Operation is subject to the following two conditions: 1. This device may not cause interference, 2. This device must accept any interference, including interference that may cause undesired operation of the device.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.

Call equipment or contact your retailer to obtain the equipment's CE mark.