

#103955-26



IMRC-INT for Conducted



IMRC-INT



IMRC-EXT



3dBi Antenna



5dBi Antenna



5VDC Adapter



12VDC Adapter



Power Distribution



Tablet Power Adapter




Tablet #1



Tablet #2



12VDC Power Supply



IMRC-INT




IMRC-EXT



Configuration 1




Configuration 2




Configuration 1



Configuration 2



7" Tablet




X Axis, IMRC-INT




X Axis, IMRC-INT



Y Axis, IMRC-INT



Z Axis, IMRC-INT



Above 1GHz, IMRC-INT



X Axis, IMRC-EXT 3dBi



X Axis, IMRC-EXT 3dBi



Y Axis, IMRC-EXT 3dBi



Z Axis, IMRC-EXT 3dBi




Above 1GHz, IMRC-EXT 3dBi



IMRC-EXT 5dBi



IMRC-EXT 5dBi



X Axis, IMRC-EXT 5dBi



Y Axis, IMRC-EXT 5dBi



Z Axis, IMRC-EXT 5dBi



Above 1GHz, IMRC-EXT 5dBi



Configuration 3



Configuration 3



Configuration 4



Configuration 4

#103955-27



IMRC-INT



IMRC-EXT




3dBi Antenna



5dBi Antenna



5VDC Adapter



12VDC Adapter



Power Distribution



Tablet Power Adapter




Tablet #1



Tablet #2




12VDC Power Supply



IMRC-INT



IMRC-EXT




X Axis, Configuration 5




X Axis, Configuration 5



Y Axis, Configuration 5



Z Axis, Configuration 5



X Axis, Configuration 6



X Axis, Configuration 6



Y Axis, Configuration 6




Z Axis, Configuration 6



Configuration 7



Configuration 7




X Axis, Configuration 7




Y Axis, Configuration 7



Z Axis, Configuration 7



7" Tablet




X Axis, IMRC-INT




X Axis, IMRC-INT



Y Axis, IMRC-INT



Z Axis, IMRC-INT



Above 1GHz, IMRC-INT



X Axis, IMRC-EXT 3dBi



X Axis, IMRC-EXT 3dBi



Y Axis, IMRC-EXT 3dBi



Z Axis, IMRC-EXT 3dBi




Above 1GHz, IMRC-EXT 3dBi



IMRC-EXT 5dBi



IMRC-EXT 5dBi



X Axis, IMRC-EXT 5dBi



Y Axis, IMRC-EXT 5dBi



Z Axis, IMRC-EXT 5dBi



Above 1GHz, IMRC-EXT 5dBi



Configuration 3



Configuration 3



Configuration 4



Configuration 4

103955-28



IMRC-INT



IMRC-EXT




3dBi Antenna



5dBi Antenna



5VDC Adapter



12VDC Adapter



Power Distribution



Tablet Power Adapter




Tablet #1




Tablet #2



12VDC Power Supply






X Axis, Configuration 5




X Axis, Configuration 5



Y Axis, Configuration 5



Z Axis, Configuration 5



X Axis, Configuration 6



X Axis, Configuration 6



Y Axis, Configuration 6




Z Axis, Configuration 6



Configuration 7



Configuration 7




X Axis, Configuration 7




Y Axis, Configuration 7




Z Axis, Configuration 7





7" Tablet




X Axis, IMRC-INT




X Axis, IMRC-INT



Y Axis, IMRC-INT



Z Axis, IMRC-INT



Above 1GHz, IMRC-INT



X Axis, IMRC-EXT 3dBi



X Axis, IMRC-EXT 3dBi



Y Axis, IMRC-EXT 3dBi



Z Axis, IMRC-EXT 3dBi




Above 1GHz, IMRC-EXT 3dBi



IMRC-EXT 5dBi



IMRC-EXT 5dBi




X Axis, IMRC-EXT 5dBi



Y Axis, IMRC-EXT 5dBi



Z Axis, IMRC-EXT 5dBi



Above 1GHz, IMRC-EXT 5dBi



Configuration 3



Configuration 3



Configuration 4



Configuration 4

103955-29



IMRC-INT for Conducted



IMRC-INT



IMRC-EXT



3dBi Antenna



5dBi Antenna



5VDC Adapter



12VDC Adapter



Power Distribution



Tablet Power Adapter



Tablet #1



Tablet #2





12VDC Power Supply



Inside Temperature Chamber




Outside Temperature Chamber




Configuration 1



Configuration 2



7" Tablet




X Axis, IMRC-INT




X Axis, IMRC-INT



Y Axis, IMRC-INT



Z Axis, IMRC-INT



Above 1GHz, IMRC-INT



X Axis, IMRC-EXT



X Axis, IMRC-EXT



Y Axis, IMRC-EXT




Z Axis, IMRC-EXT



Above 1GHz, IMRC-EXT



Above 1GHz, IMRC-EXT



Configuration 1



Configuration 2