

Go to www.vtechphones.com to register your product for enhanced warranty support and the latest VTech product news.

VM320 VM320-2 Video Monitor




vtech

Quick start guide

Document order number:
All rights reserved. 03/19 VM320-2_GSG_V1
Specifications are subject to change without notice.




WHAT'S IN THE BOX




1 CONNECT THE BABY MONITOR

NOTES


- The rechargeable battery is pre-installed in your parent unit.
- Use only the power adapters supplied with this product.
- Make sure the baby monitor is not connected to an electric outlet that is controlled by a switch.
- Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.
- Make sure the parent unit, the baby unit and the power adapter cords are out of reach of children.




2 POWER ON OR OFF THE BABY MONITOR



3 POSITIONING THE BABY MONITOR




4 STATUS CHECK



BASIC OPERATION - PARENT UNIT

Adjust speaker volume

Press **VOL▲ / VOL▼** to adjust your parent unit speaker volume. Even if you have set the parent unit volume to the maximum, you may not hear sound from the baby unit. It depends on the sensitivity setting.



Set screen off timer

1. Press **MENU SELECT** to enter the main menu when the parent unit is idle.
2. Press **◀** or **▶** to choose **[OFF]**, then press **MENU SELECT** or **▲** to open the submenu.
3. Press **▲** or **▼** to choose the desired time period to automatically turn off screen (**OFF** / **5 min** - 5 min. / **30 min** - 30 min. / **60 min** - 60min.), then press **MENU SELECT** to confirm your selection.

NOTE

- Press any keys on the parent unit to turn on the screen again.

Use the menu

Press **MENU SELECT** to enter the menu, choose a menu item, or save a setting. You can use the parent unit for advanced settings or operations, such as to adjust the baby unit sound sensitivity or the temperature range for alerts.

While in the menu:

- Press **◀** or **▶** to scroll among the menu options.
- Press **MENU SELECT** or **▲** to enter the desired submenu.
- Press **▲** or **▼** to select an item.
- Press **MENU SELECT** to confirm your selection.
- Press **↶** to exit the menu or submenu.

Submenu

Main menu

