



Go to www.vtechphones.com to register your product for enhanced warranty support and the latest Vtech product news.

DECT 6.0 Cordless telephone with BLUETOOTH® wireless technology



vtech® Quick start guide



The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Vtech Holdings Limited is under license. Vtech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners.

The ENERGY STAR® program (www.energystar.gov) recognizes and encourages the use of products that save energy and help protect our environment. We are proud to mark this product with the ENERGY STAR label indicating it meets the latest energy efficiency guidelines.

Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliance Logo is a trademark of the Telecommunications Industry Association. Used under license.

Channels	5
Transmit frequency	Handset: 1921.536MHz - 1928.448MHz Telephone base: 1921.536MHz - 1928.448MHz
Normal range	Maximum power allowed by FCC and IC.
Effective range	Actual operating range may vary according to environmental conditions at the time of use.
Power requirement	Handset: 2.4 VDC, AAAx2, NI-MH battery pack Telephone base: 6V DC @ 600mA
Memory	Phonebook: 200 memory locations; up to 30 digits and 15 characters; Call log: 50 memory locations; up to 24 digits and 15 characters
Call block	1000 entries

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this product near water such as near a bath tub, wash bowl, kitchen sink, laundry tub or a swimming pool, nor in a wet basement or shower.
5. Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
6. Avoid placing the telephone system in places with extreme temperature, direct sunlight, or other electrical devices. Protect your phone from moisture, dust, corrosive liquids and fumes. Slots and openings in the back or bottom of the telephone base and handset are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register. This product should not be placed in any area where proper ventilation is not provided.
7. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home or office, consult your dealer or local power company.
8. Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on.
9. Never push objects of any kind into this product through the slots in the telephone base or handset because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
10. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the telephone base or handset other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the product is subsequently used.
11. Do not overload wall outlets and extension cords.
12. Unplug this product from the wall outlet and refer servicing to an authorized service facility under the following conditions:
 - When the power supply cord or plug is damaged or frayed.
 - If liquid has been spilled onto the product.
 - If the product has been exposed to rain or water.
 - If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operation instructions. Improper adjustment of other controls may result in damage and often requires extensive work by an authorized technician to restore the product to normal operation.
 - If the product has been dropped and the telephone base and/or handset has been damaged.
 - If the product exhibits a distinct change in performance.
13. Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric shock from lightning.
14. Do not use the telephone to report a gas leak in the vicinity of the leak. Under certain circumstances, a spark may be created when the adapter is plugged into the power outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. The user should not plug the phone into a power outlet, and should not plug a charged handset into the cradle, if the phone is located in an environment containing concentrations of flammable or flame-supporting gases, unless there is adequate ventilation. A spark in such an environment could create a fire or explosion. Such environments might include medical use of oxygen without adequate ventilation, industrial gases, cleaning solvents, gasoline vapors, etc.; a leak of natural gas, etc.
15. Only put the handset of your telephone next to your ear when it is in normal talk mode.
16. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

Battery

- CAUTION: Use Only Supplied Battery.
- Do not dispose of the battery in a fire. Check with local waste management codes for special disposal instructions.
- Do not open or mutilate the battery. Released electrolyte is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.
- Exercise care in handling batteries in order not to create a short circuit with conductive materials.
- Charge the battery provided with this product only in accordance with the instructions and limitations specified in this manual.

Precautions for users of implanted cardiac pacemakers

Cardiac pacemakers (applies only to digital cordless telephones):

Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless telephones and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians that:

Pacemaker patients


- Should keep wireless telephones at least six inches from the pacemaker.
- Should NOT place wireless telephones directly over the pacemaker, such as in a breast pocket, when it is turned ON.
- Should use the wireless telephone at the ear opposite the pacemaker.

WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless telephones.

ABOUT CORDLESS TELEPHONES

- **Privacy:** The same features that make a cordless telephone convenient create some limitations. Telephone calls are transmitted between the telephone base and the cordless handset by radio waves, so there is a possibility that the cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. For this reason, you should not think of cordless telephone conversations as being as private as those on corded telephones.
- **Electrical power:** The telephone base of this cordless telephone must be connected to a working electrical outlet. The electrical outlet should not be controlled by a wall switch. Calls cannot be made from the cordless handset if the telephone base is unplugged, switched off or if the electrical power is interrupted.
- **Potential TV interference:** Some cordless telephones operate at frequencies that may cause interference to televisions and VCRs. To minimize or prevent such interference, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR often reduces or eliminates the interference.
- **Rechargeable batteries:** Exercise care in handling batteries in order not to create a short circuit with conducting material such as rings, bracelets and keys. The battery or conductor may overheat and cause harm. Observe proper polarity between the battery and the battery charger.
- **Nickel-metal hydride rechargeable batteries:** Dispose of these batteries in a safe manner. Do not burn or puncture the battery. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury.

WHAT'S IN THE BOX




- 1 set for IS8151
2 sets for IS8151-2
3 sets for IS8151-3
4 sets for IS8151-4
5 sets for IS8151-5/
IS8152-5
- 1 set for IS8151-2
2 sets for IS8151-3
3 sets for IS8151-4
4 sets for IS8151-5/
IS8152-5

CONNECT AND INSTALL


1 Connect the telephone base

If you subscribe to digital subscriber line (DSL) high-speed Internet service through your telephone line, make sure you connect a DSL filter (not included) to the telephone wall jack.


2 Install the battery



3 Connect the charger




4 Charge the battery




Install belt clip


To attach the belt clip
Snap the belt clip into the slots on both sides of the cordless handset.



To remove the belt clip
Lift either of the belt clip tabs outwards from the handset.



Improve the telephone signal strength




Display

Handset:



Telephone base:



Softkeys	Option displayed above a softkey. Press [] or [] to select.
[]	The handset battery low and needs charging.
[]	The handset battery is charging.
[H51]	Handset indicates the handset number.
[]	Handset or telephone base ringer is off.
[]	New voicemail received from your telephone service provider.
[]	The HOME line is in use.
[]	Bluetooth device is active.
[]	Bluetooth device is in use.
[]	Wireless Bluetooth headset is in use.
[]	Answering system is on.
[NEW]	There are new caller ID log entries and/or new messages.

2 SETUP

After you install your telephone or power returns following a power outage and battery depletion, the handset and telephone base will prompt you to set the date and time, and to configure the Smart call blocker® and answering system through voice guide.

Date and time

Follow the steps below to set the date and time. For example, if the date is 25 July, 2019, and the time is 12:05 AM:

- When the handset and telephone base prompt you to set the date and time**
- 1 Enter the date.
- 2 Press **NEXT**.
- 3 Enter the time.
- 4 Press **SAVE**.

Voice guide for Smart call blocker / Answering system

After setting the date and time, the handset and telephone base will prompt if you want to set Smart call blocker and the answering system. For more details, see **Use voice guide to set Smart call blocker** in the **Introducing Smart call blocker** leaflet and **Use voice guide to set Answering system** in the online help topics.

- When the handset and telephone base prompt you to set up the Smart call blocker via voice guide**
- Start voice guide to set up Smart call blocker now? **NO YES**
- Press **YES**
- Setup your Smart call blocker by inputting the designated numbers as instructed in the voice guide.
- When the handset and telephone base prompt you to set up the answering system via voice guide**
- Start voice guide to set up Answering system now? **NO YES**
- Press **YES**
- Setup your answering system by inputting the designated numbers as instructed in the voice guide.

BLUETOOTH

To use a Bluetooth enabled cellular phone with your telephone, you must first pair and connect your Bluetooth cellular phone with the telephone base. Before you begin, make sure that you have cellular coverage and your Bluetooth enabled cell phone is not connected to any other Bluetooth device.

Add a Bluetooth cell phone

- 1 Press **MENU** on the telephone base.
- 2 Press **V/Δ** to scroll to **Bluetooth**, then press **SELECT**.
- 3 Press **SELECT** to select **Add device**.
- 4 Press **SELECT** to select **Add cellular**.
- 5 Press **NEXT**.
- 6 Press **NEXT**.
- 7 Once your cellphone finds your telephone (VTech DECT 6.0), press appropriate key on your cell phone to continue the pairing process.

Add a Bluetooth headset

- 1 Press **MENU** on the telephone base.
- 2 Press **V/Δ** to scroll to **Bluetooth**, then press **SELECT**.
- 3 Press **SELECT** to select **Add device**.
- 4 Press **V/Δ** to scroll to **Add headset**, then press **SELECT**.
- 5 Press **NEXT**.
- 6 Press **NEXT**.
- 7 Place your headset next to the base to continue the pairing process.

Download a cell phone directory using the telephone base

Before downloading a directory, make sure the cell phone is paired, active, and connected to your IS8151.

- 1 Press **MENU** on the telephone base.
- 2 Press **V/Δ** to scroll to **Bluetooth**, then press **SELECT**.
- 3 Press **V/Δ** to scroll to **Download PB**, then press **SELECT**.
- 4 Press **NEXT**.
- 5 Press **NEXT**.
- 6 Press **NEXT**.
- 7 Press **NEXT**.

Activate remote voice control

Make sure your cell phone is paired and connected to your telephone system via Bluetooth.

- Handset:**
- 1 Press **VOICE** on the handset.
- 2 Speak toward the telephone base or handset, and then wait for feedback.
- Telephone base:**
- 1 Press **VOICE** on the telephone base.
- 2 Press **END** to end.

LCD LANGUAGE SETTING

If you accidentally set the LCD language to Spanish or French, press **MENU** and then enter **364#** to change the handset LCD language back to English while the handset is not in use.

*Includes licenced Gattel™ technology. Gattel™ is a trademark of Truecall Group Limited.



PHONEBOOK

Phonebook

The phonebook can store up to 4200 entries, including downloaded cellphone phonebooks, which are shared by all handsets and the telephone base. Each entry may consist of a telephone number up to 30 digits, and a name up to 15 characters.

Add a phonebook entry

1 Enter the phone number.

2 Press **SAVE**.

3 Press **NEXT**.

4 Press **▼/▲** to scroll to the desired label, then press **NEXT**.

5 Enter the name, then press **SAVE**.

Delete a phonebook entry

When your desired phonebook entry displays:

Handset: Press **MUTE DELETE**.

Telephone base: Press **DELETE** to delete.

2 Press **YES**.

ANSWERING SYSTEM

About the built-in answering system and voicemail service

For message recording, your telephone has a built-in answering system, and it also supports voicemail service offered by your telephone service provider (subscription is required, and fee may apply).

Built-in answering system VS Voicemail service

	BUILT-IN ANSWERING SYSTEM	VOICEMAIL SERVICE
SUPPORTED BY	Telephone system	Telephone service provider
SUBSCRIPTION	No	Yes
FEES	No	May apply
ANSWER INCOMING CALLS	- After 3 rings by default. - It can be changed via handset or the telephone base menu.	- Usually after 2 rings. - It can be changed by contacting your telephone service provider.
STORAGE	Telephone base	Server or System
DISPLAY NEW MESSAGES	- Handset - XX new messages - Telephone base - XX new messages	- Handset - ✉ and New voicemail - Telephone base - ✉
RETRIEVE MESSAGES	- Press PLAY / STOP on the telephone base; OR - Press MENU, and then select Play messages on the handset; OR - Access remotely with an access code.	Press ✉ on the dialpad, and enter an access number from your telephone service provider.

Turn the built-in answering system on or off On the telephone base

Press **ANS ON** to turn on; press again to turn off.

Message playback Handset:

Press **MENU**, then press **SELECT** to select **Play messages**.



CALLER ID

Caller ID

If you subscribe to caller ID service, information about each caller appears after the first or second ring.

The caller ID log stores up to 50 entries. Each entry has up to 24 digits for the phone number and 15 characters for the name.

Review caller ID log entries Handset:

1 Press **CID**.

2 Press **▼/▲** to browse the entries.

Telephone base:

1 Press **CID**.

2 Press **▼/▲** to browse the entries.

Delete a caller ID log entry

When your desired caller ID entry displays on the handset or telephone base screen:

Handset: Press **MUTE DELETE**.

Telephone base: Press **DELETE** to delete.

Set number of rings

You can set your answering system to answer calls at least two rings earlier than your voicemail service. For example, if your voicemail service answers after six rings, set your answering system to answer after four rings. Thus, if you are on a call, or if the answering system is busy recording a message and you receive another call, the second caller can leave a voicemail message.

1 Press **MENU**.

2 Press **▼/▲** to scroll to **Answering sys**, then press **SELECT**.

3 Press **▼/▲** to scroll to **Ans sys setup**, then press **SELECT**.

4 Press **▼/▲** to scroll to **# of rings**, then press **SELECT**.

5 Press **▼/▲** to scroll to the desired number of rings, then press **SELECT**.

Skip a message Telephone base:

Press **SKIP** to skip.

Repeat the playing message Telephone base:

Press **REPEAT** to repeat.

Play the previous message Telephone base:

Press **REPEAT** twice.

Save a caller ID log entry to the phonebook

When your desired caller ID entry displays on the handset.

1 Press **SAVE**.

2 Press **▼/▲** to select phonebook.

3 Edit the phone number if needed, then press **NEXT**.

4 Press **▼/▲** to scroll to the desired label, then press **NEXT**.

5 Edit the name if needed, then press **SAVE**.

Dial a caller ID log entry

When your desired caller ID entry displays on the handset or telephone base screen:

Handset: Press **MUTE DELETE**.

Telephone base: Press **DELETE** to delete.

NEED HELP?

For operations and guides to help you using your telephone, and for latest information and supports, go and check the online help topics and online FAQs.

Use your smartphone or mobile device to access our online help.

- Go to <https://help.vtechphones.com/is8151>; OR
- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the notification to trigger the redirection of the online help.
- If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it is clear.

You can also call our Customer Support at 1 (800) 595-9511 (in US) or 1 (800) 267-7377 (in Canada) for help.

FOR C-UL COMPLIANCE ONLY

Mesures de sécurité importantes

Afin de réduire les risques d'incendie, de blessures corporelles ou d'électrocution, suivez toujours ces mesures préventives de base lorsque vous utilisez votre téléphone :

- Lisez et comprenez bien toutes les instructions.
- Observez toutes les instructions et mises en garde inscrites sur l'appareil.
- Débranchez ce téléphone de la prise murale avant de le nettoyer. N'utilisez pas de nettoyeurs liquides ni en aérosol. N'utilisez qu'un chiffon doux et légèrement humecté.
- N'utilisez pas ce produit près de l'eau, tel que près d'un bain, d'un lavabo, d'un évier de cuisine, d'un bac de lavage ou d'une piscine, ou dans un sous-sol humide ou sous la douche.
- Ne déposez pas ce téléphone sur un chariot, support ou table chancelants. L'appareil pourrait tomber et être sérieusement endommagé.
- Évitez d'installer le système téléphonique dans les endroits soumis à une température extrême, à la lumière directe du soleil ou à proximité d'autres appareils électriques ou électroniques. Protégez votre téléphone contre les sources d'humidité, la poussière, les vapeurs et les liquides corrosifs.
- Le boîtier de l'appareil est doté de fentes et d'ouvertures d'aération situées à l'arrière ou en dessous. Afin d'empêcher la surchauffe, ces ouvertures ne doivent pas être obstruées en plaçant l'appareil sur un lit, divan, tapis ou autre surface similaires. Ne placez pas cet appareil à proximité d'un élément de chauffage ni d'une plinthe électrique. De plus, ne l'installez pas dans une unité murale ou un cabinet fermé qui ne possède pas d'aération adéquate.
- Ne faites fonctionner cet appareil qu'avec le type d'alimentation indiqué sur les étiquettes de l'appareil. Si vous ne connaissez pas le voltage de votre maison, consultez votre marchand ou votre fournisseur d'électricité.
- Ne déposez rien sur le cordon d'alimentation. Installez cet appareil dans un endroit sécurisé, où la personne ne pourra trébucher sur la ligne d'alimentation ni le cordon téléphonique modulaire.
- N'insérez jamais d'objets à travers les fentes et ouvertures de cet appareil, car ils pourraient toucher à des points de tension dangereux ou court-circuiter des pièces, ce qui constituerait un risque d'incendie ou d'électrocution. N'échappez pas de liquides dans l'appareil.
- Afin de réduire les risques d'électrocution, ne démontez pas l'appareil, mais apportez-le plutôt à un centre de service qualifié s'il doit être réparé. En enlevant le couvercle, vous vous exposez à des tensions dangereuses ou autres dangers similaires. Un remontage inadéquat peut être à l'origine d'une électrocution lors d'une utilisation ultérieure de l'appareil. Débranchez l'appareil avant de procéder au nettoyage. Utilisez un chiffon humide et doux.
- Ne surchargez pas les prises de courant et les rallonges.
- Débranchez cet appareil de la prise de courant et communiquez avec le département de service à la clientèle de Vtech dans les cas suivants :

- Lorsque le cordon d'alimentation est endommagé ou écorché.
- Si du liquide a été échappé dans l'appareil.
- Si l'appareil a été exposé à une source d'humidité telle que la pluie ou l'eau.
- Si le produit ne fonctionne pas normalement en respectant les instructions de fonctionnement. Réglez uniquement les commandes indiquées dans les instructions de fonctionnement. Les réglages incorrects des autres commandes pourraient provoquer un dommage qui pourrait exiger un travail exhaustif de la part d'un technicien autorisé afin de rétablir le fonctionnement normal de l'appareil.
- Si le produit a été échappé et que le socle et/ou le combiné a été endommagé.
- Si le produit affiche une nette diminution de sa performance.

Évitez d'utiliser un téléphone (autre qu'un sans fil) pendant un orage. Les éclairs peuvent être à l'origine d'une électrocution.

N'utilisez pas le téléphone pour rapporter une fuite de gaz à proximité de la fuite. En certaines circonstances, une flamme pourrait être provoquée lorsque l'adaptateur est branché à une prise de courant, ou lorsque le combiné est déposé sur le socle. Ceci est un événement commun associé à la fermeture d'un circuit électrique. L'utilisateur devrait pas brancher le téléphone à une prise de courant, et ne devrait pas déposer le combiné sur le socle. Si le téléphone se trouve à proximité d'un endroit comportant des concentrations de gaz inflammables, à moins que la ventilation soit adéquate. Une flamme dans un tel endroit pourrait provoquer un incendie ou une explosion. De tels environnements peuvent compromettre le processus de ventilation et l'oxygène nécessaire à la ventilation adéquate; des gaz industriels (dissolvants de nettoyage, des vapeurs d'essence, etc.); une fuite de gaz naturel, etc.

Ne placez que le combiné de votre téléphone près de votre oreille lorsqu'en mode de conversation.

Ces adaptateurs ont été conçus pour être orientés en position verticale ou montés au sol. Les broches ne sont pas conçues pour maintenir l'adaptateur en place si celui-ci est bouché dans une prise au plafond ou sous une table/ armoire.

Pour le MATERIEL RACCORDE PAR PRISE DE COURANT, le socle de prise de courant doit être installé à proximité du matériel et doit être aisément accessible.

⚠ **MISE EN GARDE:** Il peut y avoir un risque d'explosion si vous utilisez le mauvais type de piles pour le téléphone. N'utilisez que les piles rechargeables incluses ou les piles de rechange (BT183342/BT283342). N'incinerez pas les piles. Celles-ci requièrent d'être recyclées.

N'utilisez que les adaptateurs inclus avec ce produit. L'utilisation d'un adaptateur dont la polarité ou la tension serait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril.

Conservation des piles: Les piles doivent être conservées dans un endroit sec, à l'abri de la chaleur, de l'humidité et de la lumière directe du soleil. Ne les exposez pas à des températures supérieures à 120°F (50°C) ou inférieures à 32°F (0°C). Ne les exposez pas à des températures supérieures à 120°F (50°C) ou inférieures à 32°F (0°C). Ne les exposez pas à des températures supérieures à 120°F (50°C) ou inférieures à 32°F (0°C).

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil. Ne placez pas le produit sur une surface qui pourrait être endommagée par la chaleur, l'humidité ou la lumière directe du soleil.

SEDC RF exposure guidelines when used with the accessories supplied or designated for this product. Use of other accessories may not ensure compliance with FCC/ISED RF exposure guidelines. The telephone base shall be installed and used such that parts of the user's body other than the hands are maintained at a distance of approximately 20 cm (8 inches) or more.

This Class B digital apparatus complies with Canadian requirement: CAN ICES-3 (B)/NMB-3(B).

FCC Part 68 and ACTA

This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, among other things, a product identifier in the format U.S.A.A.E5#FTXXXX. This identifier must be provided to your telephone service provider upon request.

The plug and jack used to connect this equipment to premises wiring and the telephone network must comply with applicable Part 68 rules and technical requirements adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. An RJ11 jack should normally be used for connecting to a single line. See the installation instructions in the user's manual.

The Ringing Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. The REN for this product is encoded as the 6th and 7th characters following the U.S. product identifier (e.g., if #6 is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0) or less. For more information, please contact your telephone service provider.

This equipment must not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone service provider or a qualified installer.

If this equipment is malfunctioning, it must be unplugged from the modular jack until the problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents. For repair procedures, follow the instructions outlined under the **Limited warranty**.

If this equipment is causing harm to the telephone network, the telephone service provider may temporarily discontinue your telephone service. The telephone service provider is required to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible. You will be given the opportunity to correct the problem and the telephone service provider is required to inform you of your right to file a complaint with the FCC. Your telephone service provider may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. The telephone service provider is required to notify you if such changes are planned.

If this product is equipped with a corded or cordless handset, it is hearing aid compatible.

If this product has memory dialing locations, you may choose to store emergency telephone numbers (e.g., police, fire, medical) in these locations. If you do store or test emergency numbers, please:

Remain on the line and briefly explain the reason for the call before hanging up. Perform such activities in off-peak hours, such as early morning or late evening.

Industry Canada

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Privacy of communications may not be ensured when using this telephone.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

The Ringing Equivalence Number (REN) for this terminal equipment is 0.1. The REN indicates the maximum number of devices allowed to be connected to a telephone line. The termination of an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices not exceed five.

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

CALIFORNIA ENERGY COMMISSION BATTERY

CHARGING TESTING INSTRUCTIONS

This telephone is set up to comply with the energy-conserving standards right out of the box. These instructions are intended for California Energy Commission (CEC) compliance testing only. When the CEC battery charging testing mode is activated, all telephone functions except battery charging, will be disabled.

To activate the CEC battery charging testing mode:

1. Unplug the telephone base power adapter from the power outlet. Make sure all handsets are plugged with charged batteries before proceeding.

2. While you **press and hold FIND HS**, plug the telephone base power adapter back to the power outlet.

3. After about 20 seconds, when the **HOME** light starts flashing, release **FIND HS** and then press it again within two seconds. You hear a confirmation tone. The **HOME** light turns off and all handsets display **To register HS... see manual...** alternately. Allow up to one minute for the process to complete.

If the phone fails to enter this mode, repeat all the steps mentioned above. The telephone base will be powered up as normal if you fail to press **FIND HS** within two seconds in Step 3.

To deactivate the CEC battery charging testing mode:

1. Unplug the telephone base power adapter from the power outlet, and then plug it back in. Then the telephone base is powered up as normal.

2. Put the handsets on the telephone base cradle to begin registration.

3. The telephone base shows **Registering...** Please wait, and the handset then shows **Registering...** If the registration is successful, the handset screen displays **Registered** and beeps. The handset is registered with the telephone base.

DISCLAIMER AND LIMITATION OF LIABILITY

Vtech Communications, Inc. and its suppliers assume no responsibility for any damage or loss resulting from the use of this user's manual. Vtech Communications, Inc. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this product.

Company: Vtech Communications, Inc.
Address: 9020 SW Washington Square Road - Ste 555 Tigard, OR 97223, United States
Phone: 1 (800) 595-9511 in the U.S. or 1 (800) 267-7377 in Canada