

 Attribution-NonCommercial-ShareAlike 4.0 International
This work is licensed under a Creative Commons Attribution-NonCommercial-ShareAlike 4.0 International License.

Pan and Tilt Video Baby Monitor

For more support information,

[illegible]

NOTES

- The rechargeable battery in the parent unit is built-in.
- Use only the power adapters supplied with this product.
- Make sure the baby monitor is not connected to a switch-controlled electric outlet.
- Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.
- Make sure the parent unit, the baby units and the power adapter cords are out of reach of children.

Charge the parent unit battery

When you have connected and turned on the parent unit, the battery will be charged automatically.

Notes

- Before using the baby monitor for the first time, charge the parent unit battery for 12 hours. When the parent unit battery is fully charged, the battery icon becomes solid .
- It takes longer to charge the battery when the parent unit is turned on. To shorten the charging time, turn the parent unit off while charging.
- The standby time varies depending on the sensitivity level you set, your actual use and the age of the battery.

The battery icon indicates the battery status (see the following table).

BATTERY INDICATORS	BATTERY STATUS	ACTION
The screen displays  The  light flashes.	The battery has very little power and can only be used for a short time.	Charge without interruption (about 30 minutes).
The battery icon becomes solid  .	The battery is fully charged.	To keep the battery charged, connect the unit to AC power when not in use.

CAUTION

- Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the baby's crib or playpen.

-
-
-
-

CAUTION

- The default volume of your parent unit is level 3 and the maximum volume is level 5. If you experience high-pitched screaming noise from your baby monitor while positioning:
 - Make sure your baby unit and parent unit are more than 3 feet (1 meter) apart.
 - Turn down the volume of your parent unit.

NOTE

- To avoid interference from other electronic devices, place your baby monitor at least 3 feet (1 meter) away from devices such as wireless routers, microwaves, cell phones and computers.

Once you power on both your baby unit and parent unit, your parent unit displays image from the baby unit, and the **LINK** LED light turns on.


The baby unit's **POWER** LED light turns on.

Use the menu

Press **MENU** to enter the menu, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby unit's lullaby, or to adjust the baby unit's sound sensitivity.

While in the menu:

- Press **◀** or **▶** to scroll among the menu options.
- Press **A** or **▼** to select an item.
- Press **SELECT** to confirm your selection.
- Press **TALK/EXIT** to exit the menu and return to live view.



The diagram shows the parent unit's control panel. The screen displays a menu with 'SUBMENU' and 'MAIN MENU' options. A hand is shown pressing the 'SELECT' button. A circular inset shows a close-up of the 'SELECT' button.

1. Press **MENU** when in idle mode.
2. Press **◀** or **▶** to choose **1**.
3. Press **▲** or **▼** to select desired volume level, then press **SELECT** to confirm your selection.

1. Press **MENU** when in idle mode.
2. Press **◀** or **▶** to choose **1**.
3. Press **▲** or **▼** to choose **1**, press **SELECT**.
4. Press **▲** or **▼** to choose **1** (Zoom in) or **1/2** (Zoom out), then press **SELECT** to confirm your selection.

1. Press **MENU** when in idle mode.
2. Press **←** or **→** to choose .
3. Press **▲** or **▼** to choose , press **SELECT**.
4. Press **▲** or **▼** to choose (Zoom in) or (Zoom out), then press **SELECT** to confirm your selection.

Diagram of the baby unit with numbered callouts:

- 1. Battery LED light
- 2. 3-level sound indicator
- 3. Arrow keys
- 4. MENU/SELECT
- 5. LINK LED light
- 6. TALK/EXIT
- 7. POWER/LCD OFF
- 8. Microphone
- 9. Power Jack
- 10. Antenna
- 11. RESET
- 12. Speaker

Diagram showing the front and back views of the baby unit with numbered callouts 1 through 11.

1	Light sensor	7	Speaker
2	Camera	8	Antenna
3	Infrared LEDs	9	Power jack
4	Microphone	10	Slots for wall mounting
5	POWER LED light	11	PAIR/RESET key The parent unit and baby unit(s) provided are already paired.
6	ON/OFF switch		

Status icons

Connection status

- or displays when strong signal strength is detected between the baby unit and the parent unit.
- or displays when moderate or low signal strength is detected between the baby unit and the parent unit.

Patrol mode

- Displays when the parent unit is in **PATROL** mode (For VM923-2 only).

Current view status

- Displays the baby unit number of the baby unit that is being viewed.

Zoom

- Displays when the current image on the parent unit has zoomed in.

Night vision

- Displays when the baby unit being viewed has activated the night vision feature.

Talkback

- Displays when talking back to the baby units from parent unit.

Lullaby

- Displays when a lullaby is playing.

Mute alert

- Displays when the parent unit speaker volume is set to zero.
- Displays when the parent unit is talking to the baby unit.

Real-time temperature

- Displays the real-time temperature detected by the baby unit in Fahrenheit (°F) or Celsius (°C) (e.g. 57°F or 14°C).

Battery status

- animates when the battery is charging.
- displays solid when the battery is fully charged.
- displays when the battery is low and needs charging.

Main menu	Sub-menu	Main menu	Sub-menu
Volume	- Parent unit speaker volume - Adjust the parent unit's speaker volume.	Sound Detection	Vox (Voice Activated) Detection Sensitivity - You can choose to hear sounds from the baby unit all the time, or to only hear sounds that exceed a certain level. Adjust the microphone sensitivity of your baby unit; the higher the sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting to the parent unit. See Sound sensitivity and sound activation section.
Settings	Zoom - Zoom in and out of the video displayed from the baby unit. Screen off timer - The parent unit display will dim to conserve energy after your chosen amount of time of inactivity. Brightness - Adjust the parent unit's LCD screen brightness level.		
Temperature	Turn on/off temperature alert tone. Set the parent unit to beep whenever the room temperature detected by the baby unit falls outside of the set temperature range. Set the minimum/maximum temperature. Set temperature display in Fahrenheit (°F) or Celsius (°C).		
			Sound-activated screen - When it is on, and the baby unit detects no sound, the parent unit screen stays off to save power. Once a sound is detected, the parent unit screen and speaker turns on automatically, and you can see and hear your baby. The parent unit will then turn off again after 50 seconds of no sound detection. NOTE - When the parent unit screen is off and it receives alerts for example, link lost between parent unit and baby unit, or battery is low, the parent unit screen and speaker will turn on for 10 seconds.

For operations and guides to help you use your video monitor, and for the latest information and support, check out our online help topics and online FAQ:

- Use your smartphone or mobile device to access our online help.
 - Go to <https://help.vtechphones.com/vm923-2>.
 - https://help.vtechphones.com/vm923-2_QR
- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the notification to be redirected to the online help page.
- If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it is clear.

You can also call our Customer Support at 1 (800) 955-9511 (in US) or 1 (800) 282-7377 (in Canada) for help.

VM923-2

