

Go to **www.vtechphones.com** to register your product for enhanced warranty support and the latest VTech product news.



vttech®

User's manual

For more support information



DM1411

Digital Audio Monitor


CONGRATULATIONS

on purchasing your new VTech product.
Before using this product, please read **Important safety instructions**.

This manual has all the feature operations and troubleshooting necessary to install and operate your new VTech product. Please review this manual thoroughly to ensure proper installation and operation of this innovative and feature-rich VTech product.

For support, shopping, and everything new at VTech, visit our website at **www.vtechphones.com**.

WHAT'S IN THE BOX



IMPORTANT SAFETY INSTRUCTIONS

- The applied nameplate is located in the battery compartment of the baby and parent units.
When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:
1. Follow all warnings and instructions marked on the product.
 2. Adult setup is required.
 3. **CAUTION:** Do not install the soother at a height above 2 meters.
 4. This product is not a substitute for adult supervision of the infant. Supervising the infant is the parent's or caregiver's responsibility. This product could cease operating, and therefore you should not assume it will continue working properly for any given period of time. Further, this is not a medical device and should not be used as such. This product is intended to assist you in supervising your baby.
 5. Do not use this product near water. For example, do not use it next to a bath tub, wash bowl, kitchen sink, laundry tub or swimming pool, or in a wet basement or shower.
 6. **CAUTION:** Use only the batteries provided. There may be a risk of explosion if a wrong type of battery is used for the parent unit. The batteries cannot be subjected to high or low extreme temperature and low air pressure at high altitude during use, storage or transportation. Disposal of batteries into fire or a hot oven, or mechanically crushing or cutting or the batteries can result in an explosion. Leaving the batteries in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of gas. Batteries subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. Dispose of used battery according to the information in The RBRC seal.
 6. Use only the adapters included with this product. Incorrect adapter polarity or voltage can seriously damage the product.
 7. Use only adapters and batteries listed below.
- Power adapter information:**
Output: 6V DC 400mA / 5V DC 600mA
VTECH TELECOMMUNICATIONS LTD.
Model: VT05UUS06040 / VT05EUUS05060
- Rechargeable battery information:**
2.4V NiMH battery
YIYANG CORUN BATTERY CO LTD.
Model: NI-MHAAA400×2-FF / NI-MHAAA750×2-FF
8. The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.
 9. For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.
 10. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
 11. Unplug the power cords before replacing batteries.
 12. Do not cut off the power adapters to replace them with other plugs, as this causes a hazardous situation.
 13. Do not allow anything to rest on the power cords. Do not install this product where the cords may be walked on or crimped.
 14. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home, consult your dealer or local power company.
 15. Do not overload wall outlets or use an extension cord.
 16. Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
 17. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation.

- SAVE THESE INSTRUCTIONS**
- Cautions**
1. Use and store the product at a temperature between 32°F and 104°F.
 2. Do not expose the product to extreme cold, heat or direct sunlight. Do not put the product close to a heating source.
 3. Batteries should not be exposed to excessive heat such as bright sunshine or fire.

- Warning**—Strangulation Hazard—Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9 m) away). Do not remove this tag.
5. Never place the soother inside the baby's crib or p. laypen. Never cover the soother or parent unit with anything such as a towel or a blanket.
 6. Other electronic products may cause interference with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible: wireless routers, radios, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and cordless telephones.

Precautions for users of implanted cardiac pacemakers
Cardiac pacemakers (applies only to digital cordless devices): Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless devices and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians that:

- Pacemaker patients**
- Should keep wireless devices at least six inches from the pacemaker.
 - Should NOT place wireless devices directly over the pacemaker, such as in a breast pocket, when it is turned ON. WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless devices.

Electromagnetic fields (EMF)
This VTech product complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user's manual, the product is safe to be used based on scientific evidence available today.


1 CONNECT THE BABY MONITOR

Install the parent unit battery

The parent unit runs on rechargeable battery or AC power. To continuously monitor your baby, make sure you use both battery and AC power at the same time. With the battery alone, the parent unit can cordlessly run for a short time only.

NOTES

- Use only the battery supplied with this product.
- If the parent unit will not be used for a long time, disconnect and remove the battery to prevent possible leakage.




Replace the battery

To replace the battery, press down on the battery compartment cover and pull it out, then follow the steps above to install the battery.

Connect the baby monitor

NOTES

- Use only the power adapters supplied with this product.
- Make sure the baby monitor is not connected to a switch controlled electric outlet.
- Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.
- Make sure the parent unit, the soother and the power adapter cords are out of reach of children.





Charge the battery

This portable soother has a built-in rechargeable battery for cordless usage.

To charge the battery, connect the soother with the adaptor provided to a power source.

NOTES

SOOTHER OVERVIEW



1

Lullaby

- Press to play or stop the lullaby.

2

vol-

- Press to decrease the speaker volume.

3

Auto-off timer

- Press to turn on a 60-minute timer while playing lullaby or soothing sound. It will automatically stop the lullaby or soothing sound after playing for 60 minutes.

4

Skip

- Press to skip to the next lullaby or soothing sound.

5

Tail

- Hook the soother on an object.

6

Dimmable soft-glow night light

7

Soothing sound

- Press to play or stop the soothing sound.

8

vol +

- Press to increase the speaker volume.

9

Dimmable soft-glow night light

- Press to turn on the night light in dim light or bright light mode.

10

ON/ OFF/ ONLY power switch

- Slide to power on or off the soother, or use the soothing functions on the soother only.

11

DC jack for battery charging only

12

Slot for the additional strap

13

Speaker

14

Auto-off timer light indicator

- On when the auto-off timer feature is turned on.
- Off when the auto-off timer feature is turned off.

15

Battery status light indicator

- On when the battery is being charged.
- Flashes when the battery is low and needs charging.
- Off when the battery is not being charged; or the battery is fully charged.

Use the soother

Power on or off the soother

- Slide the power switch on the right-hand side of the soother to **on** or **off**.

NOTE

- Make sure the soother is on before using other features.

Play the lullaby

The soother has five lullabies for you to comfort your baby.

- Brahms' Lullaby*
- Rock a Bye Baby*
- Hush Little Baby*
- Minuet in G, Bach*
- Twinkle Twinkle Little Star*

- Press to start playing lullabies.
- Press to skip to the next lullaby.
- While a lullaby is playing, press again to stop the lullaby.

NOTES

- The soother will play the lullabies continuously unless you manually stop the lullabies or turn on the auto-off timer feature.
- When a lullaby ends, the soother automatically skips to the next lullaby. After the soother plays the fifth lullaby, it restarts playing from the first lullaby again.

Play the soothing sound

The soother has five soothing sounds for you to comfort your baby.

- White noise*
- Stream*
- Crickets*
- Birds*
- Heartbeat*

- Press to start playing soothing sounds.
- Press to skip to the next soothing sound.
- While a soothing sound is playing, press again to stop the soothing sound.

NOTE

- The soother will play the soothing sounds continuously unless you manually stop the soothing sounds or turn on the auto-off timer feature.
- The soother will repeat the same soothing sound again and again unless you skip to the other soothing sounds.

Adjust the speaker volume

- Press vol- or vol+ at any time.

NOTE

- The soother beeps to notify you when the speaker volume is already at the highest or lowest setting while adjusting.

Turn on or off the auto-off timer

While the soother is playing a lullaby or soothing sound, the auto-off timer feature helps you automatically stop the lullaby or soothing sound after playing for 60 minutes.

- While a lullaby or soothing sound is playing, press to turn on the auto-off timer feature.
 - The soother starts counting down 60 minutes. The auto-off timer light indicator on the left-hand side of the soother turns on.
- After 60 minutes, the soother will automatically stop any lullaby or soothing sound. The auto-off timer feature and the corresponding light indicator will turn off.

NOTES

- You can only turn on the auto-off timer feature when the soother is playing a lullaby or soothing sound.
- The auto-off timer feature will not power off the soother after the 60-minute countdown.
- You can press again to turn off the auto-off timer feature during the 60-minute countdown.
- If you manually stop the lullaby or soothing sound while the auto-off timer is counting down, the auto-off timer will turn off.

NOTES

- The soother will play the lullabies continuously unless you manually stop the lullabies or turn on the auto-off timer feature.
- When a lullaby ends, the soother automatically skips to the next lullaby. After the soother plays the fifth lullaby, it restarts playing from the first lullaby again.

Turn on or off the dimmable soft-glow night light


When the soother is on, press repeatedly to choose from below night light options:

- Turn on the night light in dim light mode, or
- Turn on the night light in bright light mode, or
- Turn off the night light.

NOTE

- The night light will be automatically off after 15 minutes.

PARENT UNIT OVERVIEW



1

Visual sound indicators

The visual sound indicators can show the sound level detected by the soother or the volume level during speaker volume setting.

Sound level detected by the soother

- One to three green lights indicate a moderate sound level detected by the soother.
- Additional red lights indicate a higher sound level detected by the soother (e.g. baby crying loudly).

Speaker volume level

- One to three green lights indicate **Level 1 to Level 3** of the speaker volume setting.
- Additional red lights indicate **Level 4 to Level 5** of the speaker volume setting.

2