

INTERTEK TESTING SERVICE

Configuration Photographs

Radiated Emissions (30MHz - 1GHz) (Adaptor: VT07EUS05150)

(Front View)



INTERTEK TESTING SERVICE

Configuration Photographs

Radiated Emissions (30MHz - 1GHz) (Adaptor: VT07EUS05150)

(Back View)




INTERTEK TESTING SERVICE

Configuration Photographs

Radiated Emissions (30MHz - 1GHz) (Adaptor: A938-050150W-US1)

(Front View)



INTERTEK TESTING SERVICE

Configuration Photographs

Radiated Emissions (30MHz - 1GHz) (Adaptor: A938-050150W-US1)

(Back View)




INTERTEK TESTING SERVICE

Configuration Photographs

Radiated Emissions (Above 1GHz) (Adaptor: VT07EUS05150)

(Front View)




INTERTEK TESTING SERVICE

Configuration Photographs

Radiated Emissions (Above 1GHz) (Adaptor: VT07EUS05150)

(Back View)




INTERTEK TESTING SERVICE

Configuration Photographs

Radiated Emissions (Above 1GHz) (Adaptor: A938-050150W-US1)

(Front View)




INTERTEK TESTING SERVICE

Configuration Photographs

Radiated Emissions (Above 1GHz) (Adaptor: A938-050150W-US1)

(Back View)




INTERTEK TESTING SERVICE

Configuration Photographs

Worst-Case Conducted Emissions (Adaptor: VT07EUS05150)

(Front View)



INTERTEK TESTING SERVICE

Configuration Photographs

Worst-Case Conducted Emissions (Adaptor: VT07EUS05150)

(Left View)



INTERTEK TESTING SERVICE

Configuration Photographs

Worst-Case Conducted Emissions (Adaptor: VT07EUS05150)

(Right View)




INTERTEK TESTING SERVICE

Configuration Photographs

Worst-Case Conducted Emissions (Adaptor: A938-050150W-US1)

(Front View)



INTERTEK TESTING SERVICE

Configuration Photographs

Worst-Case Conducted Emissions (Adaptor: A938-050150W-US1)

(Left View)



INTERTEK TESTING SERVICE

Configuration Photographs

Worst-Case Conducted Emissions (Adaptor: A938-050150W-US1)

(Right View)

