


INTERTEK TESTING SERVICES

Configuration Photographs

Radiated Emissions (30MHz - 1GHz)

(Front View)

(Adaptor: A318-050100W-US2)




INTERTEK TESTING SERVICES

Configuration Photographs

Radiated Emissions (30MHz - 1GHz)

(Back View)

(Adaptor: A318-050100W-US2)




INTERTEK TESTING SERVICES

Configuration Photographs

Radiated Emissions (Above 1GHz)

(Front View)
(Adaptor: A318-050100W-US2)



INTERTEK TESTING SERVICES

Configuration Photographs

Radiated Emissions (Above 1GHz)

(Back View)

(Adaptor: A318-050100W-US2)




INTERTEK TESTING SERVICES

Configuration Photographs

Radiated Emissions (30MHz - 1GHz)

(Front View)
(Adaptor: VT05EUS05100)



INTERTEK TESTING SERVICES

Configuration Photographs

Radiated Emissions (30MHz - 1GHz)

(Back View)
(Adaptor: VT05EUS05100)




INTERTEK TESTING SERVICES

Configuration Photographs

Radiated Emissions (Above 1GHz)

(Front View)
(Adaptor: VT05EUS05100)



INTERTEK TESTING SERVICES

Configuration Photographs

Radiated Emissions (Above 1GHz)

(Back View)

(Adaptor: VT05EUS05100)



INTERTEK TESTING SERVICES

Configuration Photographs

Conducted Emissions

(Front View)
(Adaptor: VT05EUS05100)



INTERTEK TESTING SERVICES

Configuration Photographs

Conducted Emissions

(Left View)
(Adaptor: VT05EUS05100)



(Adaptor: VT05EUS05100)



INTERTEK TESTING SERVICES

Configuration Photographs

Conducted Emissions

(Front View)
(Adaptor: A318-050100W-US2)



INTERTEK TESTING SERVICES

Configuration Photographs

Conducted Emissions

(Left View)
(Adaptor: A318-050100W-US2)



INTERTEK TESTING SERVICES

Configuration Photographs

Conducted Emissions

(Right View)
(Adaptor: A318-050100W-US2)

