











EUT – (WF6972) Base-set: Chassis View, bottom Cover Removed**EUT – (WF6972) Base-set Main Boards with antenna Component View -1**

EUT – (WF6972) Base-set Main Boards with antenna Component View -2**EUT – (WF6972) Base-set RF Board Detail View (RF Shielding Removed)**

EUT –(WF6972) Base-set Antenna View**EUT – (WF6972) Base-set power supply**

EUT – (WF6972 & WF6909) Hand-set: (Back View 2 with battery compartment cover removed)**EUT – (WF6972 & WF6909) Hand-set: Back (Cover Removed View)**

EUT – (WF6972 & WF6909) Hand-set Main Board Component View**EUT – (WF6972 & WF6909) Hand-set RF Board Component Detail View (RF Shielding removed)**

EUT – (WF6972 & WF6909) Hand-set Antenna Detail View**EUT – (WF6972 & WF6909) Hand-set: Battery View**

EUT – (WF6909) Handset charger power supply



END OF REPORT