


AirStation Quick Setup Guide


2015-01

Setup






Default Values

WXR-1900DHPD



The setup card for the WSR-1166DD/WSR-600DD is included in the package.


Opening Settings

-  192.168.11.1
-  password
- 


Note: After logging in to Settings, we recommend that you change the default administrator password.

LEDs

WXR-1900DHPD



WSR-1166DD



Technical Support

Buffalo Americas

www.buffaloamericas.com

DD-WRT

www.dd-wrt.com

DD-WRT Forum

www.dd-wrt.com/phpBB2

WSR-600DD

