


AirStation Quick Setup Guide


2015-01

Setup



Default Values


WXR-1900DHPD



The setup card for the WSR-1166DD/WSR-600DD is included in the package.

Opening Settings


1



192.168.11.1


192.168.11.1

2



password

3



Router Info	
Release	DD-WRT NG beta r0 8.1
Hardware	Buffalo WXR-1900DHP
Kernel version	3.10.49
Uptime	01:24:17
Current time	12/01/2015 04:31:05
Current load	0.90/0.115/0.104
Memory usage	43/503 MB


Internet Connection	
Wan Port	Connecting

Wireless Network	
SSID (2.4 GHz)	Buffalo-G-4E1E
SSID (5 GHz)	Buffalo-A-4E1E


Note: After logging in to Settings, we recommend that you change the default administrator password.

LEDs

WXR-1900DHPD



WSR-1166DD



Technical Support

Buffalo Americas
www.buffaloamericas.com

DD-WRT
www.dd-wrt.com

DD-WRT Forum
www.dd-wrt.com/phpBB2

WSR-600DD

