



IKEA of Sweden

Doc ID

Created by:
Approved by:

Replaced doc

Manual ICPSW24-40-1

1. The AC adaptor is used for LED lighting.
2. Please use the unit according to the rated voltage, current and information of the label.
3. Do not use other means than rated input to power the unit.
4. For Singapore only: To use only the 3-Pin Plug complying to BS 1363-3 that is provided to power the adapter.
5. For indoor use only.
6. Short circuit Protection: Unit will resume function, when short circuit is removed.
7. Do not open the cover of the unit.
8. Do not use the unit if surface is cracked or damaged.
9. For Australia only: The Power supply shall not be covered with thermal insulating material. When recessed in ceiling or walls, there should be at least 200mm clearance in any direction to flammable building materials.



ICPSW24-40-1 사용설명서

1. 정격 전압, 전류 및 라벨의 정보에 따라 제품을 사용하십시오.
2. 정격 입력 이외의 수단을 사용하여 제품에 전원을 공급하지 마십시오.
3. 실내에서만 사용하십시오.
4. 단락 보호 : 단락이 제거되면 제품이 재 작동합니다.
5. 제품의 덮개를 열지 마십시오.
6. 표면에 금이 가거나 손상된 경우 제품을 사용하지 마십시오.
7. 플러그(ICPP-KR-1)를 다른 전기 제품에 사용하지 마십시오.

マニュアル ICPSW24-40-1

1. AC アダプターは、LED 照明
 2. 定格電圧、電流、ラベルの情報に合わせてご使用ください。
 3. ユニットの電力を供給するために定格入力以外の手段を使用しないでください。
 4. 屋内での使用のみ。
 5. 短絡保護：短絡が解除されると、ユニットは機能を再開します。
 6. ユニットのカバーを開けないでください。
 7. 表面にひびが入ったり損傷したりしている場合は、ユニットを使用しないでください。
-