

JME 8211R user guide

1、 Feature

1. 1. Transmission mode: RF
1. 2. Frequency: 2.4G
1. 3. RFchannel quantity: 1
1. 4. Power: 4pcs *7# batteries
1. 5. Modulate mode: GFSK
1. 6. Effective distance: 5m
1. 7. Quantity of connection ID: 256 个
1. 8. No. of keys: 88 key
1. 9. No. of extra multi media keys: 11 个
1. 10. Multi media keys definations: from left to right WWW E-mail Vol- Vol+ Mute
Backward Play/Pause Stop Forward Eject Sleep
1. 11. K/B Switch: power on/off for the whole keyboard
1. 12. T/P Switch: Touch PADpower on/off
1. 13. Mouse mode: Touch PAD

2、 Use guide

2. 1. First, confirm the receiver has been connected to the computer.
2. 2. Turn the K/B Switch& T/P Switch OFF.
2. 3. Put the batteries into the batteries casket, lock the cover.
2. 4. Turn T/P Switch ON the first, then turn K/B Switch ON.
2. 5. Need to check and match the code for the first time of usage only,.Please match the code as below:
 - A. Press the button on the receiver.。
 - B. Press the ID Link button on the keyboard within 10 seconds. (The ID Linkbutton is one the left bottom cornerof the keyboard)
2. 6. When find the TouchPAD can not wrok, please check whether the T/P Switch has been turn ON at the first. If the T/P Switch has been turned ON, it's possible that the TouchPAD has gone in Sleepmode, please press any key to wake up the TouchPAD.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV
INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS
EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY
TO OPERATE THE EQUIPMENT.**