

Photo # 1 Pen-Tablet Front View



Photo # 2 Pen-Tablet Rear View



Photo # 3 Pen-Tablet Unit Partially Disassembled



Photo # 4 Pen-Tablet Unit Partially Disassembled




Photo # 5 Pen-Tablet Unit Partially Disassembled



Photo # 6 Pen-Tablet Unit Partially Disassembled



Photo # 7 Cordless Mouse Front View



Photo # 8 Cordless Mouse Rear View



Photo # 9 Cordless Mouse Unit Partially Disassembled



Photo # 10 Cordless Mouse Unit Partially Disassembled





Photo # 12 Cordless Pen Unit Partially Disassembled

