

Instruction Manual for Transmitters TX-337A-R01 and TX-3377A-R01

BATTERY INSTRUCTIONS:

1. Remove battery compartment covers on vehicle and transmitter with a coin or a screwdriver.
2. Install "AA" alkaline batteries in the battery compartments with positive (+) and negative (–) ends matching the compartment markings.
3. Replace the battery covers.

OPERATION:

1. **START:** Move switch on bottom of vehicle to "ON" position.
The vehicle will automatically begin reverse and turning action.
2. **FORWARD:** Squeeze trigger on handle.
3. **REVERSE & TURNING:** Release trigger.
4. **STOP:** Move switch to "OFF" position.

FOR BEST RESULTS:

1. Do not mix old and new batteries.
2. Do not mix alkaline, standard or rechargeable batteries.
3. Use alkaline batteries only.

Remark: Modifications not authorized by the manufacturer may void users authority to operate this device.