

BATTERY INSTRUCTIONS:

1. Remove battery compartment covers on vehicle and transmitter with a coin or a screwdriver.
2. Install "AA" alkaline batteries in the battery compartments with positive (+) and negative (-) ends matching the compartment markings.
3. Replace the battery covers.

OPERATION:

1. **START:** Move switch on bottom of vehicle to "ON" position. The vehicle will automatically begin reverse and turning action.
2. **FORWARD:** Squeeze trigger on handle.
3. **REVERSE & TURNING:** Release trigger.
4. **STOP:** Move switch to "OFF" position.

FOR BEST RESULTS:

1. Do not mix old and new batteries.
2. Do not mix alkaline, standard or rechargeable batteries.
3. Use alkaline batteries only.

F.C.C. CAUTION:

The manufacturer is not responsible for radio interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

VEHICLE OPERATION:

For best results, this vehicle should be driven on dry surfaces. Mud, water or tall wet grass can damage internal electronic circuitry.

TRANSMITTER:

Radio waves control this vehicle and can easily be interrupted. Avoid operating near telephone or electrical lines or where C.B. radios are used such as near major highways.

RADIO FREQUENCY:

This vehicle runs on a specific frequency which is indicated both on the vehicle and on the controller. Operating this vehicle in the same area as another with the same frequency will cause both vehicles to malfunction.

F. C. C. APPROVED

BATTERY REQUIREMENTS: (not included)

VEHICLE: 2 "AA" Alkaline Batteries

TRANSMITTER: 2 "AA" Alkaline Batteries



INSTRUCTIONS ON PACKAGE BOTTOM

