

Features:

- Full Function Radio Control.
- 2.4GHz Frequency – allows up to 6 vehicles to run at the same time.
- Wheel Alignment – Adjust the wheel alignment located on bottom of vehicle between front wheels.

Features – Operated by the Transmitter:

1. Move Left joystick up to move the vehicle FORWARD.
2. Move Left joystick down to move the vehicle in REVERSE.
3. Move Right joystick left or right to move vehicle LEFT or RIGHT.
4. This vehicle has lights.
 - When driving forward or reverse the lights will turn on.
 - When stopping in forward or reverse the lights will turn off.
5. This vehicle has sounds.
 - Press ENGINE button on controller to hear engine sounds.

The Transmitter:

Insert 2 "AA" batteries in the battery compartment on the back of the transmitter. Be sure the (+) and (-) are properly matched.

The Vehicle:

- Insert 5 "AA" batteries in the battery compartment on bottom of vehicle. Be sure the (+) and (-) are properly matched.
- The vehicle is now ready for use.


Steering Trim:

If the vehicle veers to the left or right, adjust steering trim on underside of vehicle until the desire alignment is reached.

Batteries (not included):

Transmitter – 2 "AA" batteries.

Vehicle – 5 "AA" batteries.

**Notes:**

1. Operate the vehicle within 80-100 feet (25-30 meters) range.
2. Use alkaline batteries only.
3. Switch off the toy when not in use.
4. Remove all batteries when not in use for long periods.
5. If the vehicle is not functioning properly, replace batteries.
6. Adult supervision recommended.
7. Please remove all packaging attachments before giving this toy to your child.

The reception performance may be affected under a strong interference disturbance environment.

This product would not perform normally under a strong electrostatic environment.

We wish you many happy hours of pleasure with your New Bright toy.

