




Block Diagram - Mono Transceiver

Block Diagram



Block Diagram - Stereo Transceiver

Block Diagram



BEA Inc.
100 Enterprise Drive - RIDC Park West
Pittsburgh, PA 15275

Phone 1-412-249-4100 • FAX 1-412-249-4101
Toll Free 1-800-5 BEA INC

BEA West
2401 Pine Street
Los Angeles CA 91767

Phone 1-909-596-3011 • FAX 1-909-596-5411
Toll Free 1-877-BEA WEST

BEA South & Latin America
Mexico/Caribbean
Toll Free 1-800-711-1398
FAX 1-909-596-5411

South America
Phone & FAX ++ 55-21-2227-1341

www.beasensors.com

