

● Before you think It is out of order !!

1. System can not find mouse device

- ☞ Check receiver cable connected to system correctly (keyboard and mouse connector is very similar)
- ☞ Check receiver unit LED lamp blink when PC power on

2. Mouse cursor does not move

- ☞ Check whether battery direction correct
- ☞ Replace batteries with new one
- ☞ Move receiver unit closer to mouse (RF sensitivity can be influenced by circumstances)



3. Mouse cursor movement is not correct

- ☞ Clean mouse ball and roller
- ☞ Replace batteries with new one

4. Keyboard does not work



- ☞ Check whether battery direction correct
- ☞ Replace batteries with new one
- ☞ Move receiver unit closer to keyboard (RF sensitivity can be influenced by circumstances)

For more technical questions contact
<http://www.wingmouse.com>

Research, development & selling company

 WING COM CO.,LTD

951-25, Bongchunbon-Dong,
Kwanak-gu, Seoul, Korea 150-069
TEL : + 8 2 - 2 - 8 7 4 - 1 8 1 1
FAX : + 8 2 - 2 - 8 7 4 - 1 8 1 3
E-MAIL : trade@wingmouse.com
URL : <http://www.wingmouse.com>

Manufacturing company

 SEJIN CO.,LTD

60-19, Kasan-Dong, Keumchon-ku,
Seoul, Korea 153-023
TEL : +82-2 - 8 6 6 - 3 3 3 3
FAX : +82-2 - 8 6 6 - 8 5 6 7