

FRONT

ART+SOUND

Bluetooth

Plush Pal Wireless Speaker
AR6000GF

User Manual



Bluetooth

In the box



Plush Pal
Wireless Speaker



User Guide




Micro USB
Charging Cable

Charging the Plush Pal

To recharge the Plush Pal plug the small end of the micro USB cable into the charge port, then connect the large end of the micro USB cable into a USB port.

You can continue to use your Plush Pal while it is charging.


Location of controls



1. [⏻] button: Power ON/OFF
2. [⏸] button: Accept/reject calls; pause music
3. [⏮] button: LONG press: gradually decrease volume
QUICK press: skip to previous song
4. [⏭] button: LONG press: gradually increase volume
QUICK press: skip to next song
5. Micro USB charging port

Pairing the speaker

On an Android Phone
• Go to SETTINGS > BLUETOOTH> MENU
Search for devices (Make sure Bluetooth is turned ON)



On other Cell Phones/Devices
• Review the instruction manual that came with your phone/device.




Pairing the speaker

1. Press and hold [⏻] button for 3 seconds to turn the Plush Pal ON. A tone will be heard, indicating that the Plush Pal is in pairing mode.
2. Keep the Plush Pal and your Bluetooth-enabled device within 3 feet of each other during the pairing process.
3. Set your Bluetooth-enabled device to search for Bluetooth devices.

If there are no paired devices in range when the speaker is turned on, it will go into pairing mode automatically. If a paired device is in range, the speaker will connect to it automatically.

On an iPhone
• Go to SETTINGS > BLUETOOTH
(Make sure Bluetooth is turned ON)



On a Blackberry
• Go to SETTINGS/OPTIONS > BLUETOOTH
• Enable BLUETOOTH



4. When your device finds the speaker, select the device's model number, AR6000, from the list of devices.
5. If required, enter the password 0000. Select OK or YES to pair the Plush Pal to your device.
6. After a successful pairing, a tone will be heard, indicating that the Plush Pal is ready for use with your paired Bluetooth-enabled device.

The screenshots above are typical of many Bluetooth enabled devices in the market today, and are used to assist in the explanation of the pairing process. Your Bluetooth enabled device's interface and interaction with the speaker may slightly differ from the illustrations above.

Making phone calls

1. QUICK press the [⏸] button to answer phone. Refer to "Location of controls" section of this manual.
2. QUICK press the [⏸] button to hang up phone.

BACK

Using the Plush Pal

Adjusting the Volume

- Press and HOLD the [⏮] button to gradually increase the volume.
- Press and HOLD the [⏭] button to gradually decrease the volume.

Skipping and repeating songs

- Press the [⏮] button to skip to the next song.
- Press the [⏭] button to skip to the previous song.

NOTE: Play, Pause and Volume selection can also be controlled from your connected Bluetooth Device.

Troubleshooting tips

I can pair the Plush Pal Wireless Speaker with my Bluetooth device, but I cannot hear any music.

1. Make sure your Bluetooth device supports A2DP profile.
2. Turn up the volume on your Bluetooth device.
3. You may have to unpair the speaker, then re-pair to your device.

My Bluetooth device is not able to pair with the wireless speaker.

1. Make sure the Plush Pal Wireless Speaker is turned on before beginning the pairing process.
2. Keep the Plush Pal and your Bluetooth-enabled device within 3 feet of each other during the pairing process.
3. Check that YOUR device's Bluetooth feature is turned on.
4. Try repeating the pairing process. Consult the "Pairing the Speaker" section of this manual.
5. Make sure the speaker is charged.

I cannot get the Plush Pal Wireless speaker into pairing mode.

1. Make sure the speaker is turned ON before beginning the pairing process.
2. Make sure that your device's Bluetooth feature is powered ON and ready to search for Bluetooth devices.
3. Check that the speaker is charged.

Why is my Plush pal is beeping rapidly?

This is indicating that the Plush Pal's battery levels are low and needs to be charged.

Legal information

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Limited Warranty

90 Days Limited Warranty

In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Call the Customer Support number located below, or go to our website portal to receive an SRQ number.
- Provide proof of the date of purchase within the package (Dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:
Southern Telecom, Inc.
Attention: Customer Service (2nd Floor)
14-C 53rd Street

Should you have any questions or problems concerning this product, please contact our customer service department at:

Customer Support:
Phone: 1-877-768-8481
Monday-Friday 8AM-10PM(EST)

www.southern telecom.com
Click on "Product Support"

Limited Warranty (cont'd)

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:
• THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. AIT, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.