

PBT80

Polaroid

WIRELESS EARBUDS

PBT80 | USER MANUAL

Questions? Need some help? This manual will help you enjoy your new product.

If you still have questions, call our help line: 1-877-768-8481

or visit us at: www.southerntelecom.com Click on "Product Support"

Polaroid

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

FCC Part 15:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not modified and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment and to assist in meeting established laws, you should properly dispose of the product in compliance with all applicable regulations, directives or other governments in the area where you reside. Please check with local authorities or the dealer where you purchased this product to determine a location where you can appropriately dispose of the product.



IN THE BOX




LOCATION OF CONTROLS



CHARGING THE EARBUDS

Attach the small end of the micro USB cable to the micro USB charging port on the side of the dongle. Attach the large end of the micro USB cable to your computer or other USB charging device. The LED indicator will turn RED while charging and turn solid BLUE when it is fully charged. Remove the micro USB cable when charging is complete.



Make sure you charge the earbuds for at least 1 to 2 hours before using them for the first time.

PAIRING THE EARBUDS


1. Long press the [P] switch on the side of the earbuds. A tone will indicate that the earbuds are powered ON and in pairing mode and the LED indicator will slowly flash BLUE.
2. Set your Bluetooth-enabled device to search for Bluetooth devices.
3. When your mobile phone (or other Bluetooth-enabled device) finds the earbuds, select "PBT80" from the list of found devices.
4. After a successful pairing, a tone will indicate that the earbuds are connected and the LED indicator will slowly flash BLUE.

If required, enter the password 0000. Select OK or Yes to pair the units.

PAIRING THE EARBUDS (cont'd)

On an iPhone or Android

- Go to SETTINGS > BLUETOOTH (Make sure Bluetooth is turned ON)



The screenshots above are typical of many Bluetooth-enabled devices in the market today, and are used to assist in the explanation of the pairing process. Your Bluetooth-enabled device's interface and interaction with the earbuds may differ slightly from the illustrations above.

USING THE EARBUDS

Powering ON/OFF

- Turn the earbuds ON by long pressing the [P] button. A tone will be heard indicating that the earbuds are powered ON.
- Turn the earbuds OFF by long pressing the [P] button. A tone will be heard indicating that the earbuds are powered OFF.

NOTE: After 15 minutes of inactivity, the earbuds will turn OFF automatically.

Answering Phone Calls

- To answer a phone call quick press the [P] button.
- To end a call, quick press the [P] button. Music playback will automatically resume.

PLAYING MUSIC

To enjoy music wirelessly on your Wireless Earbuds, make sure that the earbuds are properly paired to your Bluetooth-enabled device. If you are pairing the device for the first time, please consult the "Pairing the Earbuds" section of this user guide.

Playing/Pausing Music

- Quick press the [P] button to pause the music.
- Quick press the [P] button again to resume music playback.

Skipping Songs

- Quick press the [-] button to go to the previous song.
- Quick press the [+] button to go to the next song.

Adjusting the Volume

- Long press the [-] to decrease the volume of music playback.
- Long press the [+] to increase the volume of music playback.

You may adjust the volume from both the wireless earbuds and your Bluetooth-paired device.

WARRANTY

This product as supplied and distributed new by AT, Inc. ("AT") to the original consumer purchaser is warranted by AT against defects in material and workmanship for a period of one year from your date of purchase ("Warranty"). In the unlikely event that this product is defective, or does not perform properly, you may within one year from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Call the Customer Support number located below, or go to our website portal to receive an SRO number.
- Provide proof of the date of purchase within the package (dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping, will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

AT, Inc.
ATTN: Customer Service (2nd Floor)
14-C, 32nd Street
Brooklyn, NY 11232

IN NO EVENT WILL AT, ITS MANUFACTURERS, DISTRIBUTORS OR PLR IP HOLDINGS, LLC BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) RELATED TO THIS PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY.

Questions? Need some help? This manual will help you enjoy your new product.

If you still have questions, call our help line: 1-877-768-8481

or visit us at: www.southerntelecom.com Click on "Product Support"