

165.0mm

279.0mm



INSTRUCTION MANUAL

CAN ICES-3 (B)/NMB-3(B)

Thank you for purchasing the CODE JUMPER !

Requires 4 x 1.5V "AA"/LR6 alkaline batteries (not included).
Phillips/cross head screwdriver (not included) needed to insert batteries.

To begin playing with your Code Jumper, you must first install batteries.

TO INSTALL BATTERIES

Use a Phillips/cross head screwdriver, loosen screw in battery compartment cover on the bottom of Hub (screw stays attached to cover). Insert 4 X 1.5V "AA"/LR6 alkaline batteries. Replace cover and tighten screw.



⚠ CAUTION: TO AVOID BATTERY LEAKAGE

- Be sure to insert the batteries correctly and always follow the battery manufacturers' instructions;
- Do not mix old batteries and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
- Always remove weak or dead batteries from the product.

IMPORTANT:

Please retain this information and all the packaging for future reference.
Batteries should be replaced by an adult.

Use a Phillips/cross head screwdriver, loosen screw in battery compartment cover on the bottom of Hub (screw stays attached to cover). Insert 4 X 1.5V "AA"/LR6 alkaline batteries. Replace cover and tighten screw.



⚠ CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert item correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short circuit the supply terminals.
6. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision.

DO NOT RECHARGE NON-RECHARGEABLE BATTERIES.

More details of the user manual at :

<https://codejumper.com>

折痕线

材质：250g白卡

尺寸：165.0mm * 279.0mm