



Dell Premier Multi Device **Wireless** Keyboard and Mouse Combo

KM7321W


Quick Start Guide

Wireless Keyboard: KB7221Wt
Wireless Mouse: MS3121Wt




1


1



2




3



4





5




2


1



2




3




2


1



2




3




3


1



2




3




3


1




2



3




4



4


1



2




2



3



3



3



<https://www.dell.com/support/drivers>

