



MC9000-G Quick Start Guide

<http://www.symbol.com/mc9000g>
See Product Reference Guide for more information


POST IN WORK AREA




Battery Insertion




Battery Removal




Stylus Removal



Snap-on Accessory Installation




Data
Power



Cable Adapter Module


Data
Power




Magnetic Stripe Reader

Charging Instructions


● = LED Indicator Location
Slow Flash = Normal Charge | Solid Amber = Full Charge | Fast Flash = Charging Error



Four Slot Spare Battery Charger




Single Slot Serial Cradle




Four Slot Cradles

Charge-Only Cradle and Ethernet Cradle

Optimum Scanning Positions




ALTERNATE LEFT AND RIGHT HANDS
TAKING BREAKS AND TASK ROTATION RECOMMENDED



Optimum Upright Body Posture



Avoid Extreme Wrist Angles



AVOID EXTREME
WRIST ANGLES




Optimum Body Posture for Low Scanning

ALTERNATE LEFT
AND RIGHT KNEES



AVOID BENDING



AVOID REACHING



Optimum Body Posture for High Scanning

USE A LADDER



72-63360-01 Rev A August 2003