


RACK MOUNT

| REVISION HISTORY |     |       |              |
|------------------|-----|-------|--------------|
| DATE             | REV | ECO # | COMMENT      |
| 09/24/97         | 04  | N/A   | ORIGINAL REV |
|                  |     |       |              |
|                  |     |       |              |



LABEL PLACEMENT INSTRUCTIONS:

1. AFFIX THE TEST LABEL (ITEM 1) TO THE REAR OF THE UNIT AS SHOWN. LABEL SHOULD READ FROM LEFT TO RIGHT AND NOT COVER ANY SILKSCREEN.
2. AFFIX THE SERIAL NUMBER LABEL (ITEM 2) TO THE REAR OF THE UNIT AS SHOWN. LABEL SHOULD READ FROM LEFT TO RIGHT AND NOT COVER ANY SILKSCREEN.
3. AFFIX THE FCC LABEL (ITEM 3) TO THE REAR OF THE UNIT AS SHOWN. LABEL SHOULD READ FROM LEFT TO RIGHT AND NOT COVER ANY SILKSCREEN.

| ITEM | DESCRIPTION                  | QTY |
|------|------------------------------|-----|
| 3    | LABEL - FCC                  | 1   |
| 2    | LABEL - SERIAL NUMBER        | 1   |
| 1    | LABEL - TEST - GENERIC USAGE | 1   |

|         |     |                        |            |
|---------|-----|------------------------|------------|
| PRODUCT |     | ADTRAN                 |            |
| TITLE   |     | TRACER<br>RF RACK UNIT |            |
| DRW     | LTW | ENG                    | BY ENG     |
|         |     |                        |            |
| FINISH: |     | LABEL<br>PLACEMENT     |            |
| SCALE   | NTS | SIZE                   | 3999.01397 |
|         |     |                        |            |