



Aux antenna

The diagram shows a green rectangular box in the top-left corner and a green rectangular box in the bottom-right corner. A brown diagonal line connects the top-right corner of the top box to the bottom-left corner of the bottom box. The text 'Aux antenna' is positioned to the right of the top box, and 'Main antenna' is positioned to the left of the bottom box.

Main antenna

Main antenna type: PIFA	Aux antenna type: PIFA
Antenna gain	Antenna gain
700: -1.1dBi	700: -1.5dBi
750: 1.4dBi	750: 1.5dBi
800: 0.8dBi	800: 1.5dBi
850: 0.5dBi	850: 2.1dBi
900: 0.3dBi	900: 1.4dBi
950: -1.1dBi	950: 1.7dBi
1850: 2dBi	1850: 1.4dBi
1900: 2.4dBi	1900: 1.8dBi
1950: 2.6dBi	1950: 1.2dBi
1990: 2.4dBi	1990: 0.2dBi