


2. Photograph of the test configuration



3. Sample Calculation

The emission level measured in decibels above one microvolt (dB) was converted into microvolt per meter (/m) as shown in following sample calculation.

For example :

	Measured Value at	<u>300.4 MHz</u>	50.6 dB
+	Antenna Factor		13.8 dB/m
+	Cable Loss		3.2 dB
-	Preamplifier		30.0 dB
-	Distance Correction Factor *		0.0 dB

=	Radiated Emission		37.6 dB /m
			(= 75.9 /m)

* Extrapolated from the measured distance to the specified distance by an inverse linear distance extrapolation.