


SAR Test Setup Photographs

EUT Side Definition	
Mode	Side
1	Side 1
2	Side 2
3	Side 3
4	Side 4
5	Side 5
6	Side 6

Note: We choose the maximum results of each test positions to provide the cube locations.




Phantom Position : Flat	EUT side : Side2
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side3
Spacing to phantom : 0 mm	Accessory : N/A

