

Copyright Information

All rights reserved. No part of this publication may be reproduced, transmitted, stored in a retrieval system, or translated into any language in any form by any means, mechanical, optical, electronic, recording, or otherwise, without the written permission of Mustek, Incorporated.

Mustek Incorporated reserves the right to revise this manual and to make changes to any or all parts at any time, without obligation to notify any person or entity of such revisions and changes.

Mustek is a registered trademark of Mustek, Incorporated. All other brand or product names mentioned in this manual are trademarks or registered trademarks of their respective owners.

Copyright © 1998 Mustek, Incorporated.
Printed in Taiwan, May 1998.

FCC Statement

This digital equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if it is not installed and used according to the instruction manual, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off or on, you are encouraged to try to correct the interference by one or more of the following measures:


- Reorient the receiving antenna
- Increase the distance between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

NOTE

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

Connecting the Scanner to the PC and Printer

Refer to the following illustration and steps to install your scanner.



1. Power off the computer and any devices that are connected to it (e.g., monitor, printer, modem).
2. Disconnect the printer cable from the printer port in the back of your PC.
3. Take the disconnected end of the printer cable and attach it to the port in the back of the scanner marked **Printer**. Tighten the retaining screws.
4. Connect one end of the scanner cable to the printer port in the back of your PC and tighten the retaining screws.
5. Connect the other end of the scanner cable to the port in the back of the scanner marked **Computer**.
6. Connect the power adapter to the scanner and plug it into an appropriate power outlet.
7. Power on the computer and wait for the computer to finish booting.
8. Install the scanner driver and software by referring to the next section.