



Quanta Today



ON6




Quanta Confidential

EXHIBIT 9A



Step 1: Take apart KB & screw out the screws under the KB



Push 3 kb locks, take off kb



Open membrane connector & take out kb




Screw out 10-M2X3L screws





Step 2: Take apart Base

Quanta Today




Quanta Confidential



Step 3: Take apart battery

Quanta Today



Pull out the battery plug
& remove the battery.

Caution: Do not remove
any other connector
before removing battery




Quanta Confidential

EXHIBIT 9A



Step 4: Take apart Phone cable

Quanta Today




Quanta Confidential




Step 5: Pull out the plugs & take apart speaker

Quanta Today



Pull out all the plugs



Screw out 4-M2x4L screws fixed the speaker



Quanta Confidential




Step 6: Take apart main board

Quanta Today



Screw out 2-M2x3L screws
fixed the main board




Quanta Confidential




Step 7: Take apart cradle cover


Quanta Today



Screw out 6 screws



Remove cradle cover




Quanta Confidential



Step 8: Separate the display parts from top cover

Quanta Today



Quanta Confidential

EXHIBIT 9A



Step 9: Take apart Bezel

Quanta Today



Screw out 4-M2x4L screws

Take apart Bezel





Quanta Confidential

EXHIBIT 9A



Step 10: Separate LCD panel from LCD cover


Quanta Today







Step 11: Separate L/R hinge from LCD panel

Quanta Today



Screw out 4-M2x2.5L screws



Quanta Confidential



Quanta Today



All the parts have been separated

Quanta Confidential

EXHIBIT 9A