

INSTRUCTION MANUAL

A revised preliminary draft copy of the Users Manual follows:

CDMA Tarpon Wireless Telephone Basic User's Guide

Preliminary Draft

June 19, 2000

Contents

Safety Information	3
Getting Started	10
Opening the Box	10
Battery	11
Turning On Your Phone	12
Placing a Call	13
Ending a Call	14
Redialing a Number	14
Receiving a Call	14
Viewing Your Phone Number	14
Learning More Tasks	15
Navigating to Features	15
Using Menu Features	19
Entering Text	22
Storing an Entry in the Phonebook	25
Using Text Messages	29
Using Voicemail	32
Locking and Unlocking Your Phone	33
Caller ID	35
Automatic Redial	35
Call Waiting	36
Unanswered Calls	36
Dialing Emergency Numbers	37
Additional Dialing Features	37

Using In-Call Features	39
Phone Fundamentals	40
Phone Diagram	40
Display	41
Status Light	43
Volume Keys	44
Battery Use	44
When You're Ready to Do More	46
Menu Map	46
Menu Feature Descriptions	47
Conference Call	54
VoiceNotes	55
Datebook	59
Configuring Settings	62
FDA Update	74
Index	84
Patent Information	91

Safety Information

Important: Read this information before using your wireless handheld phone.

Exposure to Radio Frequency Signals



Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.

In August 1996, The Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for handheld wireless phones. Those guidelines are consistent with safety standards previously set by both U.S. and international standards bodies:

- American National Standards Institute (ANSI) IEEE. C95. 1-1992
- National Council on Radiation Protection and Measurement (NCRP). Report 86
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1996
- Ministry of Health (Canada), Safety Code 6

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities,



government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of your phone complies with the FCC guidelines (and those standards). For additional information concerning exposure to radio frequency signals, see the statement by the FDA at the end of this user guide.

To maintain compliance with FCC RF exposure guidelines, if you wear a handset on your body, use the Motorola-supplied or approved carrying case, holster, or other body-worn accessory.

If you do not use a body-worn accessory, ensure the antenna is at least one inch (2.5 centimeters) from your body when transmitting. Use of non-Motorola accessories may violate FCC RF exposure guidelines.

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone Operation

Normal Operation

Hold the phone as you would any other telephone, with the antenna pointed up and over your shoulder.

Tips on Efficient Operation

Observe the following guidelines to operate your phone most efficiently.

- Extend your antenna fully, if applicable.
- Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

Batteries

Caution: All batteries can cause property damage, injury, or burns if a conductive material, such as jewelry, keys or beaded chains, touches exposed terminals. The material may complete an electrical circuit and become quite hot. To protect against such unwanted current drain, exercise care in handling any charged battery, particularly when placing it inside your pocket, purse, or other container with metal objects. When the battery is detached from the phone, your batteries are packed with a protective battery cover; please use this cover for storing your batteries when not in use.

Driving

Check the laws and regulations on the use of wireless telephones in the areas where you drive. Always obey them. Observe the following guidelines when using your phone while driving.

- Give full attention to driving--driving safely is your first responsibility.
- Use hands-free phone operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of six inches (15 centimeters) be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

Persons with pacemakers:

- should ALWAYS keep the phone more than six inches from their pacemaker when the phone is turned ON
- should not carry the phone in a breast pocket
- should use the ear opposite the pacemaker to minimize the potential for interference

- should turn the phone OFF immediately if you have any reason to suspect that interference is taking place

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone OFF in any facility where posted notices so require.

Aircraft

Switch OFF your phone before boarding an aircraft. Airline regulations prohibit using your phone while in the air. Check and comply with the policy of your airline regarding the use of your phone while the aircraft is on the ground.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a “blasting area” or in areas posted: “Turn off two-way radio.” Obey all signs and instructions.

Potentially Explosive Atmospheres

Turn your phone OFF, do not remove your battery when you are in any area with a potentially explosive atmosphere, and obey all signs and instructions. Sparks from your battery in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often but not always clearly marked. They include: fueling areas such as gasoline stations; below deck on boats; fuel or chemical transfer or storage facilities; areas where fuel odors are present (for example, if a gas/propane leak occurs in a car or home); areas where the air

contains chemicals or particles, such as grain, dust, or metal powders; and any other area where you normally would be advised to turn off your vehicle engine.

For Vehicles Equipped with an Air Bag

An air bag inflates with great force. Do NOT place objects, including both installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

US021600

Getting Started



Opening the Box

Your digital wireless phone typically comes equipped with a charger and at least one battery. A large selection of accessory options can customize your wireless phone for maximum performance and portability. The following illustration shows the standard package options.


Note: Your phone and accessories may not look exactly as pictured.



Motorola
Telephone



Lithium Battery



Holster

Battery

Before you can use your phone, you will need to install and charge the battery.



We recommend that you use only Motorola Original™ batteries and accessories, and that you store batteries in their protective covers when not in use.


Installing the Battery

Do This

Remove the battery's protective cover.




Push down the battery door release latch and lift open.



Do This

Insert the battery, printed arrows first, into the battery compartment and push down.



Replace and close the battery door.

Charging the Battery**Do This**

Plug the AC adapter into your phone with the release tab facing up

**Illustration
to come**

Plug the other end of the AC adapter into the appropriate electrical outlet.

Turning On Your Phone**Do This**

Press and hold 

To

turn on your phone

Do This	To
Enter your unlock code and press OK (🔍)	unlock your phone, if necessary

Placing a Call

To place a call, your phone must be turned on, be unlocked, and be in contact with the network.

Press	To
keypad keys	enter the phone number
	Tip: If you make a mistake, press DELETE (🗑️) to delete the last digit, or press and hold DELETE (🗑️) to clear all digits.
	place the call

Note: You can enter a phone number up to a maximum of 32 digits, but only the last 24 digits appear in the display.

Ending a Call

Press	To
	end the call

Redialing a Number

If you hear an ordinary busy signal, the phone number you dialed is busy.

Press	To
	hang up
	redial the busy number

Receiving a Call

To receive a call, your phone must be turned on and be in contact with the network.

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

Press	To
 or ANSWER 	answer the call

Viewing Your Phone Number


Press	To
 	display your phone number

Learning More Tasks



Navigating to Features

You can access many of your phone's features through a menu system. Use these keys to move through the menu system and find the feature you want:





Some features that are described in this guide are designated with this logo. These are optional network and subscription-dependent features. Contact your service provider for information about availability.

This guide provides navigation instructions that show you how to get to specific menu features as follows:

Find the Feature

 > Recent Calls > Dialed Calls

The > symbol means that you should scroll to and select the indicated feature. To locate and select the **Dialed Calls** feature as shown in the above example:

Do This



From the idle display, press  to enter the menu system

Do This



Recent Calls is already highlighted because it is the first item in the menu list

Press SELECT (⏏) to select Recent Calls



Press ⏏ to scroll to Dialled Calls

Do This




Press SELECT (⓪) to
select Dialed Calls

Your phone displays
the dialed calls list

Using Menu Features


To set or adjust a phone feature, you may have to select an item from a list of options, or use the keypad to enter information.

Some features prompt you to select from a list of items or actions:



- In a numbered list, press a number key to highlight the item.
- In an alphabetized list, press a key multiple times to cycle through the letters on the key and highlight the closest matching list item.
- If a list item runs off the right side of the display, press and to scroll and view the entire entry.


Other features, such as the phonebook and datebook applications, require you to enter information in multiple fields:



- Enter information in an empty field by typing numbers or text from the keypad. (See “Entering Text” on page 22.)
- When a field contains a predefined list of values, press ⏏ and # to scroll through and select a value.

The message center application lets you compose and send alphanumeric text messages. A flashing *I-beam cursor* indicates the text insertion point:

Flashing
I-beam cursor
indicates
insertion
point.



Press **CANCEL** (⏏) to exit without making changes.

Press **M** (MENU) to open the sub-menu.

Press **BROWSE** (🔍) to select data from a list of entries.

When you begin entering data, the I-beam cursor change to a *block cursor* and the soft key functions change appropriately:

Block cursor
indicates
current
highlighted
character.



Press **CANCEL** (⏏) to delete the character to the left of the insertion point.

Press **OK** (👉) to accept and store the data.

Entering Text

General Text Entry Rules

Use the number keys to enter letters, numbers, and other characters. Press the same key repeatedly to cycle through available characters (see “Character Chart” on page 23):

Press a number key to enter text at I-beam cursor location

Press a number key as many times as necessary to enter the desired character

Press and hold a number key to cycle between uppercase and lowercase characters



Move I-beam cursor up or down one line, change character in block cursor to uppercase or lowercase

Move I-beam cursor to the left or right, change block cursor to I-beam cursor

- If you do not press a key for two seconds, the character in the block cursor is accepted and the cursor moves to the next position.
- The first character of every sentence is capitalized unless you manually override it.

Character Chart

Use this chart as a guide for producing characters. Press and hold a key to cycle between uppercase and lowercase characters.


1	[space] . 1 ? ! , @ _ & : " () ' ÿ ÿ % £ \$ ¥
2 ABC	A B C 2 Ä Å à α β Ç
3 DEF	D E F 3 Δ É è Φ
4 GHI	G H I 4 Γ ì
5 JKL	J K L 5 Λ
6 MNO	M N O 6 Ñ Ö Ø Ò Ω
7 PQRS	P Q R S 7 Π ß Σ
8 TUV	T U V 8 Θ Ü ù
9 WXYZ	W X Y Z 9 Ξ Ψ
0 OPS	+ - 0 x * / = > < # §

Using iTAP

iTAP lets you type the letters of a word using only one keypress per letter. To use iTAP, press **MENU** and select iTAP when you are prompted to enter text.

When you activate iTAP, the third line of the display becomes a working area that shows a list of the most common words and letter combinations based on the keys you press. The list is updated with each keypress. When you have entered all the letters of a word, press **←*** and **#→** to scroll left and right through the list and select the word you want.

For example, to spell the word “act,” press **2^{abc}** **2^{abc}** **8^{tuv}**. The display shows:



If the word you are spelling is not in the iTAP dictionary, an appropriate letter combination may not appear in the word list. Delete one or more characters until you see an accurate letter

combination, then highlight it to lock that portion of the word. Continue entering letters and highlighting letter combinations to spell the word.

- The first word of a sentence is automatically capitalized, with following words in lowercase. Press  one or more times to force initial character capitalization, all uppercase, or all lowercase characters.
- A space is automatically added after each word. When you add punctuation, the space before the punctuation is removed. Press  or  to enter punctuation or special characters as shown in the “Character Chart” on page 23.
- To type a number, enter the first digit and then highlight it in the working area. Following keypresses add digits to the number until you press **SELECT** () to enter the number at the insertion point.

Storing an Entry in the Phonebook

You can store a list of names and phone numbers in your phone’s electronic phonebook. You can view and dial these entries directly from your phone.


Fields in a Phonebook Entry Form

Voice Name icon indicates a recorded Voice Name. (You can call the entry by saying the name when your phone is idle.)

The title is the entry's **Name** (the name of the person or group) or **Speed Number** (the number you can enter from idle to "speed dial" the entry).

Type icon is the type of phone number

-  Work
-  Home
-  Main
-  Mobile
-  Fax
-  Pager



No. is the phone number.

Speed Number

Returns to list view

Opens phone menu

Opens entry form

Storing a Phonebook Entry

Note: You can also use the following procedure to store a fixed dial entry by scrolling to and selecting **Fixed Dial**.

Find the Feature

 > Phonebook

 > New

Entering Required Fields

Some fields are required for a phonebook entry.

Press	To
	scroll to Name
Change ()	select Name
keypad keys	enter a name for the phonebook entry (see “Entering Text” on page 22)
OK ()	store the name
	scroll to No .
Change ()	select No .
keypad keys	enter the phone number
OK ()	store the phone number

Recording a Voice Name

You can also optionally record a voice name for a phonebook entry.

Press	To
	scroll to Voice Name
Record ()	record a voice name
	The phone displays Press Voice Key then say name.

Press	To
voice key and say the entry's name (in two seconds)	record the voice name The phone displays Press Voice Key then REPEAT name.
voice key and repeat the name	confirm the voice name The phone displays Trained: Voice Name .

Entering Optional Fields

Continue by entering some optional fields, if needed.

Press	To
	scroll to Type
Change 	select Type
	scroll to the type of phone number
Select 	select the type of phone number
	scroll to Speed No.
Select 	select Speed No. The phone automatically fills in the first available number on a new form.
keypad keys	enter a different speed number if desired
Save 	save the modified speed number If your chosen speed number is already assigned to another entry, you are asked if you want to replace that entry.

Press	To
	scroll to More
Select ()	select More if you want to create another entry with the same Name

Using Text Messages

Text messages are brief messages that appear on your phone display. A text message may include phone numbers or URLs. You must set up a text message inbox *before* you can send and receive these messages. Your inbox holds up to 10 messages.

Setting Up the Text Message Inbox

Find the Feature  > Messages
 > Text Msg Setup

Press	To
	scroll to the Service Center No. field
Change ()	open the Service Center No. editor
keypad keys	enter the phone number for the service center that handles your outgoing messages
OK ()	store your service center number
	scroll to the Expire After field
Change ()	open the Expire After editor

Press	To
keypad keys	enter the expiration period—the number of days your network tries to send unreceived messages
OK (⌂)	store the expiration period
⬆	scroll to the Reply Type field
Change (⌂)	open the Reply Type editor
⬆	scroll to the type of replies you want to send
Select (⌂)	store the reply type
⬆	scroll to the Cleanup Period field
Change (⌂)	open the Cleanup Period editor
⬆	scroll to the period that messages stay in your inbox
Select (⌂)	store the cleanup period
	If you select Custom , continue. Otherwise, the procedure is complete.
⬆	change the entry in the active Custom field
* and #	switch between the number and label fields
Done (⌂)	store the custom cleanup period

Reading Text Messages

Note: You must set up your inbox before reading text messages. See “Setting Up the Text Message Inbox” on page 29.

Find the Feature

 > Messages > Text Msgs

Press	To
 	scroll to the message you want (! = unread and urgent, ✓ = read, 🔒 = read and locked)
Read 	open the message

Dialing Numbers from Text Messages

Note: You must set up your inbox before opening text messages. See “Setting Up the Text Message Inbox” on page 29.

Find the Feature

 > Messages > Text Msgs

Press	To
 	scroll to the message with the number
	open the text message menu
 	scroll to Call Back
Select 	dial the number stored with the message

Note: If the phone lists more than one number for the message, press 
 to scroll to a number and press Select  to dial.

Using Voicemail



You can listen to your voicemail messages by calling your network voicemail phone number.

Storing Your Voicemail Number

Store your voicemail number in your phone to make it faster and easier to use voicemail.

Find the Feature

 > Messages

 > VoiceMail Setup

Press	To
keypad keys	enter the phone number for your voicemail
OK ()	store the number

Listening to Voicemail Messages

Note: Store your voicemail number before using this procedure.

Find the Feature

 > Messages > VoiceMail

Your phone calls the voicemail number you stored. Contact your service provider for information about your voicemail features.

Locking and Unlocking Your Phone

You can lock your phone manually, or you can set your phone to lock automatically whenever you turn it off.

When you try to use a locked phone, it prompts you for your unlock code. A locked phone still rings or vibrates for incoming calls or messages.

Locking Your Phone Manually

Find the Feature

 > Settings > Security > Phone Lock
> Lock Now

Press	To
keypad keys	enter your four-digit unlock code
Press OK ()	lock the phone

Setting Your Phone to Lock Automatically

Find the Feature

 > Settings > Security > Phone Lock
> Automatic Lock > On

Press	To
keypad keys	enter your four-digit unlock code
Press OK ()	set the phone to lock automatically

Unlocking Your Phone

At the **Enter UnLock Code** prompt:

Press	To
keypad keys	enter your four-digit unlock code
Press OK (⌂)	unlock the phone

If You Forget a Code or Password

If you forget a security code (originally set to 000000), contact your service provider.

If you forget your phone's unlock code (originally set to 1234), try the last four digits of your phone number. If that does not work, do the following when you see the **Enter UnLock Code** prompt:

Press	To
	display the security code prompt
keypad keys	enter your security code
OK (⌂)	bypass the UnLock Code prompt

Locking and Unlocking Your Keypad

Press	To
 	lock or unlock your keypad

Note: Incoming calls and messages unlock the keypad.

Caller ID



The *Calling line identification* (caller ID) feature lets you see who is calling before you answer.

- If the caller's name is stored in your phonebook, the name is displayed.
- If the name is not in your phonebook, the caller's phone number is displayed.
- If caller ID information is not available, your phone displays the message *Incoming Call*.

Automatic Redial

You may be unable to complete a call if the wireless system is busy. When this happens, the system transmits a fast busy signal, and your phone displays the message *Call Failed* along with the reason for the failure.

With automatic redial, your phone repeats the call attempt over the next four minutes.

Press	To
 or 	activate automatic redial

When the call goes through, your phone rings or vibrates one time, displays *Redial Successful*, and then connects the call.

Call Waiting



If you subscribe to call waiting, you may hear a tone while you are on a call. This tone indicates that you have received a second call.

To place the first call on hold while you answer the second call:

Press	To
SND	answer the new call
SND (analog mode)	switch back to the first call
or	
SWITCH (👁)	(digital mode)

To end the first call and answer the second call:

Press	To
END	end the current call
	Your phone rings to signal the new call.
SND	answer the new call

Unanswered Calls

When you cannot answer a call, your phone keeps a record of your unanswered calls and displays the 📞 (missed calls) icon and the

message **Missed Calls** (or **Unknown** if caller ID information is not available).

Press	To
VIEW (👁)	view the unanswered calls list
⬆ ⬆	scroll through the list and select a call that you want to return
SEND	dial the number

Dialing Emergency Numbers

Your service provider programs one or more emergency phone numbers that you can dial even if your phone is locked or restricted.

Press	To
any keypad key	display the enter code or locked prompt
keypad keys	enter the emergency number (such as 911)
SEND	dial the emergency number

Additional Dialing Features

In addition to simply dialing numbers on your keypad, you can insert numbers or characters and dial calls in a variety of ways.

To insert numbers or characters:

Do This	To Insert
Press 0 for two seconds and enter rest of number	international access code for country from which you are calling
Press MENU and then scroll to and select one of the following: • Insert Pause (to insert a p) • Wait (to insert a w) • Insert 'n' (to insert an n)	special character when making a calling card call: • Pause tells your phone to wait until the call connects before it dials the next digit in a series • Wait tells your phone to wait until the call connects, then prompt you before it sends the remaining digits • 'n' tells your phone to stop and prompt you for a number before it continues dialing
Press MENU > Attach	digits to precede the number to call
Press MENU > Add Digits	digits at the end of the number to call

To dial a call:

Do This	To Dial
Press the two-digit phonebook index number of the entry	speed dial number

Do This	To Dial
Press and hold the single-digit phonebook index number	one-touch dialing number
Press voice key and say the name (in two seconds)	voice dial number
Press  > Recent Calls > Received Calls or Dialed Calls > entry to call	missed or recent call

Using In-Call Features


While you are on a call, you can perform the following tasks:

Do This	To
Press  > Hold	place a call on hold
Press  > Mute	mute a call
Press  > Spkrphone On	activate the speakerphone (hands-free mode)
Press  > My Tel. Number	View your phone number
Press  > Send Tones	Send digits as DTMF tones, for example for credit card dialing or password entry

Phone Fundamentals




Phone Diagram



Display

The top section of the display shows phone status indicators. Text and number messages, keypad input, and menu options appear in the middle of the display. Text labels at the bottom of the display identify the current soft key and menu key functions.

Display Indicators



1 Signal Strength Indicator Shows the strength of your phone's connection with the local wireless system.

Strong No signal

You cannot make or receive calls when the no signal indicator is displayed.

② In Use Indicator Appears when a call is in progress.

③ Roam Indicator Appears when your phone accesses a wireless system outside your home network. When you leave your wireless service area, your phone *roams* or seeks another service area.



④ Message Waiting Indicator Displayed when your phone receives a text message.



⑤ Voice Message Waiting Indicator Displayed when your voicemail receives a message.

⑥ Battery Level Indicator Shows the amount of charge left in your battery. The more segments visible, the greater the charge.

High     Empty

Recharge your battery as soon as possible when you see the Low Battery warning message.

⑦ Alert Indicator Indicates the current selected alert. The default alert is a ringer.



Ringer on



Vibrate on

(add) Vibrate then ring



Ring then vibrate

-  Silent
-  Vibrate with all tones off
-  All Alerts off

③ Digital () or Analog () Signal Indicator


Indicates whether you are receiving a digital or analog signal.

Status Light

The status light provides information regarding your type of service, and incoming call or message status.

The status light changes color and flashes or remains on to indicate different states:


Status
light



Indication	State
alternating red/green	incoming call
flashing green	in service, home-type system
flashing yellow	roaming, non-home-type system
flashing red	no service
alternating red/service color (green, yellow, or red)	text message or voicemail message received

Volume Keys

Use the upper and lower volume keys to adjust your phone's earpiece and ringer volume.



When	Press	To
During a call	volume keys	increase or decrease earpiece speaker volume
When you are not on a call	volume keys	increase or decrease ringer volume

Battery Use

Caution: To prevent injuries or burns, do not allow metal objects to contact or short-circuit the battery terminals.

Maximizing Battery Life

To ensure that you enjoy maximum battery life and use your battery to its fullest capacity:

- Always use Motorola approved batteries and battery chargers.
- Maintain the battery at or near room temperature when charging.

- New batteries or batteries that have been stored for long periods of time may not rapid charge properly. In these instances, the battery requires an overnight charge.
- When you do not intend to use a battery for a while, store it uncharged in a cool, dark, dry place, such as a refrigerator.
- To prolong the life of your batteries, do not expose them to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your car.
- Over extended periods of time, batteries gradually wear down and require longer charging times. This is normal. If you charge your battery regularly and notice a decrease in talk time or an increase in charging time, then it is probably time to purchase a new battery.

Disposing of Batteries

To dispose of batteries, check with your local recycling center for a battery recycler near you. Never dispose of batteries in a fire.

When You're Ready to Do More Menu Map



This is the standard menu layout. Your service provider may have modified the menu structure or changed some feature names. And, you can change the menu structure, as well. Not all features may be available for all users.

- **Recent Calls**
 - Received Calls (53)
 - Dialed Calls (52)
 - Notepad (53)
 - Call Times (52)
- **Phonebook** (51)
- **Datebook** (47)
- **Quick Dial** (52)
- **Radio** (52)
- **Messages** (48)
- **Info on Demand** (48)
- **Shortcuts** (54)
- **VoiceNotes** (54)
- **Browser** (47)
- **Settings**
 - **Ring/Vibrate**
 - Alert (53)
 - Detail (53)
 - **Phone Status**
 - My Tel. No. (51)
 - Phone: Line 1/2 (51)
 - Battery Meter (51)
 - Credit Info (51)
 - Other Information (51)
- **Settings (continued)**
 - **Connection**
 - IrDA Link (47)
 - **In Call Setup**
 - In Call Timer (48)
 - Answer Options (47)
 - Call Waiting (48)
 - **Security**
 - Phone Lock (54)
 - Lock Keypad (53)
 - Lock Application (53)
 - Restrict Calls (54)
 - New Passwords (54)
 - **Other**
 - Personalize (50)
 - Initial Setup (49)
 - Network (50)
 - Car Settings (49)
 - Headset (49)

Menu Feature Descriptions

BROWSER Access Web pages and run Web-based applications.

The Browser delivers WAP (Wireless Application Protocol) pages from your wireless service provider directly to your phone. These pages give you current information on selected topics.



CONNECTION You can connect your phone to a computer or fax machine to send and receive fax and data calls on the connected machine. You can connect your phone using a cable and PCMCIA card, a cable only, or an *Infrared Data Association* (IrDA) link.

IrDA Link Set up a wireless infrared connection. Your phone must be within one meter of the linking device.

DATEBOOK Schedule appointments in the datebook calendar. You can display events for the week, a day, or details for a specific event. See “Datebook” on page 59.

IN CALL SETUP Customize settings that provide information during a phone call, such as timers and call-answering options.

Answer Options Turn call answering options on or off:

Multi-Key answer by pressing any key

Call Waiting Activate and deactivate call waiting.

When another call arrives while you are already on a call, call waiting can play a tone to notify you of the new call.



In Call Timer Adjust call timer settings.

You can set the following options for your display:

Time	displays the elapsed time for the current call
Off	no in-call display for the timer

INFO ON DEMAND Request and receive information from your service provider.



MESSAGES Listen to voicemail, send and receive text messages.



Your *voicemail* records voice messages from people who call you when you are unavailable. Voicemail messages are stored on the network rather than on your phone. When you receive a voicemail message, your phone displays **New VoiceMail** . See “Using Voicemail” on page 32.

Your phone can also receive *text* and *information services* messages which may include text, phone numbers, and URLs.

- Text messages are brief messages that you can enter, send, and receive (such as “Where are we meeting?”).

- Information services messages are broadcast or browser messages that you can only receive (such as stock updates or other news).

When you receive a new message, your phone displays **New Message**  and gives an alert. You must set up your message inboxes before you can use text or information services messages. See “Using Text Messages” on page 29.

OTHER

Car Settings Adjust hands-free car kit settings.

When your phone is connected to a car kit or headset, it can automatically answer calls after two rings. You can route your calls directly to a connected car kit or headset.



Headset Adjust headset settings.

Initial Setup Set several basic phone options:

Animation	switches on and off smooth scrolling within and between text fields (off conserves the battery)
Auto PIN Dial	automatically dials your PIN
Battery Save	conserves power (if available)
Auto Redial	automatically redials calls that fail due to network conditions
Backlight Display	changes the backlight display, which usually changes based on the amount of ambient light

DTMF	switches DTMF tones to long or short form
Language	sets the language for phone menus
Master Clear	performs master reset and clears all user-selectable options, resettable timer, recent call lists, and phonebook
Master Reset	resets all options back to their original factory settings <i>except</i> for the unlock and security codes
Scroll	tells the cursor to stop or wrap around when it reaches the top or bottom of a list in the display
Status Light	turns the status light off (to conserve battery power) and on
Time and Date	set the phone's time and date
Zoom	switches to three or four lines of display

Network View and adjust your phone's network settings.

Your service provider registers your phone to a network. You may need to change the network registration to do things like connecting to a TTY device or using your phone as a wireless modem.

Personalize Set several personal phone options:

Banner	changes the text displayed in the idle state
--------	--

Greeting	changes the text displayed when you turn on your phone
Keys	changes the functions of the soft keys in the idle state (see “Customizing the Soft Key Functions” on page 66)
Main Menu	changes the order of the main menu (see “Customizing the Order of Menu Items” on page 65)
Quick Dial	changes quick dial numbers

PHONE STATUS

Battery Meter View a detailed battery charge meter.

Credit Info Prepay users can view current credit information.

If you use a prepay option, you can view the credit available, its expiration date, and the date of the last deposit.



My Tel. No. Change the way your phone number displays.

Other Information view specifications for your phone’s features (if available).

Phone: Line 1/2 Change the active phone line (on dual line phones) to place or receive calls from either of the available numbers.

PHONEBOOK Open the phonebook list, where you can dial or store numbers.

To store names and phone numbers in your phonebook, see “Storing an Entry in the Phonebook” on page 25.

You can dial phonebook entries by selecting them from the phonebook list. You can also perform several other tasks:

- check your phonebook's capacity to see how many entries you have used and how many more are available
- tell your phone to sort your phonebook list by speed dial number (the standard), name, or Voice Dial
- use PIM (Personal Information Management) software to synchronize your phone with a computer, so you can edit phonebook entries on your phone and on the computer

QUICK DIAL Dial pre-programmed customer service numbers.



Your wireless service provider may program one or more quick dial numbers into your phone. These numbers usually include the customer service number, and you can dial them by selecting them from the quick dial list.

Note: Your service provider may use a different name for this feature.

RADIO Tune, store presets, and listen to AM/FM radio stations.

RECENT CALLS

Call Times View call timers.

You can view five timers that track time spent on dialed calls, received calls, and all calls. See “Call Timers” on page 66.

Dialed Calls View a list of recently dialed calls.

Your phone keeps a list of phone numbers from calls you recently dialed (even if the calls did not connect). The list is

sorted from newest to oldest. Each entry tells you the person's name and number (if available) and whether or not the call connected.

Notepad Call or store the last number entered from the keypad.

You can use this notepad to view the last number you entered, even if you did not call the number.

Received Calls View a list of recently received calls.

Your phone keeps a list of the numbers from calls you recently received (even if you did not answer). The list is sorted from newest to oldest. Each entry tells you the person's name and number (if available) and whether or not the call connected.

RING/VIBRATE See “Ring/Vibrate” on page 62.

Alert Select a type of ring or vibration alert for incoming calls and messages.

Detail Change details about the type of ring or vibration alert you select.

SECURITY

Lock Application Lock and unlock specific phone applications (such as phonebook and datebook) so that users must enter the unlock code to use them.

Lock Keypad Lock and unlock your keypad. See “Locking and Unlocking Your Phone” on page 33.

New Passwords Change your unlock code (originally set to 1234) or your security code (originally set to 000000).

Phone Lock Lock and unlock your phone. See “Locking and Unlocking Your Phone” on page 33.

Restrict Calls Restrict incoming and outgoing calls.

You can stop all outgoing or incoming calls, or you can restrict them to the numbers stored in your phonebook.

SHORTCUTS Create keypad or voice shortcuts to menu features.

See “Shortcuts” on page 64.

VOICENOTES Record messages and phone calls using your voice key. See “VoiceNotes” on page 55.

You can view, play back, lock, and delete VoiceNotes in your VoiceNote list.

Conference Call



To talk to more than one person on a call, you can make a conference call. Call the first person, call the second person, then link the two calls together.

Press	To
keypad keys	enter the first person's number
	dial the call
keypad keys	enter the next person's number

Press	To
	dial the call Your phone displays  next to the active call and  next to the first call (on hold).
Link ()	connect the two calls
	end the entire call

VoiceNotes

VoiceNotes allow you to record personal messages or phone calls. You can play them back at any time.

Recording a VoiceNote

There are no pre-recorded VoiceNotes on your phone when you receive it. To record a VoiceNote:

Find the Feature  > VoiceNotes

Do This	Result
Press the voice key and hold for one second.	A tone sounds in the earpiece and the phone displays the recording message.
Continue holding the voice key, and speak your voice message into the phone.	The phone records the message and displays a recording timer.


Do This	Result
Release the voice key to stop recording.	The phone displays the VoiceNotes list number and the total recording time.

Viewing the VoiceNotes List

The VoiceNotes list shows all your VoiceNotes along with other important information and features.

Find the Feature

 > VoiceNotes



New VoiceNote appears at the end of the list or by itself if no VoiceNotes are stored. Select **New VoiceNote** to view instructions on how to record a new VoiceNote.

Playing a VoiceNote

To play a recorded VoiceNote:


Find the Feature  > VoiceNotes

Press	To
	highlight VoiceNote for playback
PLAY ()	play a VoiceNote

Tip: You can play a VoiceNote while taking a call. It won't be transmitted to the other party.


Playback Screen

While the VoiceNote is playing, the playback screen is displayed.



VoiceNote Keys

While playing back a VoiceNote, use these keys to do the following:



Datebook


The datebook lets you schedule and organize appointments and keeps track of special events. It can display events for the week, a day, or details for a specific event.

Open the datebook to schedule or see events.

Find the Feature  > Datebook

Datebook Views

When you open the datebook, your phone displays a calendar for the week.




Lines or filled in boxes under each day indicate that events have been scheduled.

Press	To
⌂ or #	scroll left or right to past or future days
⬆ or ⬇	scroll up or down
VIEW (👁)	to open a specific day
MENU	to display the datebook sub-menu


Day View

Press **View** (👁) to view the day's events. You can store, edit, view, copy, and delete any event from the day view.



Event View

Press **View** (⌂) to open the detailed event view. You can edit, copy, and delete events from the event view. Event details include call alerts, times, days, and other event data.



Storing a New Event

Find the Feature **MENU** > Datebook > New

Press	To
SELECT (⌂)	open the event entry form
keypad keys	enter the event name
⏮ ⏭	move from one entry field to the next
	Once you reach a field, complete the event details. A title is required. Other fields include time, duration, date, repeating events, and alarms.

Press	To
DONE (⌂)	store the new event and return to the week view

Configuring Settings

You can adjust a wide variety of phone settings and configure the phone to suit your needs.

Ring/Vibrate

Your phone rings or vibrates when you have incoming calls or other events. You can customize the ring and apply it to all events or select different ring styles for specific events.

Selecting a Ring/Vibration for All Events

Find the Feature  > Setting > Ring/Vibrate > Alert

Press	To
	scroll to and select a ring or vibration
SELECT (⌕)	select a type
	The phone displays the Changed: Alert message.

Selecting a Ring/Vibration for Specific Events

When you select a ring/vibration type for a *specific* event, it overrides the ring set for *all* events.

Find the Feature  > Settings > Ring/Vibrate
> *alert type* Detail

Press	To
	scroll to the event that should have a special alert
SELECT ()	select the event The phone displays the Alert menu.
	scroll to the alert you want
SELECT ()	select the alert The phone displays the Changed: <i>event alert</i> message.

Canceling the Ring or Vibrate Alert

While the phone is ringing:

Press	To
 or IGNORE ()	cancel the ring or vibrate alert

Depending on your phone configuration and the type of subscription you have with your service provider, the call may be forwarded or the calling party may receive a busy signal.

Shortcuts

You can create shortcuts to mark frequently used menu items. There are no default shortcuts.

Setting Up Shortcuts

You can set up a shortcut from any highlighted item on the phone, except for items in a context-sensitive menu or items that are grouped together in a form.

Available Shortcuts

Type	Example
data object	Phonebook entry or text message
list	alarm setting options
highlighted item	Voicemail menu item
meter	Battery Meter
editors	time or date editor
form	blank form, such as new Phonebook entry
value	time setting for the backlight
browser service	web page
SIM Toolkit applications	SIM Toolkit initial screen

Creating Shortcuts

Find the Feature



> the item to which you want to assign a shortcut

Do This	Result
Press and hold .	The phone displays: Assign Shortcut " <i>Item</i> " to key no: #? where <i>Item</i> is the name of the item you selected, and # is the number of the next available shortcut.
Press OK ().	The phone confirms the new shortcut.

Customizing the Order of Menu Items

You can customize the order of the items in your phone's main menu, depending upon your usage.

Find the Feature



> Settings > Other Settings
> Personalize > Main Menu

Press	To
SELECT ()	open the main menu
 	scroll to the menu item you want to want to move
GRAB ()	grab the menu item you want to move
 	move the item up or down the menu

Customizing the Soft Key Functions

Find the Feature  > Settings > Other Settings
> Personalize > Keys

Call Timers

Network connection time is the elapsed time, in one-minute intervals, from the moment you connect to your service provider's network to the moment you end the call by pressing **END**. The time includes busy signals and ringing.

You can view the approximate network connection time elapsed during the following calls:

Timer	Records time spent on
Last Call	your last call
Dialed Calls	dialed calls since last reset
Received Calls	received calls since last reset
All Calls	all calls since last reset
Lifetime	all calls

Note: The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your wireless service provider. For billing information, please contact your service provider directly.

Find the Feature



> Recent Calls > Call Times

To view the timer:

Press	To
	scroll to the timer
Select ()	display the timer

To reset the timer:

Press	To
Reset ()	reset the time (if available)
Yes ()	confirm the reset

Troubleshooting



Question	Answer
I pressed the power button, but nothing happened. What's wrong with my phone?	Be sure to press and hold the power key until the display appears and you hear an audible alert. If nothing still happens, check that a charged battery is installed. For more information about battery, see “Battery” on page 11.
The display says, “Locked.” How do I unlock my phone?	Enter the factory-preset unlock code, 1234, or the last four digits of your wireless number. Also see “Locking and Unlocking Your Phone” on page 33. If all else fails, call your service provider (the company that sends you your monthly wireless bill).

Question	Answer
My battery didn't last as long as I expected. What can I do to extend battery life?	Your battery's "talk time" and "standby time" are relative measurements of the battery's capacity. The more you talk on the phone, the less standby time you have, and vice versa. To get the most from your battery, allow it to charge fully. To charge the battery to 100% of its capacity, leave it in the charger for an extra hour after the charger's light turns green. You can also turn off the status light to extend battery life. Use only Motorola approved batteries that are compatible with your phone. Exposing your battery to extreme temperatures—below -10°C (14°F) or above 45°C (113°F)—can shorten battery life. Batteries are especially sensitive to high temperatures. As a good rule, always take your phone with you when you leave your car.

Question	Answer
I tried to place a call and received a fast busy signal.	The wireless system did not process your call. For example, the wireless system may be overloaded with call attempts. To redial, press END before ending your call attempt, or press SND and try the call again later. See “Redialing a Number” on page 14.
I tried to place a call and received an alternating high/low tone.	Your call did not reach the wireless system. You may have dialed the number too soon after turning the phone on. Wait until the phone display says <i>Ready</i> before placing a call. An alternating tone may also indicate that your phone’s signal is blocked. Make sure you are clear of any obstructions such as bridges, parking garages, or tall buildings.

Question	Answer
I plugged the data cable into my phone but my phone did not beep. How do I know if the data cable is ready to go?	(This text was used in the TDMA Kool 99 user guide. Does it apply to synergy?) The beep indicates that you are setup correctly. If you did not hear the beep, the first thing to check is that your phone is data capable. To do so, see “Using Data Features” on page xx. Next, make sure that both ends of the data cable are connected—the smaller end to your phone and larger to your computer. Also, check the model number of the cable to be sure you have the right one. Look for SYN7464 printed on the cable. If all of the above checks out, your computer may have deactivated the port to save power. Try opening an application that uses the port, like a fax or dial-up application, and your computer will automatically activate the port.
My phone was stolen. What should I report and to whom?	Report a stolen phone to the police and to your service provider—the company that sends you your monthly wireless service bills.

Question	Answer
My phone beeped when I attached the data cable but my fax and data applications don't work at all. What's wrong?	(This text was used in the TDMA Kool 99 user guide. Does it apply to synergy?) You must be in an area with digital coverage. Check your phone's display for the digital icon  to be sure you're in a digital coverage area. Some wireless networks may not support data or fax transmission. If you see the digital indicator, but you are roaming on an unfamiliar network, this may be the case. Also, remember that data and fax transmission usually requires a subscription. Call your service provider for more information.
When sending data with the data cable, why does the computer show a connection rate of 19200 Kbps?	(This text was used in the TDMA Kool 99 user guide. Does it apply to synergy?) 19200 is the rate of the connection between your computer and the phone. The rate of the connection between your phone and the network is displayed on your phone, and will be either 14400 or 9600.

Question	Answer
I can't end my data call by closing the application on my computer. What can I do?	(This text was used in the TDMA Kool 99 user guide. Does it apply to synergy?) If necessary, try pressing SND on the phone. Also try disconnecting the cable or turning off the phone. If possible, always close the connection through your computer. These alternative methods may disrupt the application on your computer.
I launched the Browser but the display says: Service Not Available. What is wrong?	(This text was used in the TDMA Kool 99 user guide. Does it apply to synergy?) You are in an area without service. If you have wireless service, look in the display for the Digital indicator. If you don't see it, you may have only Analog service or no service at all. If you do see the Digital indicator, you may be connected to digital network that does not support Internet access.
I launched the Browser but the display says: Data Server Unavailable. What is wrong?	(This text was used in the TDMA Kool 99 user guide. Does it apply to synergy?) Try again in a few minutes. The servers may be temporarily busy.



**The U.S. Food and Drug
Administration's Center for Devices
and Radiological Health Consumer Update
on Mobile Phones**

FDA has been receiving inquiries about the safety of mobile phones, including cellular phones and PCS phones. The following summarizes what is known—and what remains unknown—about whether these products can pose a hazard to health, and what can be done to minimize any potential risk. This information may be used to respond to questions.

Why the concern?

Mobile phones emit low levels of radio frequency energy (i.e., radio frequency radiation) in the microwave range while being used. They also emit very low levels of radio frequency energy (RF), considered non-significant, when in the stand-by mode. It is well known that high levels of RF can produce biological damage through heating effects (this is how your microwave oven is able to cook food). However, it is not known whether, to what extent, or through what mechanism, lower levels of RF might cause adverse health effects as well. Although some research has been done to address these questions, no clear picture of the biological effects of this type of radiation has emerged to date. Thus, the available science does not allow us to conclude that mobile phones are absolutely safe, or that they are unsafe. However, the available scientific evidence does not demonstrate any adverse health effects associated with the use of mobile phones.

What kinds of phones are in question?

Questions have been raised about hand-held mobile phones, the kind that have a built-in antenna that is positioned close to the user's head during normal telephone conversation. These types of mobile phones are of concern because of the short distance between the phone's antenna—the primary source of the RF—and the person's head. The exposure to RF from mobile phones in which the antenna is located at greater distances from the user (on the outside of a car, for example) is drastically lower than that from hand-held phones, because a person's RF exposure decreases rapidly with distance from the source. The safety of so-called “cordless phones,” which have a base unit connected to the telephone wiring in a house and which operate at far lower power levels and frequencies, has not been questioned.

How much evidence is there that hand-held mobile phones might be harmful?

Briefly, there is not enough evidence to know for sure, either way; however, research efforts are on-going. The existing scientific evidence is conflicting and many of the studies that have been done to date have suffered from flaws in their research methods. Animal experiments investigating the effects of RF exposures characteristic of mobile phones have yielded conflicting results. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. In one study, mice genetically altered to be predisposed to developing one type of cancer developed more than twice as many such cancers when they were exposed to RF energy compared to

controls. There is much uncertainty among scientists about whether results obtained from animal studies apply to the use of mobile phones. First, it is uncertain how to apply the results obtained in rats and mice to humans. Second, many of the studies that showed increased tumor development used animals that had already been treated with cancer-causing chemicals, and other studies exposed the animals to the RF virtually continuously—up to 22 hours per day.

For the past five years in the United States, the mobile phone industry has supported research into the safety of mobile phones. This research has resulted in two findings in particular that merit additional study:

- 1.** In a hospital-based, case-control study, researchers looked for an association between mobile phone use and either glioma (a type of brain cancer) or acoustic neuroma (a benign tumor of the nerve sheath). No statistically significant association was found between mobile phone use and acoustic neuroma. There was also no association between mobile phone use and gliomas when all types of types of gliomas were considered together. It should be noted that the average length of mobile phone exposure in this study was less than three years.

When 20 types of glioma were considered separately, however, an association was found between mobile phone use and one rare type of glioma, neuroepitheliomatous tumors. It is possible with multiple comparisons of the same sample that this association occurred by chance. Moreover, the risk did

not increase with how often the mobile phone was used, or the length of the calls. In fact, the risk actually decreased with cumulative hours of mobile phone use. Most cancer causing agents increase risk with increased exposure. An ongoing study of brain cancers by the National Cancer Institute is expected to bear on the accuracy and repeatability of these results.¹

2. Researchers conducted a large battery of laboratory tests to assess the effects of exposure to mobile phone RF on genetic material. These included tests for several kinds of abnormalities, including mutations, chromosomal aberrations, DNA strand breaks, and structural changes in the genetic material of blood cells called lymphocytes. None of the tests showed any effect of the RF except for the micronucleus assay, which detects structural effects on the genetic material. The cells in this assay showed changes after exposure to simulated cell phone radiation, but only after 24 hours of exposure. It is possible that exposing the test cells to radiation for this long resulted in heating. Since this assay is known to be sensitive to heating, heat alone could have caused the abnormalities to occur. The data already in the literature on the response of the micronucleus assay to RF are conflicting. Thus, follow-up research is necessary.²

FDA is currently working with government, industry, and academic groups to ensure the proper follow-up to these industry-funded research findings. Collaboration with the Cellular Telecommunications Industry Association (CTIA) in particular is

expected to lead to FDA providing research recommendations and scientific oversight of new CTIA-funded research based on such recommendations.

Two other studies of interest have been reported recently in the literature:

1. Two groups of 18 people were exposed to simulated mobile phone signals under laboratory conditions while they performed cognitive function tests. There were no changes in the subjects' ability to recall words, numbers, or pictures, or in their spatial memory, but they were able to make choices more quickly in one visual test when they were exposed to simulated mobile phone signals. This was the only change noted among more than 20 variables compared.³
2. In a study of 209 brain tumor cases and 425 matched controls, there was no increased risk of brain tumors associated with mobile phone use. When tumors did exist in certain locations, however, they were more likely to be on the side of the head where the mobile phone was used.

Because this occurred in only a small number of cases, the increased likelihood was too small to be statistically significant.⁴

In summary, we do not have enough information at this point to assure the public that there are, or are not, any low incident health problems associated with use of mobile phones. FDA continues to work with all parties, including other federal agencies and industry, to assure that research is undertaken to

provide the necessary answers to the outstanding questions about the safety of mobile phones.

What is known about cases of human cancer that have been reported in users of hand-held mobile phones?

Some people who have used mobile phones have been diagnosed with brain cancer. But it is important to understand that this type of cancer also occurs among people who have not used mobile phones. In fact, brain cancer occurs in the U.S. population at a rate of about 6 new cases per 100,000 people each year. At that rate, assuming 80 million users of mobile phones (a number increasing at a rate of about 1 million per month), about 4800 cases of brain cancer would be expected each year among those 80 million people, whether or not they used their phones. Thus it is not possible to tell whether any individual's cancer arose because of the phone, or whether it would have happened anyway. A key question is whether the risk of getting a particular form of cancer is greater among people who use mobile phones than among the rest of the population. One way to answer that question is to compare the usage of mobile phones among people with brain cancer with the use of mobile phones among appropriately matched people without brain cancer. This is called a case-control study. The current case-control study of brain cancers by the National Cancer Institute, as well as the follow-up research to be sponsored by industry, will begin to generate this type of information.

What is FDA's role concerning the safety of mobile phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as mobile phones before marketing, as it does with new drugs or medical devices. However, the agency has authority to take action if mobile phones are shown to emit radiation at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of mobile phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions at this time, FDA has urged the mobile phone industry to take a number of steps to assure public safety. The agency has recommended that the industry:

- support needed research into possible biological effects of RF of the type emitted by mobile phones
- design mobile phones in a way that minimizes any RF exposure to the user that is not necessary for device function
- cooperate in providing mobile phone users with the best possible information on what is known about possible effects of mobile phone use on human health

At the same time, FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of mobile phone safety to ensure a coordinated effort at the federal level. These agencies are:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Health and Safety Administration
- National Telecommunications and Information Administration

The National Institutes of Health also participates in this group.

In the absence of conclusive information about any possible risk, what can concerned individuals do?

If there is a risk from these products—and at this point we do not know that there is—it is probably very small. But if people are concerned about avoiding even potential risks, there are simple steps they can take to do so. For example, time is a key factor in how much exposure a person receives. Those persons who spend long periods of time on their hand-held mobile phones could consider holding lengthy conversations on conventional phones and reserving the hand-held models for shorter conversations or for situations when other types of phones are not available.

People who must conduct extended conversations in their cars every day could switch to a type of mobile phone that places more distance between their bodies and the source of the RF, since the exposure level drops off dramatically with distance. For example, they could switch to:

- a mobile phone in which the antenna is located outside the vehicle
- a hand-held phone with a built-in antenna connected to a different antenna mounted on the outside of the car or built into a separate package
- a headset with a remote antenna to a mobile phone carried at the waist

Again, the scientific data do not demonstrate that mobile phones are harmful. But if people are concerned about the radio frequency energy from these products, taking the simple precautions outlined above can reduce any possible risk.

Where can I find additional information?

For additional information, see the following websites:

Federal Communications Commission (FCC) RF Safety Program (select “Information on Human Exposure to RF Fields from Cellular and PCS Radio Transmitters”):

<http://www.fcc.gov/oet/rfsafety>

World Health Organization (WHO) International Commission on Non-Ionizing Radiation Protection (select Qs & As): <http://www.who.int/emf>

United Kingdom, National Radiological Protection Board: <http://www.nrpb.org.uk>

Cellular Telecommunications Industry Association (CTIA): <http://www.wow-com.com>

U.S. Food and Drug Administration (FDA) Center for
Devices and Radiological Health:

<http://www.fda.gov/cdrh/consumer/>

1. Muscat et al. Epidemiological Study of Cellular Telephone Use and Malignant Brain Tumors. In: State of the Science Symposium;1999 June 20; Long Beach, California.
2. Tice et al. Tests of mobile phone signals for activity in genotoxicity and other laboratory assays. In: Annual Meeting of the Environmental Mutagen Society; March 29, 1999, Washington, D.C.; and personal communication, unpublished results.
3. Preece, AW, Iwi, G, Davies-Smith, A, Wesnes, K, Butler, S, Lim, E, and Varey, A. Effect of a 915-MHz simulated mobile phone signal on cognitive function in man. Int. J. Radiat. Biol., April 8, 1999.
4. Hardell, L, Nasman, A, Pahlson, A, Hallquist, A and Mild, KH. Use of cellular telephones and the risk for brain tumors: a case-control study. Int. J. Oncol., 15: 113-116, 1999.

FDA020400

Index

A

- accessories 10
- alert
 - canceling 63
 - event alert 63
 - setting 62
- alert indicator
 - defined 42–43
 - illustration 41
- animation 49
- auto PIN dial 49
- automatic redial
 - activating 49
 - using 35

B

- backlight display feature 49
- banner feature 50
- battery
 - charging 12
 - conserving power 49, 50
 - disposal 45
 - installing 11–12
 - maximizing battery life 44–45, 69

- battery level indicator
 - defined 42
 - illustration 41
- battery meter 51
- battery save feature 49
- block cursor 21
- browser 47
- busy signal 70

C

- call
 - adding digits to phone number 38
 - alert, canceling 63
 - alert, setting 62
 - answering 14
 - answering options 47
 - attaching digits to precede phone number 38
 - calling card 38
 - dialed calls list 39, 52
 - emergency number 37
 - ending 14
 - event alert, setting 63
 - hold, placing call on 39
 - in call timer 48

- call (continued)
 - international access code 38
 - muting 39
 - placing 13
 - received calls list 39, 53
 - receiving 14
 - redialing last number 14
 - restricting 54
 - unanswered call 36
 - voice dial 39
 - call timers
 - defined 66–67
 - resetting 67
 - viewing 52, 67
 - call waiting
 - activating/deactivating 48
 - using 36
 - caller ID
 - features 35
 - calling card calls
 - dialing 38
 - car settings 49
 - codes. *See* passwords
 - conference call 54–55
 - connecting to external device
 - 47
 - credit information 51
 - customer service 52
- D**
- data calls 47
 - date, setting 50
 - datebook
 - adding an event 61–62
 - calendar 59–60
 - day view 60
 - defined 59
 - event view 61
 - dialed calls list 39, 40, 52
 - display
 - greeting 51
 - idle text 50
 - zoom 50
 - DTMF tones
 - setting 50
 - using 39
- E**
- earpiece
 - illustration 40
 - volume, adjusting 44
 - emergency number 37
 - end key 40
 - menu functions 15
 - ending a call 14
 - Enter Unlock Code message
 - 34

F

- fax calls 47
- fixed dial
 - storing entry 26–29

G

- greeting feature 51

H

- hands-free car kit settings 49
- hands-free mode 39
- headset
 - adjusting settings 49
- hold, placing call on 39
- holster 10

I

- I-beam cursor 21
- in call timer 48
- in use indicator
 - defined 42
 - illustration 41
- Incoming Call message 35
- indicators
 - alert 41, 42–43
 - battery level 41, 42
 - in use 41, 42
 - message waiting 41, 42

indicators (continued)

- roam 41, 42
 - signal 41, 43
 - signal strength 41
 - voice message waiting 41, 42
- info on demand 48
- international access code 38
- IrDA link 47
- iTAP text entry 24–25

K

- key
 - end 15, 40
 - left soft key 15, 66
 - menu 15
 - power 40
 - right soft key 15, 66
 - scroll 40
 - scroll keys 15
 - send 40
 - soft 40
 - voice 27–28, 40, 55–56

L

- language 50
- left soft key
 - customizing 66
 - menu functions 15

- lock
 - keypad 34
 - phone 33–34
- lock application feature 53
- M**
- making a call 13
- master clear 50
- master reset 50
- menu
 - customizing 65–66
 - diagram 46
 - entering text 22–25
 - features 47–54
 - language, setting 50
 - locking applications 53
 - navigating 15–18
 - rearranging features 65–66
 - scroll feature, setting 50
 - shortcuts 64–65
 - using features 19–25
- menu key 15
- message
 - dialing number from 31
 - inbox setup 29–30
 - information services 48
 - reading 31
 - text 29–31, 48
 - voicemail 32, 48
- message waiting indicator
 - defined 42
 - illustration 41
- Missed Calls message 37
- muting a call 39
- my telephone number 39, 51
- N**
- network settings 50
- notepad 53
- O**
- one-touch dialing
 - using 39
- P**
- passwords
 - changing 54
 - if you forget a password 34
- phone
 - accessories 10
 - active phone line, changing 51
 - alert, canceling 63
 - connecting to an external device 47
 - date, setting 50
 - feature specifications 51

- phone (continued)
 - keypad, locking/unlocking 34
 - language, setting 50
 - locking 33–34
 - muting a call 39
 - network settings 50
 - one-touch dialing 39
 - passwords 34, 54
 - security code 34
 - speed dial, using 38
 - time, setting 50
 - turning on/off 12
 - unlock code 34
 - unlocking 13, 33–34
 - voice dial 39
 - phone number
 - adding digits 38
 - attaching preceding digits 38
 - viewing your own 14, 39
 - phonebook
 - features 51–52
 - fields 26
 - number type icon 26
 - one-touch dialing 39
 - speed dial, using 38
 - speed number 26, 28
 - storing an entry 25–29
 - phonebook (continued)
 - Voice Name entry 27–28
 - Voice Name icon 26
 - PIN code
 - dialing automatically 49
 - placing a call 13
 - power key 12, 40
- Q**
- quick dial
 - setting number 51
 - using 52
- R**
- radio 52
 - received calls list 39, 53
 - receiving a call 14
 - redial
 - automatic redial 35
 - last number 14
 - restrict calls 54
 - right soft key
 - customizing 66
 - menu functions 15
 - ring/vibrate alert
 - canceling 63
 - event alert 63
 - setting 62

ringer
 setting 62
 volume, adjusting 44
roam indicator
 defined 42
 illustration 41

S

scroll feature 50
scroll keys 15, 40
security code 34
send key 40
shortcuts 64–65
signal indicator
 defined 43
 illustration 41
signal strength indicator
 defined 41
 illustration 41
SIM PIN code
 dialing automatically 49
soft key 40
soft keys 15, 66
speakerphone 39
speed dial 38
speed number
 defined 26
 selecting 28

status light 40, 43
 activating/deactivating 50

T

text
 block cursor 21
 character chart 23
 entering from keypad 22–25
 I-beam cursor 21
 iTAP text entry 24–25
text message 29–31, 48
time, setting 50
timers
 defined 66–67
 resetting 67
 viewing 52, 67
tone, alternating high/low 70

U

Unknown message 37
unlock
 keypad 34
 phone 33–34
unlock code 34
unlocking
 phone 13

V

- voice dial 39
- voice key 40
 - recording Voice Name 27–28
 - recording VoiceNote 55–56
 - voice dial 39
- voice message waiting indicator
 - defined 42
 - illustration 41
- Voice Name
 - phonebook icon 26
 - recording 27–28
- voicemail 32, 48
- VoiceNotes
 - key controls 58
 - playback screen 57
 - playing 57–58
 - recording 55–56
 - viewing VoiceNotes list 56
- volume
 - earpiece 44
 - ringer 44
- volume keys 44

Z

- zoom feature 50

Patent Information

Manufactured under one or more of the following U.S. patents:

4291475	4628529	4809356	4904549	5008925	5058136	5127040
4302845	4629829	4811377	4904992	5010309	5059885	5127042
4312074	4633141	4811404	4905288	5010570	5060264	5127100
4365221	4636593	4817157	4905301	5014294	5063340	5128834
4369516	4636741	4827507	4912602	5014346	5065408	5133010
4369520	4648125	4829543	4916262	5017856	5067139	5134717
4369522	4649543	4831647	4918431	5018188	5070310	5140286
4374370	4654655	4843621	4918732	5020076	5077757	5140635
4378603	4680787	4845772	4922178	5020091	5077790	5142551
4390963	4704588	4851966	4941203	5020092	5081674	5142696
4398265	4711361	4852090	4942570	5020093	5083304	5144533
4400584	4715063	4860336	4945570	5023580	5087004	5146620
4400585	4717884	4860341	4956854	5023866	5093632	5148471
4434461	4730195	4868576	4959851	5023911	5095503	5148473
4455534	4731813	4870686	4963812	5025387	5107487	5150075
4486624	4736277	4872196	4964121	5027388	5109400	5150359
4491972	4737976	4873683	4970475	5028083	5111162	5150384
4523155	4741018	4876552	4972355	5028859	5113400	5151643
4546329	4742562	4876656	4972432	5029233	5113436	5152006
4574243	4761621	4876740	4972455	5036532	5117073	5152007
4581602	4764737	4879533	4975808	5038253	5117441	5153590
4581749	4775998	4885553	4977589	5040127	5117449	5157693
4585957	4791527	4887050	4977616	5042071	5117450	5160898
4593155	4794489	4890199	4979207	5045824	5121047	5162144
4594657	4797929	4896124	4984219	5053924	5121288	5163159
4602218	4797947	4896361	4984290	5055800	5121412	5164652
4605987	4798975	4897873	4989230	5055802	5122480	5166596
4616314	4802236	4903326	4992753	5055803	5122722	5166642
4617520	4803726	4903327	4996529	5057762	5124889	5168522

5170173	5222078	5276707	5359696	5428836	5486843	5530399
5170485	5222104	5276913	5361400	5430416	5487184	5530922
5170492	5222251	5276915	5363071	5432017	5488649	5533119
5175729	5230007	5278832	5365549	5434947	5490177	5535258
5175759	5230093	5278994	5366826	5436802	5491739	5535434
5175874	5233506	5280630	5367538	5438684	5493198	5539360
5182749	5233633	5280637	5367558	5442680	5493700	5542016
5185566	5235492	5280644	5371791	5444764	5493714	5542103
5185790	5237257	5285443	5373101	5446763	5495206	5542106
5187640	5237570	5287013	5375143	5446766	5495208	5542116
5187809	5239127	5287553	5375258	5448763	5497126	5544250
5192924	5241545	5287555	5379324	5448770	5497382	5546275
5193223	5241548	5287556	5381114	5448771	5497383	5546380
5195106	5241592	5289505	5384825	5453997	5499273	5551078
5195108	5241688	5297142	5392000	5457744	5499394	5551627
5198887	5242767	5299232	5392023	5459640	5499397	5553137
5200655	5243355	5301365	5392331	5459774	5502437	5553376
5201069	5247544	5308716	5396654	5461643	5504494	5554996
5203009	5247565	5321705	5401927	5463351	5504812	5555550
5203012	5249302	5321737	5402447	5463406	5506490	5557743
5203013	5251331	5321847	5402448	5463628	5508709	5559471
5203021	5255292	5323421	5404580	5463646	5509048	5559522
5204977	5257414	5325405	5404582	5463674	5510693	5559806
5205751	5259005	5325429	5406146	5463688	5511235	5561436
5210793	5260170	5327578	5406562	5463694	5513078	5561437
5211581	5260988	5327642	5408693	5465409	5513996	5561852
5212815	5261119	5331123	5410275	5465412	5519303	5565881
5212826	5262710	5333153	5410741	5469177	5519346	5566224
5214675	5263052	5336984	5414711	5471671	5519506	5568548
5214774	5263055	5338909	5420759	5475752	5519777	5570453
5216389	5265271	5343213	5424689	5477192	5524276	5572223
5220290	5267230	5349588	5428362	5485506	5526398	5572224
5220936	5276588	5351245	5428820	5485513	5528666	5574976

5577267	5630210	5691947	5742894	5798716	5835535	5877633
5577268	5630213	5692046	5745116	5799011	5835785	5878075
5583520	5630215	5692101	5745566	5799256	5838202	5878209
5584054	5631538	5696497	5745848	5801513	5841851	5878336
5586146	5633484	5696821	5747970	5801567	5842122	5878353
5588041	5633786	5699070	5748727	5802111	5844943	5880637
5589796	5634202	5699389	5754141	5805992	5846094	5880646
5590177	5640690	5699408	5754455	5807012	5848072	5881377
5594778	5642368	5701130	5754583	5808585	5848152	5889737
5594951	5646576	5701244	5754645	5808586	5848356	5889768
5598129	5649306	5701589	5754956	5809020	5848718	5889859
5598431	5649309	5703470	5758271	5809419	5850440	5892410
5600341	5656914	5703539	5760714	5809421	5854549	5893036
5604050	5656917	5703909	5761300	5809430	5854785	5894597
5604468	5657418	5706019	5761610	5809433	5854972	5896054
5604787	5659601	5706313	5764100	5809544	5856763	5896261
5606332	5660945	5708445	5764111	5812093	5856766	5898933
5606560	5661433	5710862	5764730	5812542	5857148	5900829
5606730	5664973	5710987	5764743	5812590	5857192	5901347
5613229	5666429	5711001	5766794	5814798	5859522	5901357
5613863	5668871	5715520	5771182	5815507	5859567	5903825
5615233	5670912	5715524	5771471	5815570	5859890	5903852
5615259	5673001	5717307	5777521	5815804	5861853	5905956
5615260	5673003	5722052	5777856	5815805	5862460	5907418
5621763	5673287	5724004	5784368	5815807	5862493	5907615
5621766	5674326	5726983	5784419	5815820	5864799	5909102
5625316	5675591	5729221	5784585	5821820	5865487	5910944
5625683	5675702	5732350	5787128	5822726	5867063	5912648
5628001	5678201	5737327	5787577	5826224	5867127	5920549
5628057	5678221	5737685	5793315	5831826	5867140	5920550
5628089	5678227	5738954	5793866	5832080	5867510	5923007
5629979	5680063	5739792	5796822	5832388	5870670	5924044
5630159	5684384	5740525	5797101	5835006	5872744	5925835

5925942	5977916	6021332	D306583	D339335	D348071	D357457
5926119	5980268	D284759	D306594	D339336	D348250	D357680
5926503	5982881	D285439	D307271	D339337	D348427	D357681
5926751	5983082	D288432	D309301	D339564	D348470	D358148
5930268	5987012	D288683	D309451	D339578	D348665	D359052
5930288	5988577	D289156	D314173	D339581	D348666	D359734
5930299	5995050	D292578	D315330	D339582	D348668	D359735
5933330	5996178	D292920	D315346	D340709	D348674	D359959
5936516	5999115	D295627	D315543	D340710	D348880	D360398
5936972	5999821	D295973	D315559	D340711	D349273	D360632
5939939	5999832	D295975	D315565	D340906	D349701	D361070
5940452	6002922	D296187	D315907	D341589	D350113	D361763
5940746	6002937	D297734	D316417	D342248	D350348	D362840
5943027	6005498	D297735	D316859	D342663	D350349	D362852
5945852	6006104	D297736	D320780	D342729	D350350	D365094
5945964	6008636	D299136	D322783	D342730	D351375	D365817
5946395	6009168	D299137	D324024	D342741	D351840	D366872
5949020	6009309	D299232	D324388	D343173	D352497	D367640
5950131	6009325	D300742	D325028	D343615	D352503	D368479
5950139	6009336	D300827	D325029	D343616	D352946	D368696
5953413	6009552	D301473	D325032	D343834	D353131	D369162
5954817	6011699	D301476	D325583	D343835	D353361	D369359
5955700	6011784	D301883	D325915	D343836	D353587	D369797
5955999	6011959	D302015	D327061	D344087	D353588	D370016
5956626	6011961	D303656	D327062	D344271	D353591	D370463
5963848	6012634	D304189	D328302	D344444	D354055	D370672
5963876	6014376	D305427	D332261	D344511	D354062	D372237
5964858	6014552	D305717	D332785	D344512	D355181	D372481
5966101	6016312	D306015	D334746	D344945	D355895	D372703
5966667	6016422	D306163	D337332	D345977	D356084	D372896
5966671	6018584	D306293	D338012	D346785	D356309	D372919
5969545	6018651	D306299	D338887	D346786	D357224	D373585
5974042	6018671	D306441	D339127	D346798	D357249	D373764

D374013	D380751	D385888	D389478	D396472	D406191	D411535
D374014	D381021	D386175	D389488	D397337	D406586	D411843
D374227	D381664	D386494	D389641	D397689	D406695	D411844
D374424	D382537	D386757	D390221	D397694	D406812	D412000
D374872	D382538	D387054	D390222	D398926	D407063	D412487
D375732	D382872	D387055	D390509	D400161	D407685	D412709
D375733	D383115	D387199	D391567	D400165	D407708	D413893
D375734	D383748	D387346	D391955	D400204	D408401	D413898
D375932	D383749	D388078	D391966	D400209	D408402	D414159
D375935	D383759	D388079	D393470	D400496	D408418	D415122
D375952	D384080	D388080	D394256	D400526	D408783	D415499
D376127	D384662	D388081	D394423	D400527	D408815	D416226
D377792	D384951	D388082	D394425	D400874	D409186	D417224
D377934	D384952	D388424	D394433	D401554	D410459	D417449
D378366	D385271	D388429	D394438	D401929	D410460	D419155
D378911	D385283	D388430	D394439	D403265	D410929	D419290
D379558	D385555	D388775	D395301	D404397	D411165	D419565
D379624	D385873	D388783	D395302	D405080	D411196	PAT022500
D379981	D385874	D388793	D395431	D405782	D411202	
D379982	D385875	D389157	D395642	D405801	D411204	
D380468	D385877	D389476	D395875	D406098	D411507	

Other patents pending.