





Meet Your

XT2423-6



Put in the card(s) & power on



1 Insert the SIM tool into the hole next to the tray to pop out the tray.

Make sure you use the correct size SIM card and don't cut the SIM card.

2 Insert the SIM card(s) with the gold contacts down, then gently push the tray into the slot.

Add a microSD card (optional, sold separately) for additional storage.

3 Press and hold the power button to turn on your phone, then follow the prompts to get started.

Note: To turn off your phone, press the Power and Volume Up buttons at the same time.

Help & more

Get answers, updates, and info:

- **Help is here:** From the home screen, swipe up and tap **Settings > Help** to learn how to use your phone and get support.
- **Get more:** Get software, user guides, and more at www.motorola.com/mymotog.
- **Get apps:** Tap **Play Store** to browse and download apps.

Operational warnings. Obey all local restrictions when using mobile devices in public areas, such as hospitals, airplanes, or schools.

- **Potentially explosive areas:** Potentially explosive areas are often, but not always, posted and can include blasting areas, fueling stations, fueling areas (such as below decks on boats), fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders. Turn off your phone before entering such an area, and do not charge batteries. In such areas, sparks can occur and cause an explosion or fire.

- **Symbol key:** Your charger, phone, battery (if user-removable), phone display, user's guide, or packaging may contain symbols, defined as follows:

	Important safety information follows.		For indoor use only.
	Don't dispose of your battery or phone with your household waste.		Don't dispose of your battery or phone in a fire.
	Listening at high volume to music or voice through a headset or headphone may damage your hearing.		The package and paper products that came with your phone should be recycled.

Legal disclaimers. Features, services and applications are network dependent and may not be available in all areas; additional terms/charges may apply. Product specifications and other information contained in this guide are believed to be accurate at the time of release. Motorola reserves the right to correct or change any information without notice.

Arbitration. Your purchase is governed by a binding arbitration clause. For more information and how to opt-out, see the legal guide that came with your phone.

Copyright & trademarks. MOTOROLA, the stylized M logo, MOTO, and the MOTO family of marks are trademarks or registered trademarks of Motorola Mobility Holdings, LLC. Google, Android, Google Play and other related marks and logos are trademarks of Google LLC. microSD Logo is a trademark of SD-3C, LLC. USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum. All other product or service names are the property of their respective owners.

© 2023 Motorola Mobility LLC. All rights reserved.

Product ID: (Model XT2423-6)

Manual Number: XXXXXXXX-A

