




FRONT OF PHONE - SLIDE OPEN



BACK OF PHONE - SLIDE OPEN



FRONT OF PHONE



BACK OF PHONE



BACK OF PHONE WITH
BATTERY COVER REMOVED



LEFT & RIGHT SIDES OF PHONE



TOP & BOTTOM SIDES OF PHONE