

Meet your phone.

About your phone



NOTE: Devices and software are constantly evolving – the screen images and icons you see here are for reference only.

NOTE: Transform your phone into a movie projector, battery powerhouse and more, with <TBD>. <TBD> are sold separately.

Setting up your phone

Your phone already has a SIM card installed.

Optional: Insert a microSD card.

1. With the phone facing up, insert the tool that comes with your phone into the small hole on the card tray and pop out the tray.



2. Turn the tray over and insert the microSD card with the gold contacts facing up.



NOTE: The microSD card is sold separately.

3. Carefully insert the tray back in the phone.



Charge your phone

Before turning on your phone, charge it fully.

Insert the small end of the USB cable into the USB/charger port. Insert the other end into the power adapter, and plug the power adapter into an electrical outlet.



WARNING! Only use approved chargers with your device. Using incompatible chargers or tampering with the charging port could damage your device and void the warranty.

SAR

This product meets the applicable national or international RF exposure guidance (SAR guideline) when used normally against your head or, when worn or carried, at a distance of 1.0 cm from the body. The SAR guideline includes a considerable safety margin designed to assure the safety of all persons, regardless of age and health.

To view the SAR values for your phone, visit motorola.com/sar. To view additional SAR information on your phone, tap **Apps > Settings > Legal information > RF information**. To view the information on the web, visit motorola.com/rfhealth.

Motorola
Moto-Z
XT1650-03

by motorola



Using your phone


Turning your phone on/off

To turn your phone on, press and hold the **Power/Lock** button on the phone until the screen turns on.

To turn your phone off, press and hold the **Power/Lock** button and then tap **Power off**.


Locking/unlocking the screen

To turn on your screen, press the **Power/Lock** button. Then drag the lock icon  up to unlock it.




To turn off your screen and prevent accidental key presses, press the **Power/Lock** button. Your phone will also lock automatically if you don't use it for a while.

Home screen



Volume and interruptions

Press the side volume buttons up or down to select a ringer volume from high to vibrate .



To turn off some or all sounds, swipe the status bar down with two fingers and tap **Do not disturb**.

Advanced Calling

You can make High-Definition Voice and Video Calls, and surf the web while you talk on the phone, when you add Advanced Calling to your line. Visit verizonwireless.com/AdvancedCalling to learn how.

Copying content from your old phone

For help transferring contacts, photos, and other content from your old phone, visit verizonwireless.com/cloud.

Learning more

The **Help** app gives you tips, videos, and other information on how to use your phone, including:

-  Making calls
-  Voice mail
-  Sending texts
-  Getting apps
-  Taking photos
-  Accessibility settings

From your computer, visit verizonwireless.com/support.

Download a User Guide from verizonwireless.com/support, or call **1.800.734.5870** to order a copy.

Managing your account

My Verizon Mobile app

 Manage your account, track your usage, edit account information, pay your bill, and more.

International travel

 For features and rates when traveling outside the US, visit verizonwireless.com/international.

Customer service

 Call **1.800.922.0204**
Twitter **@VZWSupport**

Legal, safety and warranty information

To see legal, safety and warranty information for this phone, tap **Apps > Settings > Legal information** and select a topic. Or visit motorola.com/device-legal.

Additional information

Your wireless device and third party services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.

Hearing aid compatibility information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

© 2016 Verizon Wireless. All Rights Reserved.

Copyright & trademarks

MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Android, Google and other trademarks are owned by Google Inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. The microSD logo is a trademark of SD-3C, LLC. DROID is a trademark of Lucasfilm Ltd. and its related companies. Used under license. All other product or service names are the property of their respective owners.

© 2016 Motorola Mobility LLC.

Product ID: <TBD> by Motorola (Model XXXXXX)

Manual Number: 680XXXXXXX-A