

Locking and Unlocking Your Phone

You can lock your phone manually or set your phone to lock automatically whenever you turn it off. To use a locked phone, you must enter the unlock code. A locked phone still rings and/or vibrates for incoming calls/messages, *but you must unlock it to answer/read.*

You can make emergency calls on your phone even when it is locked.

Locking Your Phone Manually

Find the Feature



- > **Settings**
- > **Security**
- > **Code status**
- > **Phone lock**
- > **Lock now**

Press	To
1 keypad keys	enter your phone lock/unlock code if you want to lock the phone manually
2 OK ()	lock the phone

Tip: To unlock the phone, refer to the steps above.



Locking Your Phone Automatically

The phone will automatically be locked after you turn it off. Enter your phone code to unlock the phone when you power it on.

Find the Feature



- > **Settings**
- > **Security**
- > **Code status**
- > **Phone lock**
- > **Automatic lock** > **ON**



Setting and Changing Codes

You can set and change the following codes that block other people from using your phone and data in it.

PIN code	Lock your SIM card when you turn your phone off.
PIN2	Lock certain subscription-dependent features every time you use them.
Phone code	Lock your phone when you turn it off.
SIM lock	Lock your phone when you insert an unidentified SIM card.

Tip: Contact your service provider for those codes.

To set or change codes:

Find the Feature



- > **Settings**
- > **Security**
- > **Change code**

To activate/deactivate codes:

Find the Feature



- > **Settings**
- > **Security**
- > **Code status**

If You Forget Codes

If you forget your codes, contact your service provider.

If You Enter the Wrong PIN or PIN2 Code 3 Times in a Row



If you enter a wrong PIN or PIN2 code 3 times in a row, your phone prompts you to enter the PUK or PUK2 code to unblock your SIM card. For the PUK and PUK2 codes, contact your service provider.

Tip: The default phone code is “1234.” Please change the phone code after you receive your phone and keep it safely.


Setting Up Your Phone

Calibrating Your Finger Writing Recognition


When you use the A668 Finger Writing Recognition (FWR) functionality to write messages, add phonebook entries, or quickly launch specific phone features, such as **Ringing style**, if finding something fuzzy as the following conditions describe, it's time to calibrate your FWR feature. The following happen as the FWR technology is vulnerable to the environmental temperature, humidity and electric charge of fingers. Before you start to use this built-in FWR technology for the 1st time, it is recommended to calibrate it so that the FWR functionality will be able to read your input more accurately and precisely.




- #1: The display shows a spot before you touch the sensitive keypad.



- #2: The display shows your input only when you heavily write text on the keypad. Or the display shows a short stroke when you draw a long stroke when you draw a long stroke on the keypad.




- **#3:** A stroke you write on a specific part of the keypad appears in a different part of the display.



- **#4:** The display does not show the letter you write on the keypad. For example, write "y" on the keypad and the display shows "g."



Remedy: You have to calibrate the FWR functionality. (To activate, keep fingers or any objects off the keypad and in the idle display, press  > **Settings** > **Initial settings** > **Input mode** > **Finger writing settings** > **Calibration**.)



After you calibrate the FWR functionality and the conditions described above remain, please contact the local Motorola Customer Call Center personnel.

Note: Activating the FWR calibration option will not cause any impact on placing/answering calls or receiving/sending messages.



Adjusting the Backlight

You can set the amount of time that both the display and the keypad backlights remain on. You may also turn backlights off to extend battery life.

Find the Feature



- > Settings
- > Initial settings
- > Backlight

Adjusting Display Brightness

Find the Feature



- > Settings
- > Initial settings
- > Adjust brightness



	Press	To
1	 left/right	scroll to the desired display brightness
2	OK ()	select the display brightness

Adjusting Display Color

Find the Feature



- > Settings
- > Display
- > Color scheme

Setting Date and Time

To see date and time in both idle displays, set date and time 1st:

Find the Feature



- > Settings
- > Initial settings
- > Clock
- > Set date/time
- > Set the date/Set the time

You can choose to turn the default 24-hour time format off:

Find the Feature



- > Settings
- > Initial settings
- > Clock
- > 24-hour clock
- > OFF

You can also select a date format:

Find the Feature



- > Settings
- > Initial settings
- > Clock
- > Date format

To see date and time in both idle displays:

Find the Feature



- > Settings
- > Initial settings
- > Clock
- > Show clock
- > ON



You may specify a place and display the corresponding date and time:

Find the Feature



- > **Settings**
- > **Initial settings**
- > **Clock**
- > **Set date/time**
- > **Local time zone**

Setting Power-Off Time

You can let your phone turn off automatically in a specified time.

Find the Feature



- > **Settings**
- > **Auto power off**
- > **On**



Tip: Press  left/right to select a **Repeat type** for the power-off time setting.

Setting a Wallpaper Image

You can set a picture or animation as a wallpaper (background) image shown in your phone's internal and external displays.

Note: When you set an animation as a wallpaper image, only the 1st frame of the animation displays. Additionally, using the Dynamic Wallpapers may result in reduced battery standby times.

Find the Feature



- > **Settings**
- > **Display/External display**
- > **Wallpaper**

Setting a Screen Saver Image

You can set a picture or animation as a screen saver image shown in your phone's internal and external displays. The screen saver image plays for 3 minutes (the default, but it depends on marketing areas) when no activity occurs in 1 minute (the default, but it depends on marketing areas). If you set an animation as a screen saver image, only the last frame of that animation shows in either display after the screen saver image has finished playing.

Find the Feature



- > **Settings**
- > **Display/External display**
- > **Screen saver**

Tip: Scroll to **Off** or **Power saving** to turn **Screen saver** or the LCM off so that you can extend your battery life.

Customizing Service Light

You can specify a service light for use when the phone is successfully connected to your service provider, when you receive incoming calls or the alarm clock rings, and when you have new events.

Find the Feature



- > **Settings**
- > **Initial settings**
- > **Service light**

Press

To

1



scroll to the desired option



Press	To
2 OK ()	select the option
3 	scroll to the desired service light
4 OK ()	select the service light

Using Ambient Light Sensor

The keypad backlight can be turned on automatically when your surroundings are dark.

Find the Feature



- > **Settings**
- > **Initial settings**
- > **Light sensor**
- > **ON**



Calling Features

Putting a Call on Hold

When you are on a call, you can put the current call on hold.

Press	To
1 OPTIONS ()	open the options menu
2 	scroll to Hold Tip: Scroll to Activate to answer the call on hold.
3 OK ()	put the current call on hold

Answering a New Call



When you are on a call, you can answer a new incoming call.

To turn **Call waiting** on 1st:

Find the Feature

-  > **Settings**
- > **Call features**
- > **Call waiting**
- > **On**



To answer a new incoming call:

Press	To
1 	put the current call on hold and answer the new call
2 	end the new call and continue with the call on hold

Tip: If you have an active call and a held call, and you want to answer a new incoming call, you must end the active or held call to answer the new call. Depending on your service provider, you can also transfer current incoming calls to another phone number when you are not available. (To activate, press **OPTIONS** () > select **Deflection** > enter the desired phone number > press  .)

Making a New Call

When you are on a call, you can make a new outgoing call.



Press	To
1 OPTIONS ()	open the options menu
2 OK ()	select Dial new call
3 keypad keys	enter the desired phone number
4 	dial the phone number

Making an Emergency Call

With or without the SIM card installed, you can make an emergency call to the Emergency phone number your service provider gave you.

Press	To
1 keypad keys	enter the emergency phone number
2 	dial the emergency call

Selecting a Phone Number to Use



You can select a phone number (phone line) to make and receive calls.

Find the Feature



- > Settings
- > Call features
- > Phone lines

Redialing Automatically

You can immediately redial the last call you failed to make.

Find the Feature



- > Settings
- > Call features
- > Auto redial
- > ON



Checking Recent Calls

You can view the recent history for the calls you missed, received or dialed on your phone.

Find the Feature



- > Recent calls
- > Missed calls/Received calls/
Dialed calls

Tip: If the selected recent call entry includes a phone number, you may directly press  to dial. You can also press  > **Save** to store the recent call entry in your phonebook. To erase the recent call entry, press  > **Erase**.

Clearing Recent Call History

Find the Feature



- > Recent calls
- > Erase all



Messages and Chat

You can write, send and receive messages, either by Short Messaging Service (SMS) or by Multimedia Messaging Service (MMS). You can also open a chatroom to have an online chat.



Writing an SMS Message

You can insert quick notes, phonebook entries (numbers or names), image objects (pictures or animations), and sound objects (sounds or melodies) when composing an SMS message.

Find the Feature



- > **Msg. center**
- > **Write message**
- > **Text messages**

Press	To
1 keypad keys	enter text
2 	open the options menu
3 	scroll to the desired option beginning with Insert
4 OK ()	select the option
5 	scroll to the desired sub-option, if necessary
6 OK ()	select the sub-option, if necessary



Press	To
7 	scroll to the object you want to insert to your SMS message
8 OK ()	select the object
Tip: Repeat steps 2-8 to insert more objects, if necessary.	

Sending an SMS Message



To send your SMS message right after you finish editing it:

Press	To
1 SEND ()	select SEND
2 P.BOOK ()	open your phonebook
3 	scroll to the desired entry
4 OK ()	select the entry
Tip: If the entry includes more than 1 phone numbers, continue the following steps; otherwise, repeat steps 3-4 to add other recipients or go to steps 8-9 to send your SMS message immediately.	



Press	To
5 	scroll to the desired phone number
6 OK ()	select the phone number
7 OK ()	return to the previous menu
Tip: Repeat steps 3-4 to add other recipients or continue the following steps to send your SMS message.	
8 OK ()	return to the previous menu
9 SEND ()	send your SMS message

Saving an SMS Message as a Draft

To save your SMS message in the **Drafts** folder after you finish editing it:

Press	To
1 	open the options menu
2 	scroll to Save to drafts
3 OK ()	select Save to drafts
4 P.BOOK ()	select a recipient
5 	scroll to the desired phonebook entry
6 OK ()	select the phonebook entry



Press	To
7 	scroll to the desired phone number, if necessary
8 OK ()	select the phone number, if necessary
9 SAVE ()	save your SMS message along with recipient(s) in Msg. center > Drafts

Tip: You may also save your SMS message in the **Saved Msgs** folder under **Msg. center** by selecting  > **Save message** after you finish composing it.

Activating MMS Service



To send/receive MMS messages, you must subscribe for MMS service from your service provider and then activate your service provider on the phone. MMS service works via GPRS your service provider supports. To activate your service provider, follow the steps:

Find the Feature

-  > **Msg. center**
- > **Settings**
- > **Multimedia msg.**
- > **Connection settings**

Press	To
1 	scroll to the service provider you have subscribed for using MMS service



Press	To
2 OK ()	select the service provider
3 OK ()	activate the service provider

Writing an MMS Message

An MMS message may consist of several page sets. A page set can include an image object  (photo/picture/animation/video), a sound object  (melody/voice note), and/or text objects (quick notes/phone numbers).

Note: You can insert only 1 image object and 1 sound object to a page set. To insert more image and sound objects, press **YES** () when your phone displays: ...
existed, add to next page?

Find the Feature



- > **Msg. center**
- > **Write message**
- > **Multimedia msgs.**

Press	To
1 keypad keys	enter text
2 	open the options menu
3 	scroll to Insert object
4 OK ()	select Insert object
5 	scroll to the desired option



Press	To
6 OK ()	select the option
7 	scroll to the desired sub-option, if necessary
8 OK ()	select the sub-option, if necessary
	Tip: Repeat steps 7-8, if necessary.
9 	scroll to the object you want to insert to your MMS message
10 OK ()	insert the selected object
	Tip: Repeat this step if you select Media center to add objects.
	Tip: Repeat steps 2-10 to insert more objects, if necessary.

Switching among Page Sets

You can go to a desired page set and view the objects on it.

Press	To
1 	open the options menu
2 	scroll to Go to...



Press	To
3 OK ()	select Go to...
4 	scroll to the desired page set
5 OK ()	go to the selected page set

Viewing Media Objects

You can view any media objects in the current page set.

Press	To
1 	open the options menu
2 	scroll to View object
3 OK ()	select View object
4 	scroll to the desired object
5 OK ()	view the selected object

Deleting Media Objects

You can delete any media objects from the current page set.

Press	To
1 	open the options menu
2 	scroll to Remove object



Press	To
3 OK ()	select Remove object
4 	scroll to the desired object
5 OK ()	select the object
6 OK ()	delete the selected object

Deleting Page Sets

You can delete a page set, including all objects and a page itself in it. If there is only 1 page set, you can only delete all objects, not a page itself in it.

In the current page set (if it is not the only 1):

Press	To
1 	open the options menu
2 	scroll to Delete page
3 OK ()	delete the selected page set, including all objects and a page itself in it

In the only 1 page set:

Press	To
1 	open the options menu
2 	scroll to Delete page



Press	To
3 OK ()	delete all objects, not a page itself in it

Previewing an MMS Message

You can preview your created MMS message before sending it.

Press	To
1 	open the options menu
2 	scroll to Preview
3 OK ()	select Preview
4 	preview the next/previous page set(s)

Sending an MMS Message



You can send your MMS message to friends via either their phone numbers or email addresses.

To send via a phone number:

Press	To
1 SEND ()	select SEND
2 P.BOOK ()	open your phonebook



Press	To
3 	scroll to the desired entry
4 OK ()	select the entry Tip: If the entry includes more than 1 phone numbers, continue the following steps; otherwise, repeat steps 3-4 to add other recipients or go to steps 8-9 to send your MMS message immediately.
5 	scroll to the desired phone number
6 OK ()	select the phone number
7 OK ()	return to the previous menu Tip: Repeat steps 3-4 to add other recipients or continue the following steps to send your MMS message.
8 OK ()	return to the previous menu
9 SEND ()	send your MMS message

To send via an email address:

Press	To
1 SEND ()	select SEND
2 	open the options menu



Press	To
3 	scroll to New e-mail address
4 OK ()	select New e-mail address
5 keypad keys	enter an email address
6 OK ()	add the email address to the Recipients box
	Tip: Repeat steps 2-6 to add other recipients.
7 SEND ()	send your MMS message

Configuring Sending Options for MMS Messages



You can read delivery status reports for sent MMS messages, specify how long MMS messages will be stored in the message center, select a message priority level, choose to send MMS messages anonymously, let the message center send you notes if recipients read the MMS messages you sent to them, and determine when you want MMS messages to be sent.

Find the Feature



- > **Msg. center**
- > **Settings**
- > **Multimedia msgs.**
- > **Sending options**



Press	To
1 	scroll to the desired sending option
2 OK ()	select the sending option or check/uncheck the selected sending option
3 	scroll to the desired sub-sending option, if necessary
4 OK ()	select the sub-sending option, if necessary

Saving an MMS Message as a Draft

You can save your MMS message in the **Drafts** folder after you finish editing it.

Press	To
1 	open the options menu
2 	scroll to Set title
3 OK ()	select Set title
4 keypad keys	enter a name
5 OK ()	save the name
6 	open the options menu
7 	scroll to Save to drafts
8 OK ()	save your MMS message in Msg. center > Drafts

Reading a Received SMS/MMS Message

You can open the SMS/MMS messages you received in the **Inbox** folder.



Find the Feature



> **Msg. center**
> **Inbox**

Press	To
1 	scroll to the desired message
2 OK ()	read the selected message

Reading a Sent or Unsent SMS/MMS Message

You can open the SMS/MMS messages you sent or failed to send in the **Outbox** folder.

Find the Feature



> **Msg. center**
> **Outbox**



Indicates a sent SMS message.



Indicates an unsent SMS message.



Indicates a sent MMS message.



Indicates an unsent MMS message.



Press	To
1 	scroll to the desired message
2 OK ()	read the selected message

Reading a Draft Message

You can open the SMS/MMS messages you saved in the **Drafts** folder.

Find the Feature



> **Msg. center**
> **Drafts**



Indicates a draft SMS message.



Indicates a draft MMS message.

Press	To
1 	scroll to the desired message
2 OK ()	read the selected message

Reading a Saved SMS Message

You can open the SMS messages you saved in the **Saved Msgs** folder.

Find the Feature



> **Msg. center**
> **Saved Msgs**

Press	To
1 	scroll to the desired message
2 OK ()	read the selected message



Erasing SMS/MMS Messages

You can erase SMS/MMS messages stored in the **Inbox**, **Outbox**, **Drafts**, or **Saved Msgs** folder. To delete all the messages from a specified folder, scroll and select **Erase all**. To delete various messages you marked from a specified folder, scroll and select **Erase multiple**.

Find the Feature



> **Msg. center**

> **Erase all/Erase multiple**

Managing SMS/MMS Messages

You can perform these functions on a SMS/MMS message stored in the **Inbox**, **Outbox**, **Drafts**, or **Saved Msgs** folder:

- **Erase** (to erase the selected message)
- **Send/Resend** (to send/resend the selected message)
- **Move to drafts** (to move the selected message to the **Drafts** folder)
- **Reply** (to reply the selected message)
- **Forward** (to forward the selected message)
- **Edit** (to edit the selected message)
- **View** (to display objects included in the selected message)/**Save object** (to save objects from the selected message)



message)/**Object info.** (to read information on objects from the selected message)

- **Use address** (to dial/save a phone number, to connect to a URL, or to save a URL as a bookmark from the selected message)
- **Detail info.** (to read information on the selected message)
- **Callback** (to call to the sender of the selected message)
- **Open chatroom** (to chat with the sender of the selected message)
- **Save message** (to save the selected message in the **Saved Msgs** folder)

Find the Feature



> **Msg. center**

> **Inbox/Outbox/Drafts/Saved
Msgs**

Press	To
1 	scroll to the desired message
2 OK ()	select the message
3 OPTIONS ()	open the options menu
or	
	

Editing MMS Message Templates

You can edit MMS message templates and save them in **Msg. center > Templates > MMS templates**.



Find the Feature



> **Msg. center**
> **Templates**
> **MMS templates**

Press	To
1 	scroll to any entry
2 OK ()	select the entry
3 	scroll to Edit template
4 OK ()	select Edit template
5 	open the options menu and select an option from it to edit your MMS message template
6 SAVE ()	save the created MMS message template

Creating Quick Notes

You can create new quick notes for use in SMS messages.

Find the Feature



> **Msg. center**
> **Templates**
> **Quick notes**



Press	To
1 	scroll to any blank entry
2 OK ()	select the blank entry
3 	scroll to Edit quick note
4 OK ()	select Edit quick note
5 keypad keys	enter text
6 SAVE ()	save the created quick note

Setting a Voicemail Service Number

Your service provider may have set a voicemail service number before you receive your phone. If not, refer to the following procedures.

Find the Feature



> **Msg. center**

> **Voice mailbox**

Press	To
1 keypad keys	enter the voicemail service number your service provider provided
2 OK ()	save the setting

Editing Topic Messages



You can edit topic messages you want to receive from your service provider, such as traffic reports and today's news.



Find the Feature



- > **Msg. center**
- > **Cell broadcast**

Sorting Messages

You can classifying SMS and MMS messages by time or by type.

Find the Feature



- > **Msg. center**
- > **Settings**
- > **Message sorting**

Clearing Sending History

You can clear the SMS and/or MMS sending history from your phone memory.

Find the Feature



- > **Msg. center**
- > **Sending history**
- > **Text messages/Multimedia msgs.**

Press	To
1	open the options menu
2	scroll to Erase all



Press	To
3 OK ()	clear the SMS/MMS sending history

Editing Service Commands



You can edit service commands you want your service provider to operate.

Find the Feature



> **Msg. center**

> **Service command**

Press	To
1 keypad keys	enter the service command you want your service provider to operate
2 OK ()	send the service command to your service provider

Having an Online Chat



You can open up to 4 chatrooms and have an online chat.

Find the Feature



> **Tools**

> **Chatroom**



Press	To
1 	scroll to any chatroom available
2 NAMES ()	select from your phonebook a person you want to have a chat with
3 	scroll to the desired entry
4 OK ()	select the entry
5 	scroll to the desired phone number
6 OK ()	select the phone number
7 OK ()	save the setting
8 keypad keys	enter your nickname
9 OK ()	save the setting
10 keypad keys	enter your instant message
11 SEND ()	send your instant message

Adding a Quick Note or Smiley to Your Instant Message

Press	To
1 	open the options menu
2 	scroll to Insert quick note or Insert smiley



Press	To
3 OK ()	select Insert quick note or Insert smiley
4 	scroll to the desired quick note or smiley
5 OK ()	add the selected quick note or smiley to your instant message

Editing Your Nickname

Press	To
1 	open the options menu
2 	scroll to Nickname
3 OK ()	select Nickname
4 keypad keys	edit your nickname
5 OK ()	save the setting

Placing a Call to Chatters

Press	To
1 	open the options menu
2 	scroll to Call
3 OK ()	select Call



Press	To
4 CALL ()	make a phone call to the chatter

Saving Chat Numbers as Phonebook Entries

Press	To
1 	open the options menu
2 	scroll to Save
3 OK ()	select Save
4 SAVE ()	prepare to edit the phonebook entry
5 keypad keys	fill in the blanks with suitable words
6 SAVE ()	store the settings

Editing a Chatroom Phone Number

Press	To
1 	open the options menu
2 	scroll to Chat Numbers
3 OK ()	select Chat Numbers
4 keypad keys	edit a chatroom phone number



Press	To
5 OK ()	save the setting

Viewing Old Instant Messages

Press	To
1 	open the options menu
2 	scroll to View history
3 OK ()	view old instant messages

Clearing Instant Messages History

Press	To
1 	open the options menu
2 	scroll to Clear history
3 OK ()	delete all the old instant messages from phone memory

Configuring SMS Settings

You can select a service provider which supports SMS service, read delivery status reports for SMS messages, let the message center send you notes after recipients read your sent SMS messages, and specify a wireless

communication protocol for use in sending SMS messages.

Find the Feature



- > **Msg. center**
- > **Settings**
- > **Text messages**



Configuring MMS Settings

You can choose to seamlessly receive MMS messages, receive MMS messages even if you are roaming over another network, save MMS messages you sent, reject the message center to send you notes if recipients have read the MMS messages you sent to them, configure and activate MMS service, block certain MMS messages, and set various options when you send MMS messages.

Find the Feature



- > **Msg. center**
- > **Settings**
- > **Multimedia msgs.**

Selecting Memory for Saving SMS Messages

You can select either SIM card memory or phone memory to store your SMS messages.

Find the Feature



- > **Msg. center**
- > **Settings**
- > **Memory in use**
- > **Select SMS memory**

Checking SIM Card or Phone Memory Which Saves SMS Messages



You can read the details of SIM card or phone memory that saves your SMS messages.

Find the Feature



- > **Msg. center**
- > **Settings**
- > **Memory in use**
- > **SMS status**

Checking Phone Memory Which Stores MMS Messages

You can view the details of phone memory that stores your MMS messages.

Find the Feature



- > **Msg. center**
- > **Settings**
- > **Memory in use**
- > **MMS status**

Setting Up Your Phonebook

Selecting Memory for Saving Phonebook Entries

You can select either SIM card memory or phone memory to store your phonebook entries.

Find the Feature



- > Phonebook
- > Option
- > Memory

Checking SIM Card or Phone Memory Which Stores Phone Numbers and Notes

You can read the details of SIM card memory or phone memory that saves your phone numbers and notes.

Find the Feature



- > Phonebook
- > Option
- > Memory status



**X/100**

Number (X) of phone numbers in SIM card memory. You can store up to 100 phone numbers in SIM card memory.

Note: The capacity of SIM card memory depends on your service provider's settings.

**X/300**

Number (X) of phone numbers in phone memory. You can store up to 300 phone numbers in phone memory.

**X/100**

Number (X) of notes in phone memory. You can store up to 100 notes in phone memory.

Creating Phonebook Entries

You can add phonebook entries to **Phonebook** on your phone.

Find the Feature

> **Phonebook**> **Add**

Option	Description
Memory	specify memory for storing phonebook entries
Name	type a name
Number type	select a phone number type
Number	type a phone number
Caller group	specify a caller group for classifying phonebook entries
Picture *	add a photo caller ID

Option	Description
Note Type *	select a note type
Note *	enter text for the selected note type

* The option is available only for the phonebook entries saved in phone memory, not in SIM card memory.

Tip: Remember to press **SAVE** () when you finish editing phonebook entries.

Using Phonebook Entry Options

You can perform various functions on the selected phonebook entry.

Find the Feature



> **Phonebook**
> **Search**

Press	To
1 keypad keys	enter the 1st letter(s) of a name
2 OK ()	open your phonebook
3 	scroll to the desired entry
4 OK ()	select the entry





Press	To
5 	scroll to the name, the desired phone number/note, or the Personal picture entry (if you have added a photo caller ID)
6 	open the options menu

Option	Description
Edit	edit the selected phone number and then specify a number type or edit the name
Add > Add number	add phone number(s) (up to 4)
Add > Add text	add note(s)
Add > Caller group	specify a caller group for the selected entry
Add > Add picture	create a photo caller ID
Add > Add voice tag	record a name command and use it to dial by voice
Remove picture	remove a photo caller ID (by selecting Personal picture > )
Copy	copy/move the selected entry saved on SIM card memory to phone memory and vice versa

Option	Description
Erase	remove the selected entry or note
View	display the details of the selected entry

You can also use many other features for the selected phonebook entry via a different access method.

Find the Feature



> **Phonebook**

> **Search**



Press	To
1 keypad keys	enter the 1st letter(s) of a name
2 OK ()	open your phonebook
3 	scroll to the desired entry
4 	open the options menu

Option	Description
Detail	display the details of the selected entry
Add	add entry(ies)
Erase	delete the selected entry
Copy	copy/move the selected entry saved on SIM card memory to phone memory and vice versa



Option	Description
Caller group	specify a caller group for the selected entry
Speed dial	create a 1-touch dial entry
Send message	write and send an SMS message from the selected entry
Send business card	send the selected entry as a business card
Set as default	set the desired phone number to be called by default
View mode	display your phonebook entries as a text list or icons
Sort by	sort your phonebook entries by the desired sorting type

Creating a Photo Caller ID

You can add an image (photo caller ID) to a phonebook entry. Both the internal and the external displays show that image when the caller places a call to you.

Note: To create photo caller IDs, save phonebook entries on phone memory.

To create photo caller IDs from your phonebook:

Find the Feature



> **Phonebook**

> **Search**

Press	To
1 keypad keys	enter the 1st letter(s) of a name
2 OK ()	open your phonebook
3 	scroll to the desired entry
4 OK ()	select the entry
5 	open the options menu
6 	scroll to Add
7 OK ()	select Add
8 	scroll to Add picture
9 OK ()	select Add picture
10 	scroll to Media center Tip: Select Camera to use the picture you just took as a photo caller ID.
11 OK ()	select Media center
12 OK ()	select Photo album (for example)
13 	scroll to the desired folder
14 OK ()	select the folder
15 	scroll to the desired photo



Press	To
16 OK ()	select the photo
17 OK ()	set the selected photo as a photo caller ID attached to the phonebook entry

To create photo caller IDs from your media center:

Find the Feature



> **Media center**

Press	To
1 	scroll to Photo album (for example)
2 OK ()	select Photo album (for example)
3 	scroll to the desired folder
4 OK ()	select the folder
5 	scroll to the desired photo
6 	open the options menu
7 	scroll to Apply as
8 OK ()	select Apply as
9 	scroll to Personal icon
10 OK ()	select Personal icon
11 	scroll to the desired phonebook entry



Press	To
12 OK ()	set the photo as a photo caller ID attached to the selected phonebook entry

Sorting Phonebook Entries

You can sort phonebook entries by a desired type.

Find the Feature



- > Phonebook
- > Option
- > Sort by



Tip: Selecting **Location** lets you classify phonebook entries by creation priority numbered 1, 2, 3 and so on.

Browsing Your Phonebook to Make a Call

You can from the idle display look up your phonebook and pick up an entry to make a call.

To turn **Dialing number lookup** on 1st:

Find the Feature



- > Phonebook
- > Option
- > Dialing number lookup
- > ON

To pick up a phonebook entry and dial from the idle display:

Press	To
1 keypad keys	enter the 1st letter(s) of a name
2 	scroll to the desired entry
3 	make a phone call

1-Touch Dialing

You can press and hold any of the keys from  to  to quickly make a phone call from the idle display.

To turn **Speed dialing** on 1st:

Find the Feature

-  > **Settings**
- > **Call features**
- > **Speed dialing**
- > **ON**

To create 1-touch dial entries:

Find the Feature

-  > **Phonebook**
- > **Speed dial**

Press	To
1 	scroll to the desired speed dial key
2 OK ()	open your phonebook

Press	To
3 	scroll to the desired entry
4 OK ()	assign the speed dial key for the default phone number

Changing 1-Touch Dial Entries

Find the Feature



> **Phonebook**

> **Speed dial**

Press	To
1 	scroll to the desired name
2 	open the options menu
3 	scroll to Change
4 OK ()	open your phonebook
5 	scroll to the desired entry
6 OK ()	assign the speed dial key for the default phone number of the selected entry



Customizing Ring Tone for a Caller Group

You can select a ring tone for a caller group to use. The ring tone plays when 1 of the caller group calls you.

Find the Feature



> Phonebook

> Caller group



Press	To
1	scroll to the desired caller group
2 OK ()	select the caller group
3	scroll to Ring tone
4 OK ()	select Ring tone
5	scroll to the desired ring tone
6 OK ()	select the ring tone

Tip: To change the names of caller groups, scroll and select **Rename**. To display, add or delete caller group members, select **Member** > .

Creating a Photo Caller ID for a Caller Group

You can select an image (photo caller ID) for a caller group to use. The image displays when 1 of the caller group calls you.

Find the Feature



> **Phonebook**
> **Caller group**

To turn **Graphic** on 1st:

Press	To
1	scroll to the desired caller group
2 OK ()	select the caller group
3	scroll to Graphic
4 OK ()	select Graphic
5 ON ()	turn Graphic on

To use a preset image as a photo caller ID for a caller group:

Press	To
1	scroll to View
2 OK ()	select View





Press	To
3 	scroll to the desired preset image
4 OK ()	select the preset image

To use your own image as a photo caller ID for a caller group:

Press	To
1 	scroll to the blank entry
2 	open the options menu
3 	scroll to Media center Tip: Select Camera to use the picture you just took as a caller group photo caller ID.
4 OK ()	select Media center
5 	scroll to the desired option
6 OK ()	select the option
7 	scroll to the desired folder, if necessary
8 OK ()	select the folder, if necessary
9 	scroll to the desired object
10 OK ()	select the object

Press	To
11 OK ()	set the selected object as a photo caller ID for the caller group

To create a photo caller ID for a caller group from your media center:

Find the Feature



> **Media center**

Press	To
1 	scroll to Photo album (for example)
2 OK ()	select Photo album (for example)
3 	scroll to the desired folder
4 OK ()	select the folder
5 	scroll to the desired photo
6 	open the options menu
7 	scroll to Apply as
8 OK ()	select Apply as
9 	scroll to Group icon
10 OK ()	select Group icon
11 	scroll to the desired caller group

