



AGES 5 & UP

# SPORTS<sup>TM</sup> 2000



because kidz like toyz


KIDZ TOYZ, INC. WHITE PLAINS, N.Y. 10605

For Product Questions,  
Call 1-877-KIDZTOYZ (877-543-9869)  
Ask for CUSTOMER SERVICE.  
Only in the U.S. and CANADA

- TO OPERATE**
- Switch the **ON/OFF VOLUME** control **ON** by sliding upwards.
  - To transmit, press the **PUSH TO TALK** button with the speaker about 4" from your mouth.
  - To receive a message, release the **PUSH TO TALK** Button.
  - To transmit a code, press and hold the **PUSH TO TALK** Button and tap the **MORSE CODE** Button to transmit the desired code characters.
  - After you have finished using the walkie talkie, switch the **ON/OFF VOLUME** control **OFF** by sliding downward.


**CAUTION:**

- Operation performance may be affected by surrounding structures and equipment. For best results, use the walkie talkies in an open area.
- If your walkie talkies are not operating properly, install a new battery. The manufacturer recommends alkaline batteries for maximum performance.
- Always turn the walkie talkies "OFF" when you are finished using them.
- To prevent damage, do not expose them to rain or moisture.
- Do not touch the antenna with your fingers or hand, it may cause weak transmission.
- Your walkie talkies have been set and fully adjusted by the manufacturer prior to shipping. Do not touch internal parts other than replacing the battery.
- Modifications not authorized by the manufacturer may void users authority this device.



**BATTERY REPLACEMENT**

REMOVE SCREW TO OPEN BATTERY COMPARTMENT COVER.  
EACH UNIT REQUIRES 1-9V BATTERY (NOT INCLUDED).  
ALWAYS REPLACE BOTH BATTERIES AT THE SAME TIME.  
REPLACE BATTERY COMPARTMENT COVER AND SCREW.  
ALKALINE BATTERIES ARE RECOMMENDED FOR BEST PERFORMANCE.  
DO NOT MIX OLD AND NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD OR RECHARGEABLE (NICKEL-CADMIUM) BATTERIES.  
NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED.  
BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY.  
EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY.  
THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUTED.



MADE IN CHINA  
ITEM NO. 22210

Please visit us on the web at: [www.kidztoyz.com](http://www.kidztoyz.com)