



SCOSCHE FOUNDIT™ WALLET+ LTWAL2



Works with
Apple Find My

Works with Android
Find Hub

OVERVIEW APERÇU / DESCRIPCION GENERAL



Card Storage

The Foundit Wallet can store up to 4 cards in its outer pocket, 2 cards in the interior slots plus 1 more under the window pocket inside for a total of 7 cards. The window pocket is designed to store a driver's license or other ID card for presentation without the need for removal (Fig. 1, Pg. 2).

Apple Users

To add FOUNDIT™ WALLET+ to your Find My® network:

- Ensure Bluetooth Location Services are enabled.
- To enable discovery, press the button on the Foundit Wallet (Fig. 2, pg. 2). A confirmation sound will play.
- Open the Find My app on your Apple device.
- Select "Items" at the bottom of the screen, then "+" to "Add other item."
- Select it and assign a name to your item (this can be changed anytime).
- Select an icon that will represent the Foundit Wallet+ on the map screen (the icon can be changed anytime).
- Select finish.

- The Foundit Wallet+ can now be located using the Find My app.
- Select FOUNDIT™ WALLET+ in the Find My® App to:
- See last known location on the map or current location if nearby.
- Find by playing a sound once it is in range.
- Share location with others.
- Check battery status.
- Change the device name.

visit scosche.com/ind

IF FOUNDIT™ WALLET+ IS NOT DISCOVERABLE ON YOUR DEVICE DURING SETUP, TRY THE FOLLOWING:

1. Use the Reset procedure.
2. Restart your Device.

(refer to page 4 for details)

Charging the Battery

The Foundit Wallet+ can be recharged using any Qi-compatible wireless charger. Place the charging symbol on the back of the housing (Fig. 3, Pg. 2) against the charging surface. An orange light indicates charging, a green light indicates charging is complete (Fig. 4, Pg. 2). The light will turn off when the battery is fully charged. The light will not affect charging. If the charging indicator light is not on simply adjust the position of the Wallet on the charger until the light turns on.

Android™ Users

To add FOUNDIT™ WALLET+ to the Find Hub App:

- If Find Hub is not pre-installed on your device, download the app on Google Play.
- Ensure Bluetooth and Location Services are enabled.
- To enable discovery, press the button on the Foundit Wallet+ (Fig. 2, pg. 2). A confirmation sound will play.
- The Foundit Wallet+ will automatically pop up on your device screen.
- Follow the prompts to add to your Find Hub items list.
- The Foundit Wallet+ can now be located using the Find Hub app.

Select FOUNDIT™ WALLET+ in the Find Hub app to:

- See last known location on the map or current location if nearby.
- Find by using the haptic feature or playing a sound if it is in range.
- Share location with others.
- Check battery status.
- Change the device name.

visit android.com/ind

IF FOUNDIT™ WALLET+ IS NOT DISCOVERABLE ON YOUR DEVICE DURING SETUP, TRY THE FOLLOWING:

1. Use the Reset procedure.
2. Restart your Device.

(see below)

Turn off or Reset Procedure

To turn off/disabled without resetting:

- Press and hold the button for 15 seconds until a confirmation sound is heard (Fig. 2, Pg. 2). Foundit Wallet+ is now disabled and cannot be found until the button is pressed again to re-enable it.

To reset to original factory settings:

- Short press the button once, then press and hold for 5 seconds until you hear 4 steady beeps (Fig. 2, Pg. 2). The device will reset to factory settings.
- Remove from your wallet and add to the Find My app (Apple device) or the Find Hub app (Android device).
- The Foundit Wallet+ is reset to its original state. It can no longer be found and can now be paired with any device.

Rangement pour les cartes

Nous Foundit Wallet+ peut ranger jusqu'à 4 cartes dans sa poche extérieure, 2 cartes dans les fentes intérieures et 1 carte de plus sous la poche fenêtre à l'intérieur, pour un total de 7 cartes. La poche fenêtre est conçue pour ranger une permis de conduire ou une carte d'identité afin de faciliter sa présentation sans avoir à la sortir (Fig. 1, page 2).

Utilisateurs Apple

Pour ajouter le chargeur FOUNDIT™ WALLET+ à votre réseau Find My® :

- Assurez que les services Bluetooth et les services de localisation sont activés et autorisés à deux niveaux.
- Pour activer la découverte appuyez sur le bouton de Foundit Wallet+ (Fig. 2, page 2). Un son de confirmation va émettre.

Le Foundit Wallet+ va apparaître automatiquement sur votre réseau Find My.

- Sélectionner les 4 items (préciser) au bas de l'écran, puis "+" puis «Ajouter d'autres items».
- Le Foundit Wallet+ devrait apparaître sur votre écran.
- Sélectionner l'icône, et lui assigner un nom (ce nom pourra être modifié en tout temps).
- Sélectionner une icône, cela représentera votre localisateur sur la page de la carte (peut être modifiée en tout temps).
- Sélectionner «Finir l'ajout».

Le Foundit Wallet+ peut maintenant être localisé en utilisant votre appli Find My.

- Sélectionner FOUNDIT™ WALLET+ dans l'appli Find My® pour :
 - Voir la dernière emplacement connu sur la carte, ou un emplacement actuel si à proximité.
 - Faire résonner ou utiliser la fonction tactile pour trouver l'objet si c'est à portée.
 - Partager l'emplacement avec les autres.
 - Vérifier l'état de la pile.
 - Changer le nom de l'appareil.

OU

visitez apple.com/ind

S'IL LE CHARGEUR FOUNDIT™ WALLET+ N'EST PAS DÉCOUVRABLE SUR VOTRE APPAREIL LORS DE LA CONFIGURATION, ESSAYEZ CE QUI SUIT :

1. Réinitialiser la procédure de mise à jour.
2. Redémarrer votre appareil.

(référer à la page 5 pour plus de détails)