





4.3 Front view with the case removed




4.4 Rear view with the case removed




4.5 Component side of the Main Board & RS232/TTL Expansion Board




4.6 Non-component side of the Main Board & RS232/TTL Expansion Board



4.7 Component side of the Scanner Driver Board



4.8 Non-component side of the Scanner Driver Board



4.9 View with case removed and Scanner Head exploded