


Label Diagram and Placement



Label is located on outer back surface of device.

Text is 4 point font or larger.