

GARMIN.

Quick Start Manual

Getting Started

WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Setting Up the System

Complete these tasks to set up the system.

- 1 Charge the A03071 device (page 3).
- 2 Install backup batteries in the A03070 unit (page 3).
- 3 Select a mounting location, and install the A03070 unit (page 4).
- 4 Set up a boundary (page 5).
- 5 Use the wireless system.

Device Overviews

A03070 Unit

①	Keypad
②	Battery cover D-ring
③	Power port

A03071 Device

①	Power key
②	Status LED
③	Contact points
④	Charging clip contacts
⑤	Band

Charging the A03071 Device

NOTICE

To prevent corrosion, thoroughly dry the contacts on the A03071 device and the surrounding area before connecting the charging clip.

You should fully charge the battery before you use the device for the first time. Charging a fully depleted battery takes about two hours.

- 1 Snap the device ① onto the charging clip ②.

- 2 Plug the power cable into a power source.

The status LED is solid red when the device is charging.

- 3 After the status LED turns solid green, remove the charging clip from the device.

Turning On the A03071 Device

Hold the power key until the status LED turns green and the device beeps.

Installing Backup Batteries

The A03070 unit uses three AA batteries (not included). You should install backup batteries in the A03070 unit to maintain an active signal during a power outage.

NOTE: Use NiMH or lithium batteries for best results.

- 1 Turn the D-ring counter-clockwise, and pull up to remove the cover.
- 2 Insert three AA batteries, observing polarity.

- 3 Replace the battery cover, and turn the D-ring clockwise.

Mounting Location Considerations

- The A03070 unit should be approximately 1.5 m (5 ft.) above the ground when mounted.
- The A03070 unit should be near a power source.
- The A03070 unit should be away from metal structures, appliances, microwaves, and wireless routers for ideal operation.
- You must leave enough cable length to reach the power source. To purchase a longer accessory cable, go to buy.garmin.com.

Installing the A03070 Unit

- 1** Choose a mounting location (page 4).
- 2** Using two screws (not included), attach the mount to an exterior wall for best results.
- 3** Pull up the weather cap from the power port.

- 4** Plug the small end of the power cable into the port on the base unit.

- 5** Slide the base unit into the mount.

- 6** Plug the power cable into a power source.

Device Information

A03070 and A03071 Device Specifications

Operating temperature range From -20 to 60 C (from -4 to 140 F)

Charging temperature range	From 0 to 45 C (from 32 to 113 F)

Support and Updates

- You can update software and maps for your A03070 device using Garmin Express™.
- You can update software for your A03071 device using Garmin WebUpdater.

Getting the Owner's Manual

The owner's manual includes instructions for using device features and accessing regulatory information.

Go to garmin.com/manuals

support.garmin.com

© 2017 Garmin Ltd. or its subsidiaries

Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. . These trademarks may not be used without the express permission of Garmin.

M/N: A03070, M/N: A03071

Printed in Taiwan
August 2017
I90-02273-90_01

