




GARMIN A04684



GARMIN.

2

Set Up • Configuration • Configurazione • Einrichtung • Configurar



garmin.com/driveapp




Manuals and Regulatory Information • Manuels et informations réglementaires • Manuali e note legali
Handbücher und Regulierungsinformationen • Manuales e información legal



garmin.com/manuals/A04684

Data Transfer • Transfert de données • Trasferimento dati • Datenübertragung • Transferencia de datos



support.garmin.com

© 2023 Garmin Ltd. or its subsidiaries

Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Garmin Dash Cam™ is a trademark of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The microSD™ logo is a trademark of SD-3C, LLC.

MN: A04684





Printed in Taiwan
October 2023
I90-03082-02_0A



1

Installation • Installation • Installazione • Installation • Instalación



TIP: To hide the 4 m (13 ft.) cable, route it behind the vehicle trim along the windshield, doorframe, or dash.

ASTUCE : pour masquer le câble de 4 m (13 pi), faites-le passer sous le ciel de toit le long du pare-brise, de la portière ou du tableau de bord.

SUGGERIMENTO : per nascondere il cavo da 4 m (13 piedi), passarlo dietro all'allestimento del veicolo lungo il parabrezza, lo sportello o il cruscotto.

TIPP: Verlegen Sie das 4 m (13 Fuß) lange Kabel hinter der Verkleidung des Fahrzeugs entlang der Windschutzscheibe, des Türrahmens oder des Armaturenbretts, damit es nicht zu sehen ist.

SUGERENCIA: Para ocultar el cable de 4 m (13 ft), colócalo a lo largo de la moldura del parabrisas del vehículo, del marco de la puerta o del salpicadero.

