



PREFACE

Quick Tips

- To find an address, see [page 3](#).
- To learn about the map, see [page 8](#).
- To adjust the backlight brightness, see [page 16](#).
- To clean and store your StreetPilot, see [page 24](#).
- To turn off the GPS receiver to use indoors, see [page 10](#).

Manual Conventions

Serial Number

Record the serial number (8-digit number located on the **back of the unit, under the Auto Mount bracket**) in case your StreetPilot 7200 needs service or you want to buy additional maps.

Serial Number: ____ _

Contact Garmin

If you encounter any difficulty while using your StreetPilot 7200, or if you have any questions, in the U.S.A. contact Garmin Product Support by phone at 913/397.8200 or 800/800.1020, Monday–Friday, 8 AM–5 PM Central Time; or by e-mail at sales@garmin.com. In Europe, contact Garmin (Europe) Ltd. at 44/0870.8501241.

The unit has no user-serviceable parts. If you ever have a problem with your unit, take it to an authorized Garmin dealer for repairs.

The unit is fastened shut with screws. Any attempt to open the case to change or modify the unit in any way voids your warranty and may result in permanent damage to the equipment.



TABLE OF CONTENTS

Preface	i
Quick Tips	i
Manual Conventions	i
Serial Number	i
Contact Garmin	i
 Warning	iv
 Caution	v
Caring for Your StreetPilot 7200	vi
Find It and Go!	1
Finding a Restaurant 	1
Following Your Route	2
Where To?	
 Where To?	3
Finding an Address 	3
Finding a Place by Browsing the Map	4
Finding Streets and Cities	4
Finding Recently Found Places	4

ii

TABLE OF CONTENTS

Changing Your Search Area	5
Finding a Place Near Another Place	5
Narrowing Your Search	5
My Locations 	7
Saving Places You Find	7
Finding Saved Places	7
Editing Saved Places	7
Going Home	8
Deleting a Saved Place	8
Setting a Home Location	8
Viewing the Map and Other	
Pages	9
Viewing the Map Page	9
Trip Computer	10
Turn List	10
Voice Directions	10
GPS Info	11
Creating and Editing Routes	12
Creating a New Route	12
Editing a Saved Route	13
Saving the Active Route	13
Navigating a Saved Route	13
Recalculating the Route	13
Adding a Detour to a Route	13
Stopping Your Route	13
Adding Avoidances	14
Using The Logs	15
Adjusting the Track Log	15
Using the Mileage Logs	15
Listening to Music	16
XM Radio	16
Listening to Music over the Vehicle's Speakers	19
Watching Videos	21
Connecting a Video Device	21
Video Settings	21

StreetPilot 7200 Owner's Manual



TABLE OF CONTENTS

Customizing the StreetPilot 7200

23

Customizing the General Settings ..	23
Changing the Map Settings.....	25
Changing the Navigation Settings...	26
Adjusting the Traffic Settings	27
Changing the Screen Settings	27
Viewing Unit Information (About)	27
Restoring the Settings.....	28
Adjusting the Volume	28

Traffic Information with an FM

TMC Traffic Receiver29

Connecting the GTM 10 to Your 7200.	29
Viewing Traffic Events.....	29
Understanding Traffic Symbols	29
Changing the Traffic Settings.....	29
Adding a Subscription	30
Switching Between Providers	31

Appendices32

StreetPilot 7200 Owner's Manual

Using the Remote Control.....	32
Installing the StreetPilot in Your Vehicle..	33
USB Mass Storage	34
Connecting the GXM 30.....	35
Custom POIs (Points of Interest)	36
Technical Specifications	37
Changing the Fuse.....	37
Not waterproof	37
Using a Remote Antenna	38
Updating the Software and Map Data.	38
Software License Agreement	38
FCC Compliance.....	39
Weather Data Warranty	40
XM Satellite Radio Service Agreement ...	41

DoC Here42

Index43

iii



PREFACE


Warning

This manual uses the term **Warning** to indicate a potentially hazardous situation, which, if not avoided, could result in death or serious injury.

Failure to avoid the following potentially hazardous situations could result in an accident or collision resulting in death or serious injury.

When installing the unit in a vehicle, place the unit securely so that it does not interfere with vehicle operating controls or obstruct the driver's view of the road (see diagram).

Do not mount where driver's field of vision is blocked.



Do not place unsecured on the vehicle dash.

Do not mount in front of an airbag field of deployment.

When navigating, carefully compare information displayed on the unit to all available navigation sources, including information from street signs, visual sightings, and maps. For safety, always resolve any discrepancies or questions before continuing navigation.

Always operate the vehicle in a safe manner. Do not become distracted by the unit while driving, and always be fully aware of all driving conditions. Minimize the amount of time spent viewing the screen of the unit while driving and use voice prompts when possible.

Do not enter destinations, change settings, or access any functions requiring prolonged use of the unit's controls while driving. Pull over in a safe and legal manner before attempting such operations.

The unit contains a non-user-replaceable, rechargeable lithium-ion battery. The battery may present a risk of fire or chemical burn if mistreated.

- Do not remove from the unit, heat unit above 158°F (70°C), or incinerate.
- Dispose of unit properly. Contact your local waste disposal department for information on properly disposing of lithium-ion batteries.

WARNING: This product, its packaging, and its components contain chemicals known to the State of California to cause cancer, birth defects, or reproductive harm. This Notice is being provided in accordance with California's Proposition 65. If you have any questions or would like additional information, refer to our Web site at <http://www.garmin.com/prop65>.





Caution

This manual uses the term **Caution** to indicate a potentially hazardous situation, which, if not avoided, may result in minor injury or property damage. It may also be used without the symbol to alert you to avoid unsafe practices.

Failure to avoid the following potentially hazardous situations may result in injury or property damage.

The unit is designed to provide you with route suggestions. It does not reflect road closures or road conditions, traffic congestion, weather conditions, or other factors that may affect safety or timing while driving.

Use the unit only as a navigational aid. Do not attempt to use the unit for any purpose requiring precise measurement of direction, distance, location, or topography. This product should not be used to determine ground proximity for aircraft navigation.

The Global Positioning System (GPS) is operated by the United States government, which is solely responsible for its accuracy and maintenance. The government's system is subject to changes which could affect the accuracy and performance of all GPS equipment, including the unit. Although the unit is a precision navigation device, any navigation device can be misused or misinterpreted and, therefore, become unsafe.

Important Information

MAP DATA INFORMATION: One of the goals of Garmin is to provide customers with the most complete and accurate cartography that is available to us at a reasonable cost. We use a combination of governmental and private data sources, which we identify in product literature and copyright messages displayed to the consumer. Virtually all data sources contain inaccurate or incomplete data to some extent. **This is particularly true outside the United States, where complete and accurate digital data is either not available or prohibitively expensive.**

StreetPilot 7200 Owner's Manual

v



PREFACE

Caring for Your StreetPilot 7200

The StreetPilot 7200 is constructed of high quality materials and does not require user maintenance other than cleaning.

Cleaning the Unit

Clean the unit's outer casing using a cloth dampened with a mild detergent solution and then wipe dry. Avoid chemical cleaners and solvents that can damage plastic components.

Caring for the Touch Screen

The touch screen is intended to be operated with a finger. Never use a hard or sharp object to operate the touch screen or damage may result. Though a PDA stylus can also be used to operate the touch screen, never attempt this while operating a vehicle.

Clean the touch screen using a soft, clean, lint-free cloth. Use water, isopropyl alcohol, or eyeglass cleaner if needed. If these are used, apply the liquid to the cloth and then gently wipe the touch screen.

Protecting Your StreetPilot 7200

- Do not store the unit where prolonged exposure to extreme temperatures can occur (such as in the trunk of a car), as permanent damage may result.
- Do not leave your unit in plain sight when you leave your vehicle to avoid theft.
- Do not store alkaline batteries in the remote control for extended periods. To reduce the chance for battery leakage in the battery compartment, remove the batteries when storing the remote control for more than six months.