



WATCHING VIDEOS

You can watch DVD videos and monitor a backup camera using your 7200.

Connecting a Video Device

Video Settings




WATCHING VIDEOS




CUSTOMIZING THE STREETPILOT 7200

To change StreetPilot settings, open the Menu page and touch **Settings**. See the following pages for more information.

1 Touch **Settings**.



2 Touch the setting.



StreetPilot 7200 Owner's Manual

Customizing the General Settings

From the Menu page, touch **Settings** >  **General**.

GPS

From the Menu page, touch **Settings** >  **General** > **GPS**. See [page 10](#).

Language

From the Menu page, touch **Settings** >  **General** > **Language**

Voice Language—select the language for the vocal prompts.

Text Language—select the language for the text. Note:
This setting does not affect the text in the map....

Speech Rate—select the rate at which prompts are spoken.

Phonetics—turn off and on the phonetics feature, which




CUSTOMIZING THE STREETPILOT 7200

allows the vocal prompts to more correctly pronounce words.

Audio

From the Menu page, touch **Settings** >  **General** > **Audio**

Audio Output—select Internal Speaker or FM Transmitter. For more information about broadcasting the 7200 Audio over your vehicle's stereo using the FM Transmitter, see page XX.



Attention Tone—turn on or off the attention tone sounded before voice prompts.

Touch screen Tone—turn off or on the tone sounded each time you touch of the screen.

Keypress Tone—???? No keys

Speed-Adjusted Volume—Wally?

Video Input

From the Menu page, touch **Settings** >  **General** > **Video**

Input Type—select the video input type: DVD/video or Backup Camera.

Reverse Response—select how the 7200 handles reversing the automobile when a Backup Camera is used.

Volume—opens the volume adjustment screen. See page XX for more information.

Proximity Alerts

From the Menu page, touch **Settings** >  **General** > **Proximity Alerts**. This adjust the visual and audio notifications for custom POIs you have loaded on the 7200. See [page 23](#) for more information.

Audio Notification

Visual Notification

Continuous Notification *StreetPilot 7200 Owner's Manual*



Units

From the Menu page, touch **Settings** >  **General** > **Units**. Change units of measure to Metric or Statute, Custom.

Time Zone

From the Menu page, touch **Settings** >  **General** > **time Zone**. Select a time zone or city.

Time Format

From the Menu page, touch **Settings** >  **General** > **Time Format**. Choose a 12- or 24-hour time format or UTC.

Daylight Saving

From the Menu page, touch **Settings** >  **General** > **Daylight Saving**. Select on or off, or **Auto**.

Safe Mode

From the Menu page, touch **Settings** >  **General** > **Safe Mode**. Turn on or off the Safe Mode, which

StreetPilot 7200 Owner's Manual

disables all unit functions that require significant operator attention and could become a distraction while driving.

Changing the Map Settings

From the Menu page, touch **Settings** >  **Map**.



Map Detail—adjust the amount of detail shown on the map. Displaying more detail causes the map to redraw slowly.

Orientation—change the perspective of the map.

- **2D North Up**—display the map in 2 dimensions (2-D) with North at the top.
- **2D Track Up**—display the map in 2 dimensions (2-D) with your direction of travel at the top.



CUSTOMIZING THE STREETPILOT 7200

• **3D Track Up**—display the map in 3 dimensions (3-D), Track Up orientation. This is the default map view.

Color Mode—choose **Day** for a bright background. Select **Night** for a black background. Select **Auto** to automatically switch between the two.

Auto Zoom—disable or enable automatic zooming on the map for optimal viewing.

Route Color—select the color of the route line.

Dim Roads—dim roads that are not on your route.

Map Data Fields—adjust the width of the data fields displayed on the map page. To select the type of information displayed in the fields, select **Wide** or **Thin** and touch **Next**.

Text Size—adjust the display size of text on the map.

Zoom Level Detail—adjust the zoom level at which map items are shown.

Detail Maps—enable and disable the detailed maps loaded in your 7200.


Changing the Navigation Settings

From the Menu page, touch **Settings** >  **Navigation**.

Vehicle—specify your vehicle type to optimize routes.

Preference—select a preference for route calculations.

Ask Preference—select whether the unit asks for your preference each time it calculates a route.



Next Turn Pop-up—select when the Next Turn pop-up window appears.

Off-Route Recalculation—set the way the unit recalculates the route. You can silence the “Off-Route,



recalculating” message here.

Continuous Auto Routing—Hmmm

Avoidance Setup—see [page 13](#).

Adjusting the Traffic Settings

See [page 21](#).

Changing the Screen Settings


From the Menu page, touch **Settings** >  **Screen**.

Brightness—select **Manual Brightness** and then touch  to decrease the brightness of the backlight or  to increase it. Select **Auto** for automatic brightness adjustment.

Calibrate Touch Screen—if you think the touch screen is not responding properly, you can calibrate the screen.

Viewing Unit Information (About)

From the Menu page, touch **Settings** >  **About** > **StreetPilot**. The unit’s software version, audio version, and unit ID are listed.



FM Traffic Receiver’s Unit ID

If you have a FM Traffic Receiver, you can view the FM Traffic Receiver’s unit ID through the 7200. Connect the GTM 10 to the 7200 using the USB cable.

From the Menu page, touch **Settings** > **About** > **FM Traffic Receiver**. Or, from the Menu page, touch **Settings** > **Traffic** > **Traffic Receiver** > **Subscriptions** > **Add Subscription**. The GTM 10’s unit ID is shown.



CUSTOMIZING THE STREETPILOT 7200

XM Radio ID



If you have an XM Smart Antenna, you can view the XM Antenna's Radio ID through the 7200. Connect the GXM 30 to the 7200 using the USB cable. From the Menu page, touch **Settings** > **About** > **XM**.

Restoring the Settings

To restore the unit to its original settings, open the Menu page and touch **Settings** > **Restore Defaults** > **Yes**.

Adjusting the Volume

From the Menu page, touch **Volume**. Touch the  and  to adjust the volume of the speaker.





TRAFFIC INFORMATION WITH AN FM TMC TRAFFIC RECEIVER

Using a Garmin FM TMC Traffic Receiver, your StreetPilot 7200 can receive and use traffic information broadcast over the FM Radio Data System (RDS). When a traffic message is received, your unit displays the event on the map and can change your route to avoid the traffic incident; no more changing the radio stations to hear the latest traffic report! For more information about the GTM 10 FM TMC Traffic Receiver, visit the Garmin Web site (www.garmin.com). For participating subscription providers, refer to the Garmin Web site at <http://www.garmin.com/fmtraffic>.

Connecting the GTM 10 to Your 7200

Connect your FM Traffic Receiver to your 7200; plug the mini-USB cable into the mini-USB connector located on the back of the 7200, under the weather cap.

Viewing Traffic Events

From the Menu page, touch **Tools** > **Traffic Info**.

Traffic Near Here		
⚠ I-290 WESTBOUND	5.6"	E
⚠ I-294 NORTHBOUND	5.9"	W
⚠ IL-53 NORTHBOUND	20.8"	NW
⚠ I-90 EASTBOUND	37.2"	NW
Back	Near...	▲ ▼

Understanding Traffic Symbols

There are several

Changing the Traffic Settings

From the Menu page, touch **Settings** > **Traffic**. For more information about the Traffic settings, see page XX.




TRAFFIC


Adding a Subscription

Your GTM 10 may have a trial subscription or you may be in an area with free service. You can also add subscriptions to expand your service area. Write down your FM Traffic Receiver's unit ID; see below or [page 17](#). Go to <http://www.garmin.com/fmtraffic> to purchase a traffic subscription and get a 25-character traffic subscription code.


1 Touch **Settings**.




2 Touch **Traffic**.




3 Touch **Traffic Receiver**.




4 Touch **Subscriptions**.



5 Touch **Add Subscription**.



6 Touch **Next**.



7 Enter the code and touch **Next**.



8 Touch **OK**.

