

M-RBG112

Logitech
LX7
Cordless Optical Mouse

Installation




1



English Turn ON computer.
Deutsch Schalten Sie den Computer EIN.
Français Mettre l'ordinateur sous tension.
Italiano Accendere il computer.
Español ACTIVE el ordenador.
Português Ligue o computador.
Nederlands Zet de computer AAN.
Svenska Starta datorn.

Dansk Tænd for computeren.
Norsk Slå på dataskjermen.
Suomi Käynnästä tietokone.
Ελληνική Ενεργοποίησε τον υπολογιστή.
Πο-руськи Включите компьютер.
Magyar Kapcsolja be a számítógépet.
Česká verze Zapněte počítač.
Po polsku Włącz komputer.

2



English For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Deutsch For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Français For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Italiano For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Español For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Português For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Nederlands For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Svenska For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Dansk For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Norsk For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Suomi For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.

Ελληνική For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Πο-руськи For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Magyar For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Česká verze For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.
Po polsku For Desktop PC: 1) Plug USB stand into computer's USB port. 2) Insert wireless mini-receiver into USB stand. For **Notebooks**: 3) Plug wireless mini-receiver directly into computer's USB port.

3



English Slide the battery door off. Install the AA battery.
Deutsch Slide the battery door off. Install the AA battery.
Français Slide the battery door off. Install the AA battery.
Italiano Slide the battery door off. Install the AA battery.
Español Slide the battery door off. Install the AA battery.
Português Slide the battery door off. Install the AA battery.
Nederlands Slide the battery door off. Install the AA battery.
Svenska Slide the battery door off. Install the AA battery.
Dansk Slide the battery door off. Install the AA battery.
Norsk Slide the battery door off. Install the AA battery.
Suomi Slide the battery door off. Install the AA battery.
Ελληνική Slide the battery door off. Install the AA battery.
Πο-руськи Slide the battery door off. Install the AA battery.
Magyar Slide the battery door off. Install the AA battery.
Česká verze Slide the battery door off. Install the AA battery.
Po polsku Slide the battery door off. Install the AA battery.

4



English Turn ON mouse.
Deutsch Turn ON mouse.
Français Turn ON mouse.
Italiano Turn ON mouse.
Español Turn ON mouse.
Português Turn ON mouse.
Nederlands Turn ON mouse.
Svenska Turn ON mouse.
Dansk Turn ON mouse.
Norsk Turn ON mouse.
Suomi Turn ON mouse.
Ελληνική Turn ON mouse.
Πο-руськи Turn ON mouse.
Magyar Turn ON mouse.
Česká verze Turn ON mouse.
Po polsku Turn ON mouse.

5



English To enjoy all the features of your product, install the software. For Macintosh users, download software at www.logitech.com/LX7mac.
Deutsch Um alle Funktionen Ihres Produkts zu nutzen, installieren Sie die Software. Macintosh-Nutzer können die Software herunterladen von www.logitech.com/LX7mac.
Français Pour pouvoir utiliser pleinement toutes les fonctions de votre produit, installez le logiciel. Utilisateur Macintosh: téléchargez le logiciel à partir du site www.logitech.com/LX7mac.
Italiano Per potere utilizzare tutte le funzionalità del prodotto, occorre installare il software. Gli utenti Macintosh: download scaricate il software dal sito www.logitech.com/LX7mac.
Español Para disponer de todas las funciones del producto, debe instalar el software. Los usuarios de Macintosh: descargue el software desde www.logitech.com/LX7mac.
Português Para utilizar todas as funções do produto, instale o software. Para os utilizadores de Macintosh: descarregue o software em www.logitech.com/LX7mac.
Nederlands Installeer de software om alle functies van uw product te kunnen gebruiken. Macintosh gebruikers kunnen de software downloaden van www.logitech.com/LX7mac.

Svenska Installera programmet om du vill kunna utnyttja alla produktens funktioner. Macintosh-användare kan ladda ned programvaran från www.logitech.com/LX7mac.
Dansk Hvis du vil have fuld udbytte af alle produktens funktioner, skal du installere programmet. Macintosh-brugere kan hente programmet på www.logitech.com/LX7mac.
Norsk Hvis du ønsker å kunne bruke alle funksjonene til denne enheten, må du installere programmet. Macintosh-brukere kan hente programmet fra www.logitech.com/LX7mac.
Suomi Jossin pitää asentaa ohjelma, jotta voit käyttää kaikkia tuotteen toimintoja. Macintosh-käyttäjät voivat ladata ohjelman www.logitech.com/LX7mac.
Ελληνική Προσκαλέστε τον εγκατάσταση του λογισμικού, για να μπορείτε να χρησιμοποιήσετε όλες τις λειτουργίες του προϊόντος. Οι χρήστες Macintosh: κατεβάστε το λογισμικό από το www.logitech.com/LX7mac.
Πο-руськи Для использования всех функций устройства необходимо установить программное обеспечение. Пользователи Macintosh: скачайте программное обеспечение с веб-сайта www.logitech.com/LX7mac.
Magyar A termék összes szolgáltatásának használatához szükséges a szoftver. Macintosh-használók letölthetik a szoftvert a www.logitech.com/LX7mac címről.
Česká verze Chcete-li využít všechny funkce produktu, je třeba nainstalovat příslušný software. Uživatelé systému Macintosh: stáhněte software ze stránky www.logitech.com/LX7mac.
Po polsku Zanim używać wszystkich możliwości tego urządzenia, należy zainstalować odpowiednie oprogramowanie z witryny www.logitech.com/LX7mac.

i



English 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Deutsch 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Français 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Italiano 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Español 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Português 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Nederlands 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.

when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Svenska 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Dansk 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Norsk 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Suomi 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Ελληνική 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Πο-руськи 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Magyar 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Česká verze 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.
Po polsku 1) The wheel plus zoom. Push wheel to either side to scroll side-to-side. Click and roll the wheel to zoom in and out. (Works only if software is installed.) 2) Universal forward and back buttons. 3) Left and right mouse buttons. Launch Logitech® SetPoint™ to customize button and 8B wheel assignments. 4) Battery LED. LED turns green briefly when mouse is powered on or is lit. LED blinks red when battery level drops below 10%.

www.logitech.com

© 2005 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

62380-001A-1