


Front view (FRONT-C-UNIT (for VX-7100))



Front view (FRONT-D-UNIT (for VX-7200))



Rear view



Left view



Right view



Top view



Bottom view



Microphone



DC Power Cable

